

AFRL-PR-WP-TR-1998-2068

**COMBUSTION AND HEAT
TRANSFER; VOLUME 2 -
ADVANCED JET FUELS DATA
SETS**



| | | |
|----------------|-----------------|-----------------|
| S. Zabarnick | D. R. Ballal | K. E. Binns |
| G. L. Dieterle | J. S. Ervin | R. R. Grinstead |
| S. P. Heneghan | D. H. Kalt | R. E. Kauffman |
| W. A. Rubey | R. C. Striebich | M. D. Vangsness |
| T. F. Williams | | |

University of Dayton Research Institute
300 College Park
Dayton, OH 45469-0001

APRIL 1998

FINAL REPORT FOR PERIOD JUNE 8, 1992 – DECEMBER 31, 1997

Approved for public release; distribution unlimited

**PROPULSION DIRECTORATE
AIR FORCE RESEARCH LABORATORY
AIR FORCE MATERIEL COMMAND
WRIGHT-PATTERSON AIR FORCE BASE, OH 45433-7251**


19990128 015

NOTICE


USING GOVERNMENT DRAWINGS, SPECIFICATIONS, OR OTHER DATA INCLUDED IN THIS DOCUMENT FOR ANY PURPOSE OTHER THAN GOVERNMENT PROCUREMENT DOES NOT IN ANY WAY OBLIGATE THE US GOVERNMENT. THE FACT THAT THE GOVERNMENT FORMULATED OR SUPPLIED THE DRAWINGS, SPECIFICATIONS, OR OTHER DATA DOES NOT LICENSE THE HOLDER OR ANY OTHER PERSON OR CORPORATION; OR CONVEY ANY RIGHTS OR PERMISSION TO MANUFACTURE, USE, OR SELL ANY PATENTED INVENTION THAT MAY RELATE TO THEM.

THIS REPORT IS RELEASABLE TO THE NATIONAL TECHNICAL INFORMATION SERVICE (NTIS). AT NTIS, IT WILL BE AVAILABLE TO THE GENERAL PUBLIC, INCLUDING FOREIGN NATIONS.

THIS TECHNICAL REPORT HAS BEEN REVIEWED AND IS APPROVED FOR PUBLICATION.



CHARLES W. FRAYNE
Combustion Branch
Propulsion Sciences and
Advanced Concepts Division



CHARLOTTE R. EIGEL
Chief, Combustion Branch
Propulsion Sciences and
Advanced Concepts Division



LEO S. HAROOTYAN, JR.
Deputy
Propulsion Sciences and
Advanced Concepts Division

Do not return copies of this report unless contractual obligations or notice on a specific document requires its return.

REPORT DOCUMENTATION PAGEForm Approved OMB
No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington DC 20503.

| | | | | |
|--|---|--|--|--|
| 1. AGENCY USE ONLY (Leave blank) | | 2. REPORT DATE April 1998 | 3. REPORT TYPE AND DATES COVERED Final 6/8/92 – 12/31/97 | |
| 4. TITLE AND SUBTITLE COMBUSTION AND HEAT TRANSFER; VOLUME 2 – ADVANCED JET FUELS DATA SETS | | | 5. FUNDING NUMBERS C-F33615-92-C-2207 PE: 62203 PR: 3048 TA: 05 WU: AH | |
| 6. AUTHOR(S) S. Zabarnick, D.R. Ballal, K.E. Binns, G.L. Dieterle, J.S. Ervin, R.R. Grinstead, S.P. Heneghan, D.H. Kalt, R.E. Kauffman, W.A. Rubey, R.C. Striebich, M.D. Vangsness, and T.F. Williams | | | | |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) University of Dayton Research Institute 300 College Park Dayton, OH 45469-0110 | | | 8. PERFORMING ORGANIZATION REPORT NUMBER UDR-TR-1998-00036 | |
| 9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) Propulsion Directorate Air Force Research Laboratory Air Force Materiel Command Wright-Patterson AFB, OH 45433-7251 POC: Charles W. Frayne, AFRL/PRSC, 937-255-6250 | | | 10. SPONSORING/MONITORING AGENCY REPORT NUMBER AFRL-PR-WP-TR-1998- 2068 | |
| 11. SUPPLEMENTARY NOTES | | | | |
| 12. DISTRIBUTION / AVAILABILITY STATEMENT Approved for public release; distribution is unlimited | | | 12b. DISTRIBUTION CODE | |
| 13. ABSTRACT (Maximum 200 words) This report consists of data set summaries of tests performed in support of the development of advanced jet fuels, including JP-8+100, JP-900, and endothermic fuels. This includes data sets for the quartz crystal microbalance (QCM), the isothermal corrosion oxidation test (ICOT), the Phoenix rig, the fuel/materials compatibility studies, the extended duration thermal stability test (EDTST), and the advanced reduced scale fuel system simulator (ARSFSS). These data sets, and/or more complete versions of them, may also be available in electronic format on the internet at https://posfbbs.appl.wpafb.af.mil or directly from the authors. The overall program accomplishments and details of the individual test devices employed during the contract period are contained in the accompanying volume entitled, "Combustion and Heat Transfer; Volume 1 – Advanced Jet Fuels Studies." | | | | |
| 14. SUBJECT TERMS Jet Fuel, JP-8, JP-8+100, Fuel Additives, Autoxidation, Thermal Stability, Deposition, Fuel Systems | | | 15. NUMBER OF PAGES 126 | |
| | | | 16. PRICE CODE | |
| 17. SECURITY CLASSIFICATION OF REPORT UNCLASSIFIED | 18. SECURITY CLASSIFICATION OF THIS PAGE UNCLASSIFIED | 19. SECURITY CLASSIFICATION OF ABSTRACT UNCLASSIFIED | 20. LIMITATION OF ABSTRACT SAR | |

This page intentionally left blank.

TABLE OF CONTENTS

| | |
|---|-----|
| LIST OF FIGURES | v |
| LIST OF TABLES | vii |
| PREFACE | ix |
| 1. INTRODUCTION AND SUMMARY | 1 |
| 2. QUARTZ CRYSTAL MICROBALANCE DATA | 3 |
| 3. ISOTHERMAL CORROSION OXIDATION TEST DATA | 47 |
| 4. PHOENIX RIG DATA | 69 |
| 5. FUEL/MATERIALS COMPATIBILITY DATA | 85 |
| 6. EXTENDED DURATION THERMAL STABILITY TEST RESULTS | 109 |
| 7. ADVANCED REDUCED SCALE FUEL SYSTEM SIMULATOR RESULTS | 119 |
| 8. CONCLUSIONS | 123 |
| REFERENCES | 125 |

LIST OF FIGURES

1. Extended Duration Thermal Stability Test (EDTST) schematic.109
2. Advanced Reduced Scale Fuel System Simulator (ARSFSS) schematic.119

LIST OF TABLES

| | |
|---|-----|
| 1. List of QCM Experiments | 5 |
| 2. List of ICOT Experiments | 49 |
| 3. Phoenix Rig Test Name Code..... | 71 |
| 4. Phoenix Rig Deposition Tests..... | 73 |
| 5. Phoenix Rig Oxygen Consumption Tests | 79 |
| 6. Fuel/Material Test Result Summary Table..... | 87 |
| 7. Selected Fuel/Material Data | 97 |
| 8. Fuel/Material Screening Test Results..... | 105 |
| 9. Summary of EDTST Runs..... | 111 |
| 10. Summary of ARSFSS Runs..... | 121 |

PREFACE

This final report was submitted by the University of Dayton Research Institute (UDRI) under Contract No. F33615-92-C-2207, sponsored by the U.S. Air Force Research Laboratory, Propulsion Directorate, Wright-Patterson AFB, OH. Mr. Charles Frayne of AFRL/PRSC was the Contract Monitor and Dr. D.R. Ballal of the Aerospace Mechanics Division, UDRI was the Principal Investigator. This report covers work performed during the period June 8, 1992 through December 31, 1997.

The authors would like to acknowledge the support and encouragement of Dr. Mel Roquemore and Mr. Bill Harrison of the U.S. Air Force.

1. INTRODUCTION AND SUMMARY

This report consists of data set summaries of tests performed in support of the development of advanced jet fuels, including JP-8+100, JP-900, and endothermic fuels. This includes data sets for the quartz crystal microbalance (QCM), the isothermal corrosion oxidation test (ICOT), the Phoenix rig, the fuel/materials compatibility studies, the extended duration thermal stability test (EDTST), and the advanced reduced scale fuel system simulator (ARSFSS). These data sets, and/or more complete versions of them, may also be available in electronic format on the internet at <https://posfbbs.appl.wpafb.af.mil/> or directly from the authors.

For the development of JP-8+100 fuel, we have tested hundreds of additives in both small and large scale test devices. We formulated combinations of the best additives (detergent/dispersant, hindered phenol antioxidant, and metal deactivator) and demonstrated their efficacy in reducing deposition in realistic aircraft conditions in large-scale simulator rigs. We optimized the concentrations of these additives for maximum effectiveness and minimum cost. We performed extensive studies of the compatibility of these fuel additives with current and future aircraft fuel system materials. We determined that the current best additives show no negative effects on both metallic and non-metallic fuel system materials.

We also performed extensive studies on the fundamental processes of fuel oxidation, deposition, and pyrolysis. We developed chemical kinetic mechanisms which can simulate the oxidation and deposition processes. We performed experimental and modeling studies on fuel cooling which shows that deposition which occurs in fuel cooling heat exchangers can be a significant problem in fuel system design. We demonstrated an inverse relationship between oxidation and deposition over a range of fuels, and showed that our chemical kinetic mechanism can be used to explain this seemingly anomalous result. We developed statistical techniques to assist the evaluation of jet fuel additives, thermal stability measurements, and aircraft field performance. We developed a wide variety of fuels analysis techniques for measurement of the following: dissolved oxygen, detergent/dispersant capacity, antioxidants and phenolics, hydroperoxides, trace jet fuel compounds, metal deactivators, products of endothermic reforming, dissolved and free water in fuel, BHT, Betz dispersant, and elemental metals. We explored alternative techniques for reducing jet fuel deposition including: removal of dissolved oxygen, silylating agents, oxygen scavenging additives, and solid-phase extraction.

We also made progress in support of development of future fuels such as JP-900 and endothermic fuels. We explored the effect of supercritical fluid properties on high temperature fuels. We have begun to study the pyrolysis of fuel in catalytic and non-catalytic reaction systems.

The overall program accomplishments and details of the individual test devices employed during the contract period are contained in the accompanying volume entitled, "Combustion and Heat Transfer: Volume 1 – Advanced Jet Fuel Studies."

2. QUARTZ CRYSTAL MICROBALANCE DATA

The Quartz Crystal Microbalance (QCM) was developed and first used for the study of jet fuel thermal stability by Sandia National Labs (1). It enables the real-time, *in situ* measurement of extremely low amounts of deposits ($<100 \text{ ng/cm}^2$). We originally acquired a QCM system in 1993 from Sandia and made numerous additions and operating modifications. As a result of these changes the QCM system has been used extensively for evaluating additives and for fundamental studies of fuel oxidation and deposition (2). These modifications include the addition of a pressure transducer and oxygen sensor to enable the direct *in situ* monitoring of the oxidation process (3). For most testing we have chosen to operate the device under relatively low oxygen availability which more closely approximates that of real fuel systems (4).

During the contract period, we utilized the QCM system for over 1300 fuel tests encompassing additive testing and fundamental studies. Hundreds of JP-8+100 additive candidates were tested with the device. These test results are compiled in a series of UDR technical reports (5-7). The QCM was also used extensively for additive concentration optimization and additive package development (8). In fact, the current JP-8+100 dispersant-antioxidant-metal deactivator combination was first tested and proven successful in the QCM (4). The device has also been used extensively for testing of JP-8 and JP-8+100 fuel samples from the Air National Guard (ANG) field trials; these tests have confirmed that the JP-8+100 additive package has shown significant improvement in oxidation and deposition properties for fuels used in actual ANG aircraft.

Table 1 contains a chronological list of experiments performed in the QCM. The table lists the run number, the fuel number, additive names and concentrations, the temperature of the run, the gas used for saturating the fuel and headspace, the final deposition at the end of a 15 hour run, and the QCM electrode material. Fuel and additive numbers (POSF codes) are assigned by the Fuels Branch of the Fuels and Lubrication Division of Wright Laboratory (WL/POSF), WPAFB, OH. Runs were performed using three separate QCM devices; runs labeled ssz... and steve... were conducted on QCM system #1, runs labeled qcm... were conducted on QCM system #2, and runs labeled pz... were conducted on QCM system #3. Duplicate runs performed on the three systems yield results that are in substantial agreement. Deposition and oxidation plots for each of these runs can be obtained by referencing the appropriate technical report which details the chosen run (5-7). The plotted data are also available from the authors as a Filemaker Pro database file which is about 50 megabytes in size.

This page intentionally left blank.

Table 1. List of QCM Experiments

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| Steve01 | 2827 | 140 | Air | 5.1 | Au |
| Steve02 | 2747 | 140 | Air | 2.3 | Au |
| Steve03 | 2799 | 140 | Air | 1.7 | Au |
| Steve04 | 2799 | 140 | Air | 1.4 | Au |
| Steve05 | 2747 | 140 | Oxygen | 0.9 | Au |
| Steve06 | 2747 | 140 | Air | 0.4 | Au |
| Steve07 | 2747 | 140 | Oxygen | 1.1 | Au |
| Steve08 | 2747 | 140 | Air | 0.7 | Au |
| Steve09 | 2827 | 140 | Air | 2.6 | Au |
| Steve10 | 2827 | 160 | Air | 4.0 | Au |
| Steve11 | 2827 | 180 | Air | 1.8 | Au |
| Steve12 | 2827 | 150 | Air | 7.9 | Au |
| Steve13 | 2827 | 150 | Air | 6.7 | Au |
| Steve14 | 2827 | 150 | Air | 7.6 | Au |
| Steve15 | 2827 | 140 | Air | 4.0 | Au |
| Steve16 | 2827 | 150 | Air | 6.9 | Au |
| Steve17 | 2747 | 140 | Air | 0.6 | Au |
| Steve18 | 2747 | 160 | Air | 0.6 | Au |
| Steve19 | 2747 | 180 | Air | 0.8 | Au |
| Steve20 | 2747 | 140 | Air | 0.3 | Au |
| Steve21 | 2827 | 140 | Nitrogen | 0.2 | Au |
| Steve22 | 2827 after solid phase extraction | 140 | Air | 0.5 | Au |
| Steve23 | 2747 w/ 2827 solid phase extract | 140 | Air | 2.8 | Au |
| Steve24 | 2926 | 140 | Air | 5.0 | Au |
| Steve25 | 2827 | 140 | Air | 3.7 | Au |
| Steve26 | 2827 w/di-t-butyl peroxide | 140 | Air | 2.8 | Au |
| Steve27 | 2926 | 140 | Air | 2.9 | Au |
| Steve28 | 2922 | 140 | Air | 2.0 | Au |
| Steve29 | 2747 | 140 | Air | 0.7 | Au |
| Steve30 | 2827 w/ 2,2 azobis-2-methyl propionitrile 0.178 g/100 ml | 140 | Air | 7.5 | Au |
| Steve31 | 2827 | 140 | Air | 2.7 | Au |
| Steve32 | 2827 w/ 8Q405 100 mg/l and MCP-477 300 mg/l | 140 | Air | 0.5 | Au |
| Steve33 | 2799 | 140 | Air | 1.0 | Au |
| Steve34 | 2893 (JPTS w/o JFA-5) | 140 | Air | 0.6 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|--|------------------------|------------|--|---------------------------|
| Steve35 | n-dodecane | 140 | Air | 0.1 | Au |
| Steve36 | n-dodecane w/ 2827 solid phase extract | 140 | Air | 0.3 | Au |
| Steve37 | 2928 | 140 | Air | 3.2 | Au |
| Steve38 | 2959 | 140 | Air | 2.5 | Au |
| Steve39 | 2922 clay treated | 140 | Air | 0.4 | Au |
| Steve40 | 2934 | 140 | Air | 6.5 | Au |
| Steve41 | 2936 | 140 | Air | 6.9 | Au |
| Steve42 | 2827 w/ 8Q405 100 mg/l | 140 | Air | 0.7 | Au |
| Steve43 | 2827 w/ JFA-5 12 mg/l | 140 | Air | 5.7 | Au |
| Steve44 | 2827 w/ MDA 10 mg/l | 140 | Air | 1.7 | Au |
| Steve45 | 2934 | 140 | Air | 5.0 | Au |
| Steve46 | 2827 w/ Cu acetate monohydrate 50 ppb | 140 | Air | 3.4 | Au |
| Steve47 | 2922 w/ 8Q405 100 mg/l and MCP-477 300 mg/l | 140 | Air | 0.3 | Au |
| Steve48 | 2934 w/ 8Q405 100 mg/l and MCP-477 300 mg/l | 140 | Air | 0.5 | Au |
| Steve49 | 2936 w/ 8Q405 100 mg/l and MCP-477 300 mg/l | 140 | Air | 4.0 | Au |
| Steve50 | 2827 w/ Cu naphthenate 50 ppb | 140 | Air | 2.3 | Au |
| Steve51 | 2827 w/ JP-8 additives | 140 | Air | 2.5 | Au |
| Steve52 | 2747 w/ JP-8 additives | 140 | Air | 0.4 | Au |
| Steve53 | 2827 w/ JP-8 additives, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.6 | Au |
| Steve54 | 2928 w/ JFA-5 12 mg/l | 140 | Air | 10.2 | Au |
| Steve55 | 2928 w/ 8Q405 100 mg/l | 140 | Air | 2.7 | Au |
| Steve56 | 2934 w/ JFA-5 12 mg/l | 140 | Air | 5.1 | Au |
| Steve57 | 2922 w/ JFA-5 12 mg/l | 140 | Air | 3.7 | Au |
| Steve58 | 2936 w/ JFA-5 12 mg/l | 140 | Air | 5.5 | Au |
| Steve59 | 2827 w/ JFA-5 6 mg/l | 140 | Air | 4.5 | Au |
| Steve60 | 2827 w/ JFA-5 24 mg/l | 140 | Air | 6.4 | Au |
| Steve61 | 2827 w/ 8Q405 50 mg/l | 140 | Air | 0.6 | Au |
| Steve62 | 2827 w/ 8Q405 10 mg/l | 140 | Air | 3.3 | Au |
| Steve63 | 2926 w/ JP-8 additives (EGME) | 140 | Air | 2.1 | Au |
| Steve64 | 2926 | 140 | Air | 4.1 | Au |
| Steve65 | 2926 w/ JP-8 additives (DiEGME) | 140 | Air | 1.4 | Au |
| Steve66 | 2922 w/ 8Q405 10 mg/l | 140 | Air | 3.5 | Au |
| Steve67 | 2827 w/ 8Q405 25 mg/l | 140 | Air | 3.3 | Au |
| Steve68 | 2922 w/ 8Q405 100 mg/l | 140 | Air | 3.2 | Au |
| Steve69 | 2922 w/ 8Q405 50 mg/l | 140 | Air | 4.3 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| Steve70 | 2922 w/ 8Q405 50 mg/l and MCP-477 50 mg/l | 140 | Air | 1.6 | Au |
| Steve71 | 2922 w/ MCP-477 50 mg/l | 140 | Air | 5.1 | Au |
| Steve72 | 2922 | 140 | Air | 2.9 | Au |
| Steve73 | 2963 | 140 | Air | 6.1 | Au |
| Steve74 | 2963 w/ 8Q405 100 mg/l | 140 | Air | 3.8 | Au |
| Steve75 | 2922 w/ TBHQ 25 mg/l | 140 | Air | 3.2 | Au |
| Steve76 | 2922 w/ BHT 25 mg/l | 140 | Air | 4.0 | Au |
| Steve77 | 2922 w/ 2927 (phenylenediamine AO) 25 mg/l | 140 | Air | 5.6 | Au |
| Steve78 | 2922 w/ 2927 25 mg/l and 8Q405 100 mg/l | 140 | Air | 2.5 | Au |
| Steve79 | 2922 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.2 | Au |
| Steve80 | 2936 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 5.4 | Au |
| Steve81 | 2926 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.6 | Au |
| Steve82 | 2827 w/ BHT 25mg/l and 8Q405 100 mg/l | 140 | Air | 0.9 | Au |
| Steve83 | 2934 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 3.7 | Au |
| Steve84 | 2963 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 2.6 | Au |
| Steve85 | 2827 w/ JFA-5 200 mg/l | 140 | Air | 8.0 | Au |
| Steve86 | 2980 | 140 | Air | 7.4 | Au |
| Steve87 | 2980 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.6 | Au |
| qcm0001 | 2827 | 140 | Air | 8.4 | Au |
| Steve88 | 2981 | 140 | Air | 9.2 | Au |
| qcm0002 | 2934 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 5.0 | Au |
| qcm0003 | 2980 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.8 | Au |
| Steve89 | 2981 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.5 | Au |
| qcm0004 | 2827 w/ JFA-5 12 mg/l | 140 | Air | 7.9 | Au |
| qcm0005 | 2827 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.5 | Au |
| Steve90 | 2827 w/ JFA-5 12 mg/l | 140 | Air | 4.3 | Au |
| Steve91 | 2922 w/ MCP-477 50 mg/l | 140 | Air | 3.0 | Au |
| qcm0006 | 2922 w/ 8Q405 50 mg/l | 140 | Air | 3.0 | Au |
| Steve92 | 2936 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.8 | Au |
| Steve93 | 2827 w/ 7R30 100 mg/l | 140 | Air | 6.2 | Au |
| qcm0007 | 2936 w/ 7R30 100 mg/l | 140 | Air | 8.9 | Au |
| Steve 94 | 2747 | 140 | Air | 1.0 | Au |
| qcm0008 | 2934 w/ 7R30 100mg/l | 140 | Air | 9.8 | Au |
| Steve 95 | 2747 w/ BHT 25mg/l, 8Q405 100mg/l, MCP-477 300mg/l | 140 | Air | 0.2 | Au |
| qcm0009 | 2827 w/ JP-8 add, 8Q405 100mg/l, MCP-477 300mg/l | 140 | Air | 0.4 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|------------|--|---------------------------|
| Steve 96 | 2827 w/ 8Q405 (New) 100mg/l | 140 | Air | 0.9 | Au |
| qcm0010 | 2827 w/ JP-8 additives | 140 | Air | 3.5 | Au |
| Steve 97 | 2827 w/ JP-8 add, 8Q405 100mg/l | 140 | Air | 0.4 | Au |
| Steve 98 | 2963 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.6 | Au |
| Steve 99 | 2964 (Preproduction JP-7) | 140 | Air | 0.9 | Au |
| qcm0011 | 2926 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 0.8 | Au |
| qcm0012 | 2980 w/ JP-8 additives | 140 | Air | 6.6 | Au |
| ssz100 | 2922 w/ JP-8 additives | 140 | Air | 1.5 | Au |
| ssz101 | 2893 (JPTS w/o JFA-5) w/ AO from JFA-5 | 140 | Air | 1.7 | Au |
| ssz102 | 2934 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 1.7 | Au |
| ssz103 | 2985 | 140 | Air | 10.1 | Au |
| ssz104 | 2934 w/ 8Q405 400 mg/l and BHT 25mg/l | 140 | Air | 9.2 | Au |
| qcm0014 | 2936 w/ 8Q405 400 mg/l and BHT 25 mg/l | 140 | Air | 3.0 | Au |
| ssz105 | 2963 w/ 8Q405 400 mg/l and BHT 25 mg/l | 140 | Air | 0.4 | Au |
| qcm0015 | 2985 w/ 8Q405 100 mg/l | 140 | Air | 6.9 | Au |
| ssz106 | 2985 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 140 | Air | 2.0 | Au |
| ssz107 | 2893 w/ MDA 2 mg/l | 140 | Air | 1.1 | Au |
| qcm0016 | 2985 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 4.5 | Au |
| ssz108 | 2985 w/ JFA-5 12 mg/l | 140 | Air | 10.6 | Au |
| ssz109 | 2827 w/ 2957 0.006% by volume | 140 | Air | 8.1 | Au |
| qcm0017 | 2827 w/ 2958 0.019% by weight | 140 | Air | 2.6 | Au |
| ssz110 | 2893 w/ FOA-2 5 mg/l | 140 | Air | 0.3 | Au |
| ssz111 | 2827 w/ MCP-1411 300 mg/l | 140 | Air | 1.3 | Au |
| qcm0018 | 2827 w/ MCP-1020 300 mg/l | 140 | Air | 1.1 | Au |
| ssz112 | 2827 w/ MCP-1025 300 mg/l | 140 | Air | 0.8 | Au |
| qcm0019 | 2827 w/ MCP-147B 300 mg/l | 140 | Air | 0.8 | Au |
| ssz113 | 2827 w/ MCP-1408B 300 mg/l | 140 | Air | | Au |
| qcm0020 | 2827 w/ MCP-1411 300 mg/l | 140 | Air | 1.3 | Au |
| ssz114 | 2980 w/ JFA-5 12 mg/l | 140 | Air | 7.4 | Au |
| qcm0021 | 2922 w/ JFA-5 12 mg/l | 140 | Air | 3.2 | Au |
| ssz115 | 2980 w/ 8Q405 100 mg/l | 140 | Air | 0.1 | Au |
| ssz116 | 2980 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.2 | Au |
| qcm0022 | 2926 w/ 8Q405 100 mg/l | 140 | Air | 6.4 | Au |
| ssz117 | 2922 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives | 140 | Air | 0.3 | Au |
| qcm0023 | 2926 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives | 140 | Air | 1.0 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| ssz118 | 2980 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives | 140 | Air | 0.4 | Au |
| qcm0024 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives | 140 | Air | 0.8 | Au |
| ssz119 | 2747 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives | 140 | Air | 0.2 | Au |
| ssz120 | 2922 w/ MCP-1025 300 mg/l | 140 | Air | 0.5 | Au |
| qcm0025 | 2922 w/ MCP-147B 300 mg/l | 140 | Air | 0.3 | Au |
| ssz121 | 2976 (JPTS) | 140 | Air | 0.7 | Au |
| qcm0026 | 2922 w/ BHT 10 mg/l | 140 | Air | 4.2 | Au |
| ssz122 | 2922 w/ BHT 50 mg/l | 140 | Air | 1.7 | Au |
| qcm0027 | 2922 w/ BHT 100 mg/l | 140 | Air | 4.9 | Au |
| ssz123 | 2980 w/ MCP-147B 300 mg/l | 140 | Air | 0.9 | Au |
| qcm0028 | 2922 w/ BHT 50 mg/l | 140 | Air | 4.7 | Au |
| qcm0029 | 2980 w/ MCP-1025 300 mg/l | 140 | Air | 1.7 | Au |
| ssz124 | 2926 w/ 8Q405 100 mg/l and MCP-147B 300 mg/l | 140 | Air | 0.2 | Au |
| ssz125 | 2922 w/ 8Q405 100 mg/l and MCP-147B 300 mg/l | 140 | Air | 0.2 | Au |
| qcm0030 | 2926 w/ 8Q405 100 mg/l | 140 | Air | 2.8 | Au |
| ssz126 | 2799 (JPTS- failed JFTOT) | 140 | Air | 0.7 | Au |
| qcm0031 | 2980 w/ Exxon #12 25 mg/l | 140 | Air | 4.7 | Au |
| ssz127 | 2980 w/ Exxon #12 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.7 | Au |
| qcm0032 | 2922 w/ Exxon #12 25 mg/l and 8Q405 100 mg/l | 140 | Air | 1.1 | Au |
| ssz128 | 2926 w/ Exxon #12 25 mg/l and 8Q405 100 mg/l | 140 | Air | 2.0 | Au |
| qcm0033 | 2827 w/ Exxon #12 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.6 | Au |
| ssz129 | 2922 w/ Exxon #12 25 mg/l | 140 | Air | 2.7 | Au |
| qcm0034 | 2980 | 140 | Air | 5.0 | Au |
| ssz130 | 2985 w/ MCP-147B 300 mg/l | 140 | Air | 2.0 | Au |
| ssz131 | 2985 w/ MCP-1025 300 mg/l | 140 | Air | 4.0 | Au |
| qcm0035 | 2922 w/ BHT 25 mg/l and MCP-147B 300 mg/l | 140 | Air | 0.1 | Au |
| ssz132 | 2926 w/ BHT 25 mg/l and MCP-147B 300 mg/l | 140 | Air | 1.4 | Au |
| qcm0036 | 2980 w/ BHT 25 mg/l and MCP-147B 300 mg/l | 140 | Air | 0.5 | Au |
| ssz133 | 2985 | 140 | Nitrogen | 0.6 | Au |
| qcm0037 | 2926 w/ JFA-5 12 mg/l | 140 | Air | 6.0 | Au |
| ssz134 | 2922 w/ MCP-1408C 25 mg/l | 140 | Air | 1.4 | Au |
| ssz135 | 2922 w/ MCP-476 25 mg/l | 140 | Air | 1.8 | Au |
| qcm0038 | 2922 w/ MCP-1408 25 mg/l | 140 | Air | 1.7 | Au |
| ssz136 | 2827 (old can) | 140 | Air | 6.8 | Au |
| ssz137 | 2827 w/ MCP-873 300 mg/l | 140 | Air | 1.5 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------------------------------|--|-------------------------------|
| qcm0039 | 2827 | 140 | Air | | Au |
| qcm0040 | 2827 w/ MCP-1413B | 140 | Air | 1.8 | Au |
| ssz138 | 2827 | 140 | Air | 3.6 | Au |
| qcm0041 | 2827 | 140 | Air | 4.4 | Au |
| ssz139 | 2827 | 140 | Air 20 psi (Heat-up with Nitrogen) | 5.7 | Au |
| ssz140 | 2827 | 140 | Air 20 psi (Heat-up with Nitrogen) | 5.7 | Au |
| qcm0042 | 2926 | 140 | Air | 4.1 | Au |
| ssz141 | 2827 | 160 | Air 20 psi (Heat-up with Nitrogen) | 8.2 | Au |
| qcm0043 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.4 | Au |
| ssz142 | 2827 | 180 | Air 20 psi (Heat-up with Nitrogen) | 3.0 | Au |
| qcm0044 | 2827 w/ 3F33 100 mg/l | 140 | Air | 5.5 | Au |
| ssz143 | 2827 | 170 | Air 20 psi (Heat-up with Nitrogen) | 6.3 | Au |
| qcm0045 | 2827 w/ MCP-1413 | 140 | Air | 0.8 | Au |
| ssz144 | 2827 w/ 8Q405 100 mg/l | 140 | Air | 1.4 | Au |
| qcm0046 | 2827 w/ Inhibitor A 100 mg/l | 140 | Air | 3.3 | Au |
| ssz145 | 2980 w/ MCP-1413 300 mg/l | 140 | Air | 3.7 | Au |
| qcm0047 | 2926 w/ MCP-1413 300 mg/l | 140 | Air | 3.2 | Au |
| ssz146 | 2827 w/ PL-1601 25 mg/l | 140 | Air | 5.8 | Au |
| qcm0048 | 2827 w/ PL-1602 25 mg/l | 140 | Air | 12.1 | Au |
| ssz147 | 2827 w/ PL-1517 25 mg/l | 140 | Air | 12.3 | Au |
| qcm0049 | 2827 w/ PL-1610 25 mg/l | 140 | Air | 5.5 | Au |
| ssz148 | 2980 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.1 | Au |
| ssz149 | 2936 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.4 | Au |
| ssz150 | 2926 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.5 | Au |
| qcm0051 | 2928 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 2.7 | Au |
| ssz151 | 2963 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.7 | Au |
| qcm0052 | 2959 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Au |
| qcm0053 | 2922 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.4 | Au |
| ssz152 | 2934 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 4.5 | Au |
| qcm0054 | 2985 w/ 8Q405 100 mg/l, BHT, 25 mg/l, and MDA 10 mg/l | 140 | Air | 10.1 | Au |
| ssz153 | 2827 w/ PL-1606 50 mg/l | 140 | Air | 2.6 | Au |
| qcm0055 | 2827 w/ PL-1607 50 mg/l | 140 | Air | 2.9 | Au |
| ssz154 | 2922 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.4 | Au |
| qcm0056 | 2926 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 1.0 | Au |
| ssz155 | 2934 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------------------------------|--|-------------------------------|
| qcm0057 | 2936 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.3 | Au |
| ssz156 | 2980 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.9 | Au |
| qcm0058 | 2985 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 2.0 | Au |
| ssz157 | 2827 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.8 | Au |
| ssz158 | 2963 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 1.0 | Au |
| qcm0059 | 2928 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 3.3 | Au |
| ssz159 | 2959 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.2 | Au |
| ssz160 | 2827 w/ PL-1700 15 mg/l | 140 | Air | 4.1 | Au |
| qcm0060 | 2827 w/ 8Q400 10 mg/l | 140 | Air | 6.7 | Au |
| ssz161 | 2827 w/ PL-1642 50 mg/l | 140 | Air | 1.9 | Au |
| ssz162 | 2922 | 140 | Air 10 psi (Heat-up with Nitrogen) | 0.6 | Au |
| qcm0061 | 2926 w/ BHT 25 mg/l, MCP-147B 100 mg/l, and MDA 10 mg/l | 140 | Air | 1.1 | Au |
| ssz163 | 2922 | 150 | Air 10 psi (Heat-up with Nitrogen) | 0.6 | Au |
| qcm0062 | 2827 w/ BHT 25 mg/l, MCP-147B 100 mg/l, and MDA 10 mg/l | 140 | Air | 1.1 | Au |
| ssz164 | 2922 | 160 | Air 10 psi (Heat-up with Nitrogen) | 0.7 | Au |
| qcm0063 | 2959 w/ BHT 25 mg/l, MCP-147B 100 mg/l, and MDA 10 mg/l | 140 | Air | 0.5 | Au |
| ssz165 | 2922 | 140 | Air 10 psi (Heat-up with Nitrogen) | 0.6 | Au |
| ssz166 | 2827 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MCP-477 300 mg/l | 180 | Air 20 psi (Heat-up with Nitrogen) | 2.8 | Au |
| qcm0064 | 2922 w/ Exxon #4 25 mg/l | 140 | Air | 5.8 | Au |
| ssz167 | 2827 w/ 8Q405 100 mg/l | 180 | Air 20 psi (Heat-up with Nitrogen) | 4.1 | Au |
| qcm0065 | 2922 w/ Exxon #8 25 mg/l | 140 | Air | 6.7 | Au |
| ssz168 | 2926 | 180 | Air 20 psi (Heat-up with Nitrogen) | 2.8 | Au |
| qcm0066 | 2922 w/ Exxon #6 25 mg/l | 140 | Air | 4.2 | Au |
| qcm0067 | 2922 w/ Exxon #1 25 mg/l | 140 | Air | 2.8 | Au |
| ssz169 | 2922 | 140 | Air 20 psi (Heat-up with Nitrogen) | 2.0 | Au |
| qcm0068 | 2922 w/ Exxon #11 25 mg/l | 140 | Air | 1.5 | Au |
| qcm0069 | 2922 w/ Exxon #13 25 mg/l | 140 | Air | 1.4 | Au |
| ssz170 | 2922 w/ Exxon #2 25 mg/l | 140 | Air | 2.0 | Au |
| ssz171 | 2922 w/ Exxon #5 25 mg/l | 140 | Air | 3.3 | Au |
| qcm0070 | 2922 w/ Exxon #10 25 mg/l | 140 | Air | 4.0 | Au |
| ssz172 | 2922 w/ Exxon #5 25 mg/l | 140 | Air | 3.1 | Au |
| qcm0071 | 2922 w/ Exxon #7 25 mg/l | 140 | Air | 3.3 | Au |
| ssz173 | 2827 w/ Exxon #14 100 mg/l | 140 | Air | 7.0 | Au |
| qcm0072 | 2827 w/ Exxon #15 100 mg/l | 140 | Air | 3.7 | Au |
| ssz174 | 2827 w/ Exxon #16 100 mg/l | 140 | Air | 9.4 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------------------------------|--|-------------------------------|
| qcm0073 | 2827 w/ Exxon #17 100 mg/l | 140 | Air | 4.4 | Au |
| ssz175 | 2980 | 140 | Air 10 psi (Heat-up with Nitrogen) | 2.8 | Au |
| qcm0074 | 2827 | 140 | Air | 5.7 | Au |
| ssz176 | 2980 | 140 | Air 20 psi (Heat-up with Nitrogen) | 8.8 | Au |
| qcm0075 | 2980 | 140 | Nitrogen | 0.3 | Au |
| ssz177 | 2980 | 140 | Air 5 psi (Heat-up with Nitrogen) | 1.3 | Au |
| qcm0076 | 2827 | 140 | Air | 5.0 | Au |
| ssz178 | 2980 | 140 | Air 30 psi (Heat-up with Nitrogen) | 12.0 | Au |
| qcm0077 | 2827 w/ 8Q405 100 mg/l | 140 | Air | 0.6 | Au |
| ssz179 | 2980 | 140 | Air 15 psi (Heat-up with Nitrogen) | 6.6 | Au |
| qcm0078 | 2827 w/ 8Q405 100 mg/l | 160 | Air 20 psi (Heat-up with Nitrogen) | 10.5 | Au |
| ssz180 | 2827 | 140 | Air 5 psi (Heat-up with Nitrogen) | 3.7 | Au |
| qcm0079 | 2827 | 140 | Air 10 psi (Heat-up with Nitrogen) | 2.6 | Au |
| ssz181 | 3012 | 140 | Air | 9.3 | Au |
| ssz182 | 2827 w/ Exxon #11 25 mg/l and Exxon #15 100 mg/l | 140 | Air | 1.6 | Au |
| qcm0080 | 2922 w/ Exxon #11 25 mg/l and Exxon #15 100 mg/l | 140 | Air | 2.3 | Au |
| qcm0081 | 2922 w/ Exxon #11 25 mg/l and Exxon #17 100 mg/l | 140 | Air | 2.4 | Au |
| ssz183 | 2827 w/ Exxon #11 25 mg/l and Exxon #17 100 mg/l | 140 | Air | 1.5 | Au |
| ssz184 | 3012 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 5.9 | Au |
| qcm0082 | 2922 w/ Exxon #11 25 mg/l and 8Q405 100 mg/l | 140 | Air | 1.9 | Au |
| ssz185 | 2963 w/ 8Q405 100 mg/l and MDA 20 mg/l | 140 | Air | 1.2 | Au |
| ssz186 | 3012 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 2.1 | Au |
| qcm0083 | 3012 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MDA 10 mg/l | 140 | Air | 5.9 | Au |
| ssz187 | 3012 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 2.4 | Au |
| ssz188 | 2980 | 140 | Air 15 psi (Heat-up with Nitrogen) | 3.5 | Au |
| qcm0084 | 2980 | 160 | Air 15 psi (Heat-up with Nitrogen) | 3.0 | Au |
| ssz189 | 2980 | 180 | Air 15 psi (Heat-up with Nitrogen) | 2.7 | Au |
| qcm0085 | 2980 | 150 | Air 15 psi (Heat-up with Nitrogen) | 4.4 | Au |
| ssz190 | 3013 | 140 | Air | 3.0 | Au |
| qcm0086 | 3014 | 140 | Air | 1.6 | Au |
| ssz191 | 3016 | 140 | Air | 1.1 | Au |
| qcm0087 | 3017 | 140 | Air | 2.6 | Au |
| ssz192 | 3013 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 2.9 | Au |
| qcm0088 | 3014 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.5 | Au |
| ssz193 | 3013 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 0.6 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|------------|--|---------------------------|
| qcm0089 | 3014 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 0.9 | Au |
| ssz194 | 3016 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 1.0 | Au |
| qcm0090 | 3017 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 1.0 | Au |
| ssz195 | 3013 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.7 | Au |
| qcm0091 | 3014 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.2 | Au |
| ssz196 | 3016 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 1.7 | Au |
| qcm0092 | 3017 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 1.5 | Au |
| ssz197 | 2827 w/ Isopar V (50/50) | 140 | Air | 8.5 | Au |
| ssz198 | 2827 w/ Exxsol D80 (50/50) | 140 | Air | 1.4 | Au |
| qcm0093 | 2827 w/ Exxsol D80 (10/90) | 140 | Air | 0.7 | Au |
| ssz199 | Exxsol D80 | 140 | Air | 0.5 | Au |
| qcm0094 | 2827 w/ Exxsol D80 (1/60) | 140 | Air | 0.4 | Au |
| ssz200 | 2827 w/ POSF-3022 100 mg/l | 140 | Air | 2.1 | Au |
| ssz201 | 2922 w/ POSF-3023 100 mg/l and 8Q405 100 mg/l | 140 | Air | 0.3 | Au |
| ssz202 | 2827 w/ POSF-3022 200 mg/l | 140 | Air | 0.7 | Au |
| qcm0096 | 3011 | 140 | Air | 8.3 | Au |
| ssz203 | 2827 (2 ml) and Exxsol D-80 (59 ml) | 140 | Air | 0.3 | Au |
| qcm0097 | 3011 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 8.3 | Au |
| ssz204 | 2827 (4 ml) and Exxsol D-80 (55 ml) | 140 | Air | 0.9 | Au |
| qcm0098 | 3011 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 2.7 | Au |
| ssz205 | 2827 (6 ml) and Exxsol D-80 (55 ml) | 140 | Air | 0.8 | Au |
| qcm0099 | 2827 (8 ml) and Exxsol D-80 (52 ml) | 140 | Air | 0.7 | Au |
| ssz206 | 2985 w/ 8Q405 100 mg/l and Additive D 100 mg/l | 140 | Air | 2.6 | Au |
| qcm100 | 3011 w/ BHT 25 mg/l, 8Q405 100 mg/l, and MDA 10 mg/l | 140 | Air | 1.0 | Au |
| ssz207 | 2827 w/ 8Q405 200 mg/l | 140 | Air | 2.8 | Au |
| qcm101 | 2827 w/ 8Q405 400 mg/l | 140 | Air | 0.4 | Au |
| ssz208 | 2827 w/ 8Q405 400 mg/l (BAD) | 140 | Air | 0.4 | Au |
| qcm102 | 2926 w/ 8Q405 25 mg/l | 140 | Air | 6.6 | Au |
| ssz209 | 2827 w/ 8Q405 200 mg/l | 140 | Air | 1.0 | Au |
| qcm103 | 2926 w/ 8Q405 400 mg/l | 140 | Air | 0.3 | Au |
| ssz210 | 3034 | 140 | Air | 3.5 | Au |
| qcm104 | 3035 | 140 | Air | 3.3 | Au |
| ssz211 | 2827 w/ MCP-759 300 mg/l | 140 | Air | 1.9 | Au |
| qcm105 | 2827 w/ MCP-867 300 mg/l | 140 | Air | 2.0 | Au |
| ssz212 | 2827 w/ MCP-753 300 mg/l | 140 | Air | 3.1 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|------------|--|---------------------------|
| qcm106 | 2827 w/ MCP-880 300 mg/l | 140 | Air | 2.0 | Au |
| ssz213 | 2827 w/ MCP-750 300 mg/l | 140 | Air | 5.7 | Au |
| qcm107 | 2827 w/ MCP-902 300 mg/l | 140 | Air | 2.9 | Au |
| ssz214 | 2827 w/ MCP-758 300 mg/l | 140 | Air | 2.7 | Au |
| qcm108 | 2827 w/ MCP-1395 300 mg/l | 140 | Air | 0.4 | Au |
| ssz215 | 2827 w/ Ferrox 530 160 mg/l | 140 | Air | 5.4 | Au |
| qcm109 | 2827 w/ MCP-751 300 mg/l | 140 | Air | 13.3 | Au |
| ssz216 | 2926 w/ 8Q405 50 mg/l | 140 | Air | 3.8 | Au |
| qcm110 | 2926 w/ 8Q405 200 mg/l | 140 | Air | 0.8 | Au |
| qcm111 | 2926 w/ 8Q405 100 mg/l and 3F29 15 mg/l | 140 | Air | 2.5 | Au |
| ssz217 | 2926 w/ 8Q405 100 mg/l and 3F29 30 mg/l | 140 | Air | 2.2 | Au |
| ssz218 | 2926 w/ 8Q405 100 mg/l and 3F29 60 mg/l | 140 | Air | 1.1 | Au |
| qcm113 | 2926 w/ 8Q405 100 mg/l and 327S9D 30 mg/l | 140 | Air | 4.0 | Au |
| ssz219 | 2926 w/ 8Q405 100 mg/l and 327S9D 15 mg/l | 140 | Air | 4.6 | Au |
| qcm114 | 2926 w/ 8Q405 100 mg/l and 327S9D 60 mg/l | 140 | Air | 7.8 | Au |
| ssz220 | 2922 w/ BHT 25 mg/l and MCP-1395 300 mg/l | 140 | Air | 0.2 | Au |
| qcm115 | 2926 w/ BHT 25 mg/l and MCP-1395 300 mg/l | 140 | Air | 1.5 | Au |
| qcm116 | 3034 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 1.8 | Au |
| ssz221 | 2985 w/ BHT 25 mg/l and MCP-1395 300 mg/l | 140 | Air | 3.4 | Au |
| ssz222 | 2926 w/ BHT 50 mg/l and 8Q405 100 mg/l | 140 | Air | 4.4 | Au |
| qcm117 | 2827 from EDTST | 140 | Air | 3.5 | Au |
| ssz223 | 2926 w/ BHT 15 mg/l and 8Q405 100 mg/l | 140 | Air | 1.2 | Au |
| qcm118 | 2980 from RSFSS flight idle recirc | 140 | Air | 9.6 | Au |
| qcm119 | 2827 w/ SDAD-722-2 | 140 | Air | 1.5 | Au |
| qcm120 | 2827 w/ SDAD-722-4 | 140 | Air | 6.1 | Au |
| ssz224 | 2827 w/ SDAD-722-1 | 140 | Air | 3.5 | Au |
| ssz225 | 2980 w/ BHT 25 mg/l, MCP-147B 300 mg/l, and MDA 10 mg/l | 140 | Air | 0.1 | Au |
| ssz226 | 2926 w/ 8Q405 100 mg/l and Inhibitor A 30 mg/l | 140 | Air | 1.4 | Au |
| qcm121 | 3056 | 140 | Air | 2.3 | Au |
| ssz227 | 3056 w/ BHT 25 mg/l and MCP-147B 300 mg/l | 140 | Air | 0.6 | Au |
| qcm122 | 3056 w/ BHT 25 mg/l and 8Q405 100 mg/l | 140 | Air | 0.4 | Au |
| ssz228 | 2926 w/ 8Q405 100 mg/l and Inhibitor A 7.5 mg/l | 140 | Air | 4.1 | Au |
| qcm123 | 2926 w/ 8Q405 100 mg/l and Inhibitor A 15 mg/l | 140 | Air | 1.4 | Au |
| ssz229 | 2827 w/ MCP-147B 300 mg/l | 140 | Air | 0.6 | Au |
| qcm124 | 2827 w/ MCP-147B 150 mg/l | 140 | Air | 1.1 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| ssz230 | 2827 w/ MCP-147B 75 mg/l | 140 | Air | 2.5 | Au |
| qcm125 | 2827 w/ MCP-147B 30 mg/l | 140 | Air | 4.7 | Au |
| ssz231 | 2926 w/ MCP-147B 150 mg/l | 140 | Air | 1.6 | Au |
| qcm126 | 2926 w/ MCP-147B 75 mg/l | 140 | Air | 3.0 | Au |
| ssz232 | 3056 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.2 | Au |
| qcm127 | 3056 w/ MCP-147B 300 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Au |
| ssz233 | 2827 H ₂ O/KOH extracted | 140 | Air | 5.3 | Au |
| ssz234 | 2926 w/ MCP-147B 300 mg/l | 140 | Air | 0.6 | Au |
| ssz235 | 2827 w/ 3275059B 100 mg/l | 140 | Air | 8.1 | Au |
| qcm128 | 2926 w/ MCP-147B 30 mg/l | 140 | Air | 3.9 | Au |
| ssz236 | 2827 w/ 3275059C 100 mg/l | 140 | Air | 4.1 | Au |
| qcm129 | 2980 w/ 8Q405 10000 mg/l, BHT 2500 mg/l, and MDA 100 mg/l | 140 | Air | 0.3 | Au |
| ssz237 | 2990 | 140 | Air | 8.3 | Au |
| qcm130 | 2991 | 140 | Air | 0.7 | Au |
| ssz238 | 2926 w/ MCP-147B 600 mg/l | 140 | Air | 0.6 | Au |
| qcm131 | 2827 w/ MCP-147B 600 mg/l | 140 | Air | 1.0 | Au |
| ssz239 | 2827 w/ SDA-722-3 | 140 | Air | 1.3 | Au |
| ssz240 | 2990 | 140 | Air | 11.5 | Au |
| qcm132 | 2991 | 140 | Air | 7.3 | Au |
| ssz241 | 2926 w/ MCP-147B 150 mg/l and BHT 50 mg/l | 140 | Air | 1.5 | Au |
| qcm133 | 2926 w/ MCP-147B 150 mg/l and BHT 25 mg/l | 140 | Air | 1.6 | Au |
| ssz242 | 2992 | 140 | Air | 1.9 | Au |
| qcm134 | 2926 w/ MCP-147B 150 mg/l and BHT 15 mg/l | 140 | Air | 1.3 | Au |
| ssz243 | 2990 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 5.4 | Au |
| qcm135 | 2991 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 6.9 | Au |
| ssz244 | 2993 | 140 | Air | 5.2 | Au |
| qcm136 | 2926 w/ MCP-147B 150 mg/l and BHT 100 mg/l | 140 | Air | 1.7 | Au |
| ssz245 | 2827 (dirty crystal) | 140 | Air | 4.0 | Au |
| qcm137 | 2827 | 140 | Air | 6.6 | Au |
| ssz246 | 2827 | 140 | Air | 17.9 | Ag |
| ssz247 | 2827 (Al crystal) | 140 | Air | 3.7 | Al |
| qcm138 | 2827 | 140 | Air | 3.8 | Pt |
| ssz248 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Al |
| ssz249 | 2827 w/ MCP-147B 300 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.7 | Al |
| ssz250 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 3.5 | Pt |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|------------------------------------|--|---------------------------|
| qcm140 | 2827 w/ MCP-147B 300 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.8 | Pt |
| ssz251 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Nitrogen | 26.2 | Ag |
| qcm141 | 2827 | 140 | Helium | 30.2 | Ag |
| ssz252 | 2747 | 140 | Nitrogen | 1.1 | Ag |
| qcm142 | 2747 | 140 | Air | 3.1 | Pt |
| ssz253 | 2922 | 140 | Nitrogen | 0.6 | Ag |
| qcm143 | 2747 | 140 | Air | 0.5 | Al |
| ssz254 | 2980 | 140 | Nitrogen | 0.8 | Ag |
| ssz255 | 2994 | 140 | Air | 5.5 | Au |
| qcm145 | 2999 | 140 | Air | 4.4 | Au |
| ssz256 | 2995 | 140 | Air | 1.4 | Au |
| qcm146 | 3001 | 140 | Air | 2.7 | Au |
| ssz257 | 3000 | 140 | Air | 5.7 | Au |
| qcm147 | 3002 | 140 | Air | 8.8 | Au |
| ssz258 | 2827 w/ 3057 (Texaco) 442 mg/l | 140 | Air | 0.7 | Au |
| qcm148 | 2827 w/ 3058 (Texaco) 174 mg/l | 140 | Air | 4.8 | Au |
| ssz259 | 3020 | 140 | Air | 1.1 | Au |
| qcm149 | 3019 | 140 | Air | 2.1 | Au |
| ssz260 | 3030 | 140 | Air | 4.0 | Au |
| qcm150 | 3059 | 140 | Air | 4.5 | Au |
| ssz261 | 3060 | 140 | Air | 2.6 | Au |
| qcm151 | 3036 | 140 | Air | 2.3 | Au |
| ssz262 | 3061 | 140 | Air | 4.0 | Au |
| qcm152 | 3062 | 140 | Air | 4.8 | Au |
| ssz263 | 3047 | 140 | Air | 2.2 | Au |
| qcm153 | 3031 | 140 | Air | 5.7 | Au |
| ssz264 | 3029 | 140 | Air | 4.8 | Au |
| qcm154 | 3049 | 140 | Air | 7.3 | Au |
| ssz265 | 3047 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.6 | Au |
| qcm155 | 3049 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 4.6 | Au |
| ssz266 | 3030 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 2.6 | Au |
| qcm156 | 3036 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 1.2 | Au |
| ssz267 | 3019 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 5.7 | Au |
| qcm157 | 3059 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 6.5 | Au |
| ssz268 | 3019 | 140 | Air 15 psi (Heat-up with Nitrogen) | 2.9 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| qcm158 | 3029 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 5.5 | Au |
| ssz269 | 2990 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 2.8 | Au |
| qcm159 | 2991 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 3.7 | Au |
| ssz270 | 2827 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 1.5 | Au |
| qcm160 | 2999 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.9 | Au |
| ssz271 | 2980 w/ 8Q405 100 mg/l (Old Additive) | 140 | Air | 2.2 | Au |
| qcm161 | 2980 w/ 8Q405 100 mg/l (New Additive) | 140 | Air | 7.3 | Au |
| ssz273 | 2827 | 140 | Air | 6.7 | Au |
| qcm163 | 2827 w/ 8Q405 100 mg/l (new, new) | 140 | Air | 3.1 | Au |
| ssz274 | 2827 w/ 8Q405 100 mg/l (new) | 140 | Air | 2.8 | Au |
| ssz275 | 2827 (from drum) | 140 | Air | 3.2 | Au |
| qcm164 | 2827 (from 5 gal can) | 140 | Air | 4.8 | Au |
| ssz276 | 2827 (from drum) w/ 8Q405 100 mg/l (new) | 140 | Air | 2.4 | Au |
| qcm165 | 2827 (from 5 gal can) w/ 8Q405 100 mg/l (new) | 140 | Air | 2.7 | Au |
| ssz277 | 2827 (drum) w/ 8Q405 100 mg/l (new, new) | 140 | Air | 2.2 | Au |
| qcm166 | 2827 (drum) w/ 8Q405/BHT mix 170 mg/l (dirty engine test) | 140 | Air | 3.9 | Au |
| ssz278 | 2980 w/ 50 ppb copper | 140 | Air | 9.4 | Au |
| qcm167 | 2980 w/ 10 ppb copper | 140 | Air | 12.0 | Au |
| ssz279 | 2990 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 2.7 | Au |
| qcm168 | 2991 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.2 | Au |
| ssz280 | 3037 | 140 | Air | 5.1 | Au |
| qcm169 | 3048 | 140 | Air | 7.9 | Au |
| ssz281 | 3037 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 1.2 | Au |
| qcm171 | 2827 w/ MCP-1309 300 mg/l | 140 | Air | 2.0 | Au |
| ssz282 | 3048 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 1.2 | Au |
| ssz283 | 3000 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 4.8 | Au |
| qcm172 | 3001 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 4.9 | Au |
| ssz284 | 3000 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 2.0 | Au |
| qcm173 | 3001 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.1 | Au |
| ssz285 | 3059 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.5 | Au |
| ssz286 | 2827 w/ MCP-1521 300 mg/l | 140 | Air | 1.3 | Au |
| ssz287 | 2980 w/ Copper 40 ppb | 140 | Air | 28.2 | Au |
| ssz288 | 2980 w/ Copper 20 ppb | 140 | Air | 2.6 | Au |
| qcm174 | 3049 w/ 8Q405 100 mg/l, BHT 25 mg/l and MDA 10 mg/l | 140 | Air | 2.2 | Au |
| qcm175 | 2985 w/ MCP-1309 300 mg/l and BHT 25 mg/l | 140 | Air | 2.0 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (μg/cm²)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|----------------------------------|---|-------------------------------|
| ssz289 | 2827 w/ PL-1712 308 mg/l | 140 | Air | 2.9 | Au |
| pz001 | 2827 | 140 | Air | 5.0 | Au |
| ssz290 | 2827 w/ PL-1708 112.5 mg/l | 140 | Air | 1.8 | Au |
| qcm176 | 2980 w/ MCP-1521 300 mg/l | 140 | Air | 3.0 | Au |
| pz002 | 2827 (5-gallon can) | 140 | Air | 3.5 | Au |
| pz003 | 2827 (5-gallon can) 30 ml w/ Exxsol D-80 30 ml | 140 | Helium | 37.8 | Ag |
| ssz291 | 2980 w/ MCP-1309 300 mg/l | 140 | Air | 3.1 | Au |
| qcm177 | 2827 w/ PL-1715 135 mg/l | 140 | Air | 1.9 | Au |
| pz004 | 2827 (5-gallon can) 5 ml w/ Exxsol D-80 55 ml | 140 | Helium | 15.8 | Ag |
| ssz292 | 2827 w/ PL-1709 392 mg/l | 140 | Air | 3.1 | Au |
| qcm178 | 2827 w/ PL-1710 87 mg/l | 140 | Air | 2.3 | Au |
| pz005 | 3002 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 8.3 | Au |
| qcm179 | 2994 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 2.7 | Au |
| ssz293 | 2993 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.3 | Au |
| ssz294 | 2827 w/ PL-1707 125 mg/l | 140 | Air | 3.3 | Au |
| qcm180 | 2827 w/ PL-1711 235 mg/l | 140 | Air | 2.0 | Au |
| ssz295 | 2993 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.22 | Au |
| pz006 | 2827 from 5-gallon can | 140 | Air 15 psi (Heat-up with Helium) | 6.9 | Au |
| pz007 | 2827 | 140 | Air 5 psi (Heat-up with He) | 1.8 | Au |
| qcm181 | 3047 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Au |
| ssz296 | 2995 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.7 | Au |
| ssz298 | 2922 | 140 | Air | 1.5 | Au |
| ssz297 | 2922 w/ phenol 112 mg/l | 140 | Air | 0.9 | Au |
| pz008 | 2827 | 140 | Air 25 psi (Heat-up with He) | 6.6 | Au |
| qcm182 | 3037 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 4.7 | Au |
| ssz299 | 3019 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 6.2 | Au |
| qcm183 | 3048 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 4.7 | Au |
| pz009 | 2827 | 140 | Air 15 psi (Heat-up with He) | 4.7 | Au |
| ssz300 | 3036 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.3 | Au |
| qcm184 | 3049 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.2 | Au |
| ssz301 | 3037 w/ phenol 90 ppm | 140 | Air | 5.3 | Au |
| qcm185 | 3020 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.2 | Au |
| pz010 | 2827 | 140 | Air 30 psi (Heat-up with He) | 6.9 | Au |
| pz011 | 2827 | 140 | Air 10 psi (Heat-up with He) | 3.0 | Au |
| qcm186 | 3062 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 2.6 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------------------------|--|-------------------------------|
| ssz302 | 3061 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 5.5 | Au |
| ssz303 | 2992 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.9 | Au |
| pz012 | 2827 | 140 | Air 20 psi (Heat-up with He) | 6.4 | Au |
| qcm187 | 3031 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 6.6 | Au |
| pz013 | 2827 w/ 8Q405-1671 100 mg/l | 140 | Air | 1.3 | Au |
| qcm188 | 2827 w/ 8Q405-1621 100mg/l | 140 | Air | 2.4 | Au |
| ssz304 | 2827 w/ 8Q405-1591 100 mg/l | 140 | Air | 1.6 | Au |
| ssz305 | 2827 w/ 8Q405-1571 100 mg/l | 140 | Air | 2.1 | Au |
| pz014 | 2827 w/ 8Q405-1651 100 mg/l | 140 | Air | 1.3 | Au |
| qcm189 | 2827 w/ 8Q405-1641 100 mg/l | 140 | Air | 2.4 | Au |
| ssz306 | 3002 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 6.6 | Au |
| qcm190 | 3030 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.3 | Au |
| pz015 | 3031 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.2 | Au |
| ssz307 | 2995 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.0 | Au |
| pz016 | 2992 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.9 | Au |
| qcm191 | 2994 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.3 | Au |
| qcm192 | 3048 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.9 | Au |
| pz017 | 3062 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.3 | Au |
| qcm193 | 3061 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.4 | Au |
| pz018 | 2827 H2O and KOH Extracted | 140 | Air | 5.1 | Au |
| qcm194 | 2999 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.2 | Au |
| ssz308 | 3059 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 5.1 | Au |
| ssz309 | 2959 SPE Extracted | 140 | Air | 2.0 | Au |
| pz020 | 3037 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 25 mg/l | 140 | Air | 0.5 | Au |
| ssz310 | 2827 w/ 8Q406 125 mg/l | 140 | Air | 1.4 | Au |
| pz021 | 3029 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.6 | Au |
| ssz311 | 2827 w/ 3091 27 ml/l | 140 | Air | 0.8 | Au |
| qcm195 | 2827 w/ 3094 27 ml/l | 140 | Air | 1.1 | Au |
| pz022 | 2922 w/ VX-4447 25 mg/l | 140 | Air | 2.1 | Au |
| ssz312 | 2926 w/ 8Q406 125 mg/l | 140 | Air | 4.4 | Au |
| qcm196 | 2980 w/ 8Q406 125 mg/l | 140 | Air | 5.1 | Au |
| pz023 | 3020 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 0.5 | Au |
| ssz313 | 2827 w/ 8Q405-1591 100 mg/l and BHT 25 mg/l | 140 | Air | 1.2 | Au |
| pz024 | 2980 w/ 8Q405-1591 100 mg/l and BHT 25 mg/l | 140 | Air | 1.0 | Au |
| qcm197 | 2926 w/ 8Q405-1591 100 mg/l and BHT 25 mg/l | 140 | Air | 3.4 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|--|------------------------|------------|--|-------------------------------|
| qcm198 | 2827 w/ 3095 27 ml/l | 140 | Air | 0.5 | Au |
| pz025 | 2827 w/ 3096 27 ml/l | 140 | Air | 0.3 | Au |
| ssz314 | 2827 w/ 3090 27 ml/l | 140 | Air | 1.3 | Au |
| qcm199 | 2959 | 140 | Air | 4.4 | Au |
| pz026 | 3037 SPE | 140 | Air | 7.7 | Au |
| ssz315 | 2827 w/ 3092 27 ml/l | 140 | Air | 1.2 | Au |
| qcm200 | 2827 w/ 3093 27 ml/l | 140 | Air | 1.3 | Au |
| pz027 | 2827 w/ 3097 27 ml/l | 140 | Air | 6.8 | Au |
| ssz316 | 2995 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 1.1 | Au |
| ssz317 | 2827 w/ PL-1707 125 mg/l | 140 | Air | 2.5 | Au |
| qcm201 | 2827 w/ PL-1709 392 mg/l | 140 | Air | 1.3 | Au |
| pz028 | 2827 w/ PL-1710 87 mg/l | 140 | Air | 0.3 | Au |
| ssz318 | 3098 | 140 | Air | 1.2 | Au |
| qcm202 | 3099 | 140 | Air | 1.4 | Au |
| pz029 | 3100 | 140 | Air | 1.6 | Au |
| qcm203 | 3098 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.5 | Au |
| pz030 | 3098 w/ 8Q405 100 mg/l and 8Q203 70 mg/l | 140 | Air | 0.5 | Au |
| qcm204 | 2922 w/ CAO-5 25 mg/l | 140 | Air | 3.3 | Au |
| pz031 | 2922 w/ PRODOX 3114 25 mg/l | 140 | Air | 4.1 | Au |
| qcm205 | 2827 w/ IFLC 1002 125 mg/l | 140 | Air | 2.6 | Au |
| pz032 | 2980 w/ PL-1710 87 mg/l | 140 | Air | 1.9 | Au |
| ssz319 | 2827 | 140 | Air | 4.3 | Au |
| ssz320 | 2827 after clay treatment | 140 | Air | 1.3 | Au |
| qcm206 | 2926 w/ PL-1710 87 mg/l | 140 | Air | 7.5 | Au |
| pz033 | 2985 w/ PL-1710 87 mg/l | 140 | Air | 13.4 | Au |
| ssz321 | 2827 after silica gel extraction | 140 | Air | 2.9 | Au |
| qcm207 | 2959 after basic water extraction | 140 | Air | 13.1 | Au |
| pz034 | 2926 w/ MCP-1521 150 mg/l | 140 | Air | 6.0 | Au |
| ssz322 | 2926 w/ PL-1709 392 mg/l | 140 | Air | 5.1 | Au |
| qcm208 | 2980 w/ MCP-1521 150 mg/l | 140 | Air | 5.0 | Au |
| pz035 | 2926 | 140 | Air | 5.1 | Au |
| ssz323 | 2747 after basic water treatment | 140 | Air | 1.1 | Au |
| ssz324 | 2963 | 140 | Air | 13.1 | Au |
| pz036 | 2962 | 140 | Air | 6.5 | Au |
| ssz325 | 2963 w/ 8Q406 125 mg/l | 140 | Air | 4.5 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (µg/cm²)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|-------------------------------------|---|-------------------------------|
| qcm209 | 2962 w/ 8Q406 125 mg/l and MDA 2 mg/l | 140 | Air | 5.2 | Au |
| pz037 | 2962 w/ 8Q406 125 mg/l | 140 | Air | 3.8 | Au |
| qcm210 | 2962 w/ 8Q406 125 mg/l and MDA 5 mg/l | 140 | Air | 4.3 | Au |
| pz038 | 2963 w/ 8Q406 125 mg/l and MDA 5 mg/l | 140 | Air | 0.4 | Au |
| ssz326 | 2963 w/ 8Q406 125 mg/l and MDA 2 mg/l | 140 | Air | 0.8 | Au |
| qcm211 | 2963 w/ 8Q406 125 mg/l and MDA 10 mg/l | 140 | Air | 1.8 | Au |
| pz039 | 2962 w/ 8Q406 125 mg/l and MDA 10 mg/l | 140 | Air | 0.1 | Au |
| ssz327 | 2827 w/ 3111 144 mg/l | 140 | Air | 0.7 | Au |
| qcm212 | 2827 w/ 3112 135 mg/l | 140 | Air | 1.0 | Au |
| pz040 | 2827 w/ 3113 160 mg/l | 140 | Air | 0.1 | Au |
| ssz328 | 2926 w/ C-13 labelled phenol 200 mg/l | 140 | Air | 5.1 | Au |
| qcm213 | 2827 w/ 3114 160 mg/l | 140 | Air | 1.1 | Au |
| pz041 | 2827 w/ 3115 160 mg/l | 140 | Air | 0.1 | Au |
| ssz329 | 2827 w/ 3115 160 mg/l | 140 | Air | 0.6 | Au |
| qcm214 | 2827 w/ 3116 145 mg/l | 140 | Air | 1.1 | Au |
| pz042 | 2827 w/ 3117 135 mg/l | 140 | Air | 0.5 | Au |
| pz043 | 2827 w/ 3113 160 mg/l | 140 | Air | 0.1 | Au |
| pz044 | 2827 | 140 | Air | 3.8 | Au |
| ssz330 | 2827 w/ MCP-1571 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.7 | Au |
| qcm215 | 2980 w/ MCP-1571 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.1 | Au |
| pz045 | 2926 w/ MCP-1571 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.3 | Au |
| ssz337 | 2926 | 140 | Air 4.9 psi (Heat-up with Nitrogen) | 0.6 | Au |
| qcm220 | 3110 | 140 | Air | 5.7 | Au |
| ssz338 | 3083 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.7 | Au |
| qcm221 | 3098 w/ 8Q405 and 8Q203 (Kelly flight test) | 140 | Air | 0.5 | Au |
| pz046 | 3082 | 140 | Air | 12.7 | Au |
| ssz339 | 3108 | 140 | Air | 7.2 | Au |
| ssz340 | 3082 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 8.0 | Au |
| qcm222 | 3109 | 140 | Air | 2.8 | Au |
| pz048 | 2827 w/ triphenylphosphine 142 mg/60 ml | 140 | Air | 0.0 | Au |
| ssz341 | 3108 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 3.9 | Au |
| qcm224 | 3109 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.3 | Au |
| ssz342 | 3102 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 9.2 | Au |
| ssz343 | 3109 w/ 8Q405 100 mg/l, BHT 25 mg/l, and 2 mg/l | 140 | Air | 0.4 | Au |
| pz047 | 2827 | 140 | Air | 5.7 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (ug/cm²)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|--------------------------------------|---|---------------------------|
| qcm226 | 3110 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| ssz344 | 3082 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |
| ssz272 | 3285 | 140 | Air | 9.7 | Au |
| ssz331 | 3084 w/ JP-8 additives | 140 | Air | 7.1 | Au |
| ssz332 | 3084 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 5.6 | Au |
| ssz333 | 2926 | 140 | Air 14.2 psi (Heat-up with Nitrogen) | 2.9 | Au |
| ssz334 | 2926 | 140 | Air 9.4 psi (Heat-up with Nitrogen) | 1.4 | Au |
| ssz335 | 2926 | 140 | Air 18.5 psi (Heat-up with Nitrogen) | 7.2 | Au |
| ssz336 | 2926 | 140 | Air 27.9 psi (Heat-up with Nitrogen) | 7.8 | Au |
| qcm139 | 2827 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 10 mg/l | 140 | Air | 5.5 | Pt |
| qcm144 | 2747 | 140 | Air | 0.6 | Au |
| qcm159 | 2991 w/ MCP-147B 300 mg/l and BHT 25 mg/l | 140 | Air | 3.7 | Au |
| qcm162 | 2980 w/ 8Q405 100 mg/l (new, new additive) | 140 | Air | 6.1 | Au |
| qcm216 | 3084 | 140 | Air | 19.2 | Au |
| qcm217 | 3084 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 5.1 | Au |
| qcm218 | 3083 | 140 | Air | 4.4 | Au |
| qcm219 | 3102 | 140 | Air | 8.7 | Au |
| qcm228 | 3108 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.6 | Au |
| qcm229 | 3110 w/ 8Q405 100 mg/l and BHT 25 mg/l | 140 | Air | 0.8 | Au |
| ssz345 | 3083 w/ 8Q405 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 3.7 | Au |
| pz049 | 2827 w/ triphenylphosphine 142 mg/60 ml | 100 | Air | 0.0 | Au |
| ssz346 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 13.7 psi (Heat-up with Nitrogen) | 0.3 | Au |
| qcm230 | 3102 w/ 8Q405 100 mg/l, BHT 25 mg/l and MDA 2 mg/l | 140 | Air | 2.0 | Au |
| pz052 | Hexadecane | 100 | Air | 0.0 | Au |
| pz051 | Hexadecane | 140 | Air | 0.2 | Au |
| pz053 | Hexadecane | 120 | Air | 0.1 | Au |
| ssz347 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 25 psi (Heat-up with Nitrogen) | 0.6 | Au |
| ssz348 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 5.2 psi (Heat-up with Nitrogen) | 0.2 | Au |
| ssz349 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 10.1 psi (Heat-up with Nitrogen) | 0.2 | Au |
| qcm231 | 2827 w/ MCP-147B 150 mg/l, BHT 25 mg/l and MDA 2 mg/l | 140 | Air | 0.8 | Au |
| ssz350 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 36.3 psi (Heat-up with Nitrogen) | 0.4 | Au |
| qcm232 | 2926 w/ MCP-147B 150 mg/l, BHT 25 mg/l and MDA 2 mg/l | 140 | Air | 1.0 | Au |
| pz054 | Hexadecane w/ triphenylphosphine 2430 mg/l | 120 | Air | 0.0 | Au |
| ssz352 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 20.0 psi (Heat-up with Nitrogen) | 0.1 | Au |
| ssz351 | Exxsol D-80 w/ BHT 25 mg/l | 140 | Air 15.2 psi (Heat-up with Nitrogen) | 0.3 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz055 | Hexadecane w/ triphenylphosphine 0.972 g/l | 120 | Air | 0.0 | Au |
| pz056 | Hexadecane with 0.972 g/l triphenylphosphine | 100 | Air | 0.0 | Au |
| ssz353 | 2980 w/ MCP-147B 150 mg/l, BHT 25 mg/l and MDA 2 mg/l | 140 | Air | 0.6 | Au |
| ssz354 | 3084 w/ 8Q405 100 mg/l, BHT 25 mg/l, and JP-8 additives (P.H.) | 140 | Air | 4.6 | Au |
| qcm233 | 3084 w/ JP-8 additives (Parker Hannifin) | 140 | Air | 3.9 | Au |
| ssz355 | Dodecane w/ 3-methylthiophene 81 mg/l | 140 | Air | 0.9 | Ag |
| pz057 | Hexadecane | 120 | Air | 0.0 | Au |
| ssz356 | Dodecane w/ diphenylsulfide 81 mg/l | 140 | Air | 0.9 | Ag |
| qcm234 | Dodecane w/ 1-hexanethiol 67 mg/l | 140 | Helium | 0.4 | Ag |
| ssz357 | 3084 | 140 | Air | 14.9 | Au |
| ssz358 | Dodecane w/ 3,4 dimethylthiophenol 82 mg/l | 140 | Nitrogen | 0.5 | Ag |
| qcm235 | Dodecane w/ benzyldisulfide 100 mg/l | 140 | Helium | 0.8 | Au |
| ssz361 | 2747 w/ 2827 SPE extract and sulfur compounds 1 ml | 140 | Nitrogen | 1.5 | Ag |
| ssz360 | 2747 w/ 1-hexanethiol 337 mg/l | 140 | Nitrogen | 0.6 | Ag |
| ssz362 | 2827 SPE extracted | 140 | Nitrogen | 37.7 | Ag |
| qcm237 | 2747 with 2827 SPE extract | 140 | Helium | 1.5 | Ag |
| ssz363 | 2747 (used Pt crystal) | 140 | Air | 1.0 | Pt |
| qcm238 | 2980 w/ 3096 27 ml/l | 140 | Air | 0.7 | Au |
| ssz364 | 2926 w/ 3096 27 ml/l | 140 | Air | 0.5 | Au |
| qcm239 | 2747 | 140 | Air | 1.0 | Au |
| ssz365 | 2980 w/ 3096 5 ml/l | 140 | Air | 1.5 | Au |
| qcm240 | 2926 w/ 3096 5 ml/l | 140 | Air | 1.2 | Au |
| ssz366 | 2747 | 140 | Air | 1.1 | Pt |
| qcm241 | 2827 30 ml and 2747 30 ml | 140 | Air | 3.1 | Au |
| ssz367 | 2980 w/ 3096 10 ml/l | 140 | Air | 1.2 | Au |
| qcm242 | 2926 w/ 3096 10 ml/l | 140 | Air | 0.6 | Au |
| ssz369 | 2926 w/ 3096 20 ml/l | 140 | Air | 0.5 | Au |
| ssz368 | 2926 w/ tetrahydroquinoline 500 ppm | 140 | Air | 8.4 | Au |
| qcm244 | 2922 | 140 | Air | 2.9 | Au |
| ssz371 | 2926 w/ benzyl alcohol 500 ppm | 140 | Air | 2.2 | Au |
| ssz370 | 2827 | 140 | Air | 2.8 | Au |
| qcm245 | 2827 | 140 | Air | 3.6 | Au |
| ssz372 | 2827 recirculated | 140 | Air | 5.4 | Au |
| qcm246 | 2827 recirculated | 140 | Air | 4.0 | Au |
| ssz373 | 2827 | 140 | Air | 6.6 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| qcm247 | 2827 | 140 | Air | 3.0 | Au |
| ssz374 | 2827 | 140 | Air | 4.2 | Au |
| ssz375 | 2827 recirculated | 140 | Air | 5.2 | Au |
| qcm248 | 3119 | 140 | Air | 11.4 | Au |
| ssz376 | 2827 recirculated twice | 140 | Air | 3.2 | Au |
| qcm249 | 3119 recirculated | 140 | Air | 8.2 | Au |
| qcm250 | 3123 | 140 | Air | 1.4 | Au |
| ssz377 | 3122 | 140 | Air | 4.3 | Au |
| ssz380 | 2922 w/ TBHQ 25 mg/l | 140 | Air | 4.1 | Au |
| ssz381 | 2922 w/ PL-1694 25 mg/l | 140 | Air | 11.3 | Au |
| qcm252 | 2922 | 140 | Air | 2.6 | Au |
| ssz382 | 2922 w/ VX-4447 25 mg/l | 140 | Air | 3.8 | Au |
| ssz383 | 2922 | 140 | Air | 4.4 | Au |
| ssz384 | 2922 w/ 3023 25 mg/l | 140 | Air | 3.3 | Au |
| ssz385 | 2922 w/ 2927 25 mg/l | 140 | Air | 6.6 | Au |
| ssz386 | 2922 w/ 3104 25 mg/l | 140 | Air | 4.2 | Au |
| qcm253 | 2827 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.0 | Au |
| qcm254 | 2926 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |
| ssz387 | 2922 w/ BHT 25 mg/l | 140 | Air | 3.7 | Au |
| ssz388 | 2922 w/ 3105 25 mg/l | 140 | Air | 4.7 | Au |
| qcm255 | 3084 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.3 | Au |
| ssz389 | 2922 w/ 3106 25 mg/l | 140 | Air | 3.5 | Au |
| ssz390 | 2922 w/ 3079 25 mg/l | 140 | Air | 4.5 | Au |
| ssz391 | 2922 w/ 3080 25 mg/l | 140 | Air | 5.5 | Au |
| qcm256 | 3084 w/ BzOH 500 ppm | 140 | Air | 6.5 | Au |
| ssz392 | 2922 w/ PL-1694 5 mg/l | 140 | Air | 2.5 | Au |
| ssz394 | 3136 (Asian Jet A-1) | 140 | Air | 3.1 | Au |
| qcm257 | 2827 | 140 | Air | 4.5 | Au |
| ssz393 | 2922 | 140 | Air | 2.4 | Au |
| ssz395 | Dodecane w/ 10 mg/l elemental sulfur | 140 | Air | 29.0 | Au |
| ssz396 | 2922 w/ BHT 25 mg/l and MDA 5.7 mg/l | 140 | Air | 4.2 | Au |
| qcm259 | 2827 Mobile Blend #2 437.5 mg/l | 140 | Air | 0.8 | Au |
| ssz398 | Dodecane with 1 mg/l elemental sulfur | 140 | Nitrogen | 14.3 | Ag |
| qcm261 | 2827 w/ POSF-3124 160 mg/l | 140 | Air | 0.8 | Au |
| ssz399 | Dodecane w/ elemental S 0.1 mg/l | 140 | Nitrogen | 13.6 | Ag |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (ug/cm²)</u> | <u>Electrode Material</u> |
|-------------------|----------------------------------|------------------------|------------|---|-------------------------------|
| qcm260 | 2827 w/ Mobile Blend #3 500 mg/l | 140 | Air | 0.7 | Au |
| ssz397 | 2922 w/ MDA 5.7 mg/l | 140 | Air | 3.1 | Au |
| qcm262 | 2827 w/ POSF-3125 160 mg/l | 140 | Air | 2.1 | Au |
| ssz401 | 2827 | 140 | Air | 7.0 | Au |
| qcm263 | 2827 w/ POSF-3126 160 mg/l | 140 | Air | 1.0 | Au |
| ssz402 | 2827 w/ POSF-3126 160 mg/l | 140 | Air | 2.9 | Au |
| qcm264 | 2827 w/ POSF-3127 160 mg/l | 140 | Air | 0.9 | Au |
| ssz400 | 2827 w/ MCP-147B 150 mg/l | 140 | Air | 2.6 | Au |
| ssz403 | 2818 | 140 | Air | 1.7 | Au |
| qcm265 | 2827 w/ POSF-3128 160 mg/l | 140 | Air | 1.1 | Au |
| ssz404 | 2827 | 140 | Air | 6.8 | Au |
| qcm266 | 2827 w/ POSF-3129 160 mg/l | 140 | Air | 0.8 | Au |
| qcm267 | 2827 | 140 | Air | 3.1 | Au |
| qcm268 | 2827 | 140 | Air | 3.3 | Au |
| ssz405 | 2827 | 140 | Air | 6.8 | Au |
| ssz406 | 2827 | 140 | Air | 4.5 | Au |
| qcm269 | 2827 w/ MCP-147B 150 mg/l | 140 | Air | 1.7 | Au |
| ssz407 | 2827 | 140 | Air | 5.3 | Au |
| qcm270 | 2827 | 140 | Air | 5.4 | Au |
| qcm271 | 2747 | 140 | Air | 0.7 | Au |
| ssz408 | 3134 | 140 | Air | 1.2 | Au |
| ssz409 | 3135 | 140 | Air | 1.6 | Au |
| pz060 | 2827 | 140 | Air | 4.4 | Au |
| pz061 | 2827 w/ MCP-147B 150 mg/l | 140 | Air | 0.8 | Au |
| ssz410 | 3132 JP-8+100 (after filter) | 140 | Air | 1.9 | Au |
| ssz411 | 3131 JP-8+100 (before filter) | 140 | Air | 1.2 | Au |
| pz063 | 2747 | 140 | Air | 1.3 | Au |
| ssz412 | 2926 | 140 | Air | 4.0 | Au |
| pz064 | 2747 | 140 | Air | 0.7 | Au |
| ssz413 | 2926 w/ MCP-147B 150 mg/l | 140 | Air | 1.0 | Au |
| ssz414 | 2926 | 160 | Air | 1.0 | Au |
| pz065 | 2827 | 160 | Air | 4.5 | Au |
| pz066 | 2827 | 160 | Air | 4.7 | Au |
| pz067 | 2827 w/ MCP-147B 150 mg/l | 160 | Air | 3.4 | Au |
| ssz415 | 2926 | 160 | Air | 1.8 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|------------------------------------|--|---------------------------|
| ssz416 | 2926 w/ MCP-147B 150 mg/l | 160 | Air | 0.6 | Au |
| pz068 | 2827 w/ MCP-147B 150 mg/l | 160 | Air | 4.3 | Au |
| ssz417 | 2926 w/ MCP-147B 150 mg/l | 160 | Air | 0.6 | Au |
| ssz160 | 2827 w/ PL-1700 15 mg/l | 140 | Air | 4.1 | Au |
| pz069 | 2827 w/ MDA 2 mg/l | 160 | Air | 6.6 | Au |
| ssz418 | 2926 w/ MDA 2 mg/l | 160 | Air | 2.5 | Au |
| pz070 | 2827 w/ 8Q406 125 mg/l | 160 | Air | 8.5 | Au |
| ssz419 | 2926 w/ 8Q406 125 mg/l | 160 | Air | 1.7 | Au |
| ssz420 | 2926 w/ 8Q406 125 mg/l | 140 | Air | 2.5 | Au |
| pz071 | 2926 w/ 8Q406 125 mg/l | 140 | Air | 0.7 | Au |
| pz072 | 2827 w/ MDA 2 mg/l | 140 | Air | 6.9 | Au |
| ssz421 | 2926 w/ MDA 2 mg/l | 140 | Air | 2.9 | Au |
| pz073 | 2827 | 140 | Air 15 psi (Heat-up with Nitrogen) | 6.4 | Au |
| ssz422 | 2926 | 140 | Air 15 psi (Heat-up with Nitrogen) | 2.4 | Au |
| pz074 | 2827 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 160 | Air 15 psi (Heat-up with Nitrogen) | 1.7 | Au |
| ssz423 | 2926 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 160 | Air 15 psi (Heat-up with Nitrogen) | 1.8 | Au |
| pz075 | 2827 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air 15 psi (Heat-up with Nitrogen) | 0.5 | Au |
| ssz424 | 2926 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air 15 psi (Heat-up with Nitrogen) | 0.4 | Au |
| ssz425 | 2926 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 170 | Air 15 psi (Heat-up with Nitrogen) | 2.0 | Au |
| pz076 | 2827 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 170 | Air 15 psi (Heat-up with Nitrogen) | 1.9 | Au |
| pz077 | 2827 w/ 3096 10 ml/l, BHT 25 mg/L, and MDA 2 mg/l | 150 | Air 15 psi (Heat-up with Nitrogen) | 1.3 | Au |
| ssz426 | 2926 w/ 3096 10 ml/l, BHT 25 mg/l, and MDA 2 mg/l | 150 | Air 15 psi (Heat-up with Nitrogen) | 0.7 | Au |
| pz078 | 2827 | 170 | Air 15 psi (Heat-up with Nitrogen) | 2.6 | Au |
| ssz427 | 2926 | 170 | Air 15 psi (Heat-up with Nitrogen) | 1.5 | Au |
| ssz428 | 3084 | 140 | Air 15 psi (Heat-up with Nitrogen) | 10.6 | Au |
| pz079 | 3119 | 140 | Air 15 psi (Heat-up with Nitrogen) | 7.0 | Au |
| ssz429 | 3084 | 140 | Air 15 psi (Heat-up with Nitrogen) | 24.8 | Au |
| pz080 | 3119 | 140 | Air | 9.3 | Au |
| ssz430 | 3084 w/ 8Q406 125 mg/l | 140 | Air | 6.5 | Au |
| pz081 | 3119 w/ 8Q406 125 mg/l | 140 | Air | 7.8 | Au |
| ssz431 | 3084 w/ MDA 5.8 mg/l | 140 | Air | 1.8 | Au |
| pz082 | 3119 w/ MDA 5.8 mg/l | 140 | Air | 12.8 | Au |
| ssz432 | 3084 w/ 8Q406 125 mg/l and MDA 5.8 mg/l | 140 | Air | 0.2 | Au |
| pz083 | 3119 w/ 8Q406 125 mg/l and MDA 5.8 mg/l | 140 | Air | 0.5 | Au |
| ssz433 | 3084 w/ BHT 24 mg/l and MDA 5.8 mg/l | 140 | Air | 1.3 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| pz084 | 3119 w/ BHT 24 mg/l and MDA 5.8 mg/l | 140 | Air | 1.3 | Au |
| pz085 | 3119 w/ BHT 24 mg/l | 140 | Air | 26.8 | Au |
| ssz434 | 3084 w/ BHT 24 mg/l | 140 | Air | 5.3 | Au |
| pz086 | 3145 | 140 | Air | 7.1 | Au |
| ssz435 | 3139 | 140 | Air | 0.7 | Au |
| pz087 | 3145 | 140 | Air | 6.4 | Au |
| ssz436 | 3139 w/ BHT 24 mg/l | 140 | Air | 0.4 | Au |
| ssz437 | 3139 w/ MDA 5.8 mg/l | 140 | Air | 0.8 | Au |
| pz088 | 3145 w/ 8Q406 125 mg/l | 140 | Air | 2.8 | Au |
| ssz438 | 3139 w/ BHT 24 mg/l and MDA 5.8 mg/l | 140 | Air | 1.0 | Au |
| pz089 | 3145 w/ MDA 5.8 mg/l | 140 | Air | 4.9 | Au |
| ssz439 | 3139 w/ 8Q406 125 mg/l | 140 | Air | 0.2 | Au |
| pz090 | 3145 w/ BHT 24 mg/l | 140 | Air | 3.1 | Au |
| ssz440 | 3139 w/ 8Q406 125 mg/l and MDA 5.8 mg/l | 140 | Air | 0.2 | Au |
| pz091 | 3145 w/ BHT 24 mg/l and MDA 5.8 mg/l | 140 | Air | 4.9 | Au |
| ssz441 | 3139 | 140 | Air | 7.1 | Au |
| pz092 | 3145 w/ 8Q406 125 mg/l and MDA 5.8 mg/l | 140 | Air | 0.9 | Au |
| ssz442 | 3119 w/ triphenyl phosphine 0.075% | 140 | Air | 21 | Au |
| pz093 | 3145 w/ MDA 12 mg/l | 140 | Air | 3.9 | Au |
| ssz443 | 3139 | 140 | Air | 0.6 | Au |
| pz094 | 3145 w/ MDA 3 mg/l | 140 | Air | 1.0 | Au |
| ssz444 | 3119 w/ BHT 24 mg/l | 140 | Air | 18.9 | Au |
| pz095 | 3145 w/ MDA 3 mg/l | 140 | Air | 4.3 | Au |
| ssz445 | 2747 (glass liner) | 140 | Air | 0.5 | Au |
| ssz446 | 3119 (glass liner) | 140 | Air | 23.8 | Au |
| pz096 | 2827 (glass liner) | 140 | Air | 2.7 | Au |
| ssz447 | 3119 w/ MDA 5.8 mg/l (glass liner) | 140 | Air | 0.5 | Au |
| pz097 | 3145 (glass liner) | 140 | Air | 7.6 | Au |
| ssz448 | 3084 (glass liner) | 140 | Air | 14.6 | Au |
| pz098 | 3145 w/ MDA 5.8 mg/l (glass liner) | 140 | Air | 12.3 | Au |
| ssz449 | 3084 w/ MDA 5.8 mg/l (glass liner) | 140 | Air | 1.3 | Au |
| pz099 | 2827 w/ 3154 190 mg/l (glass liner) | 140 | Air | 2.0 | Au |
| ssz450 | 2926 w/ 3024 160 mg/l | 140 | Air | 1.3 | Au |
| pz100 | 3084 w/ 3124 160 mg/l | 140 | Air | 2.0 | Au |
| ssz452 | 2747 w/ 8Q406 65 mg/l and MCP-1750 220 mg/l | 140 | Air | 0.6 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---|------------------------|--------------|--|---------------------------|
| pz102 | 2827 w/ 3155 190 mg/l | 140 | Air | 1.1 | Au |
| pz103 | 2827 w/ MCP-1750 438 mg/l | 140 | Air | 0.5 | Au |
| ssz453 | 3119 w/ MCP-1750 438 mg/l | 140 | Air | 7.5 | Au |
| pz104 | 2827 w/ 3156 190 mg/l | 140 | Air | 1.0 | Au |
| ssz454 | 2747 w/ MCP-1750 438 mg/l | 140 | Air | 0.5 | Au |
| pz105 | 2827 w/ 3157 190 mg/l | 140 | Air | 0.5 | Au |
| ssz455 | 3119 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l | 140 | Air | 5.0 | Au |
| pz106 | 2827 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l | 140 | Air | 1.2 | Au |
| ssz456 | 2747 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l (1 week) | 140 | Air | 0.5 | Au |
| pz107 | 3119 w/ JP-8 additives | 140 | Air | 6.8 | Au |
| ssz457 | 2963 SPE w/ methanol extract | 140 | Air | 1.9 | Au |
| pz108 | 2827 w/ 8Q406 125 mg/l | 140 | Air | 2.1 | Au |
| ssz459 | 2963 | 140 | Air | 6.1 | Au |
| pz110 | 2922 w/ 3150 25 mg/l | 140 | Air | 1.5 | Au |
| pz111 | 2922 w/ 3151 25 mg/l | 140 | Air | 3.3 | Au |
| pz112 | 2922 w/ 3152 25 mg/l | 140 | Air | 2.9 | Au |
| pz113 | 2922 w/ 3153 25 mg/l | 140 | Air | 1.4 | Au |
| pz114 | 2827 w/ SPE | 140 | Air | 4.4 | Au |
| ssz461 | 3139 w/ BHT 25 mg/l | 140 | Air | 0.3 | Au |
| pz115 | 2922 w/ 3163 25 mg/l | 140 | Air | 2.3 | Au |
| pz116 | 2922 w/ BHT 25 mg/l | 140 | Air | 5.6 | Au |
| ssz462 | 2827 w/ 8Q460 127 mg/l | 140 | Air | 1.1 | Au |
| pz117 | 2922 w/ 3164 25 mg/l | 140 | Air | 5.7 | Au |
| ssz463 | 3119 w/ 8Q460 127 mg/l | 140 | Air | 3.6 | Au |
| pz118 | 2922 w/ 3165 25 mg/l | 140 | Air | 3.9 | Au |
| ssz464 | 2747 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l (1 month) | 140 | Air | 0.7 | Au |
| pz119 | 2827 w/ 3171 125 mg/l | 140 | Air | 0.6 | Au |
| ssz465 | 3084 w/ tetralin 500 ppm | 140 | Air | 10.2 | Au |
| pz120 | 2827 w/ 3172 125 mg/l | 140 | Air | 12.3 | Au |
| ssz466 | 3084 | 140 | Air | 11.4 | Au |
| pz121 | 2827 | 140 | Air | 4.2 | Au |
| ssz467 | n-dodecane | 140 | Air (10 psi) | 0.2 | Au |
| ssz468 | n-dodecane | 140 | Air (33 psi) | 0.4 | Au |
| pz122 | 2827 w/ 3177 100 mg/l | 140 | Air | 4.1 | Au |
| ssz469 | n-dodecane | 140 | Air (23 psi) | 0.3 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz123 | 2922 w/ 3178 25 mg/l | 140 | Air | 4.1 | Au |
| pz124 | 3119 w/ BHT 25 mg/l and MDA 5.8 mg/l (30 hrs.) | 140 | Air | 4.5 | Au |
| pz125 | 3119 w/ 8Q406 125 mg/l and MDA 5.8 mg/l (46 hrs) | 140 | Air | 0.5 | Au |
| ssz470 | 3084 w/ 8Q406 125 mg/l and MDA 5.8 mg/l (46.7 hrs) | 140 | Air | 0.6 | Au |
| pz126 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l (27 hrs) | 140 | Air | 7.3 | Au |
| ssz471 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l | 140 | Air | 1.8 | Au |
| ssz472 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l (57 hrs) | 140 | Air | 0.9 | Au |
| pz127 | 2827 (20 hrs) | 140 | Air | 4.1 | Au |
| pz128 | 2827 | 140 | Air | 5.2 | Au |
| ssz473 | 3119 | 140 | Air | 21.9 | Au |
| pz130 | 3119 | 140 | Air | 4.7 | Au |
| ssz474 | 3119 | 140 | Air | 21.9 | Au |
| pz131 | 3119 | 140 | Air | 12.9 | Au |
| ssz475 | 3119 | 140 | Air | 15.7 | Au |
| pz132 | 3119 | 140 | Air | 7.1 | Au |
| pz126 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l (27 hrs) | 140 | Air | 7.3 | Au |
| ssz471 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l | 140 | Air | 1.8 | Au |
| ssz472 | 3084 w/ BHT 25 mg/l and MDA 5.8 mg/l (57 hrs) | 140 | Air | 0.9 | Au |
| pz127 | 2827 (20 hrs) | 140 | Air | 4.1 | Au |
| pz129 | 2827 (8 μl 8Q406 added at 3.7 hrs) | 140 | Air | 4.1 | Au |
| ssz473 | 3119 | 140 | Air | 21.9 | Au |
| pz130 | 3119 | 140 | Air | 4.7 | Au |
| ssz474 | 3119 | 140 | Air | 21.9 | Au |
| pz131 | 3119 | 140 | Air | 12.9 | Au |
| ssz475 | 3119 | 140 | Air | 15.7 | Au |
| pz132 | 3119 | 140 | Air | 7.1 | Au |
| ssz476 | 3119 | 140 | Air | 17.5 | Au |
| pz133 | 3119 | 140 | Air | 7.3 | Au |
| ssz477 | 3119 | 140 | Air | 11.4 | Au |
| pz134 | 3119 | 140 | Air | 12.9 | Au |
| ssz478 | 3119 | 140 | Air | 9.2 | Au |
| pz135 | 3119 | 140 | Air | 20.6 | Au |
| pz136 | 3119 | 140 | Air | 18.9 | Au |
| ssz479 | 3119 | 140 | Air | 7.0 | Au |
| pz137 | 3119 | 140 | Air | 12.9 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| ssz480 | 3119 | 140 | Air | 9.6 | Au |
| pz138 | 3119 | 140 | Air | 17.9 | Au |
| ssz481 | 3145 w/ MDA 5.8 mg/l | 140 | Air | 5.1 | Au |
| pz139 | 3119 w/ BHT 24 mg/l | 140 | Air | 11.7 | Au |
| pz140 | 3119 w/ triphenyl phosphine 209 mg/l | 140 | Air | 11.2 | Au |
| pz141 | 3119 | 140 | Air | 22.3 | Au |
| ssz483 | 3119 w/ triphenyl phosphine 209 mg/l | 140 | Air | 8.4 | Au |
| pz142 | 3119 w/ BH T 24 mg/l | 140 | Air | 17.6 | Au |
| pz143 | 3119 w/ MDA 5.8 mg/l | 140 | Air | 4.5 | Au |
| ssz485 | 2827 | 140 | Air | 6.4 | Au |
| pz145 | 3119 w/ 8Q406 125 mg/l | 140 | Air | 0.3 | Au |
| pz146 | 3119 w/ 8Q406 125 mg/l and MDA 5.8 mg/l | 140 | Air | 0.2 | Au |
| ssz486 | 2827 w/ 3180 120 mg/l | 140 | Air | 6.3 | Au |
| pz144 | 3119 w/ BHT 24 mg/l and MDA 5.8 mg/l | 140 | Air | 1.4 | Au |
| ssz484 | 2926 w/ 3129 160 mg/l | 140 | Air | 1.4 | Au |
| ssz487 | 2827 w/ 3181 120 mg/l | 140 | Air | 0.8 | Au |
| ssz488 | 3204 | 140 | Air | 1.0 | Au |
| pz147 | 3119 w/ 8Q406 125 mg/l and MDA 5.8 mg/l (27.5 hrs) | 140 | Air | 0.2 | Au |
| ssz489 | 3205 | 140 | Air | 0.4 | Au |
| ssz490 | 2827 w/ 3182 150 mg/l | 140 | Air | 0.7 | Au |
| pz148 | 3119 w/ BHT 24 mg/l and MDA 5.8 mg/l (88 hrs) | 140 | Air | 0.5 | Au |
| pz149 | 2827 w/ 3183 120 mg/l | 140 | Air | 1.5 | Au |
| ssz491 | 3204 w/ BHT 25 mg/l | 140 | Air | 0.5 | Au |
| ssz492 | 3204 w/ AO-31 25 mg/l | 140 | Air | 0.4 | Au |
| pz150 | 2827 w/ 3184 120 mg/l | 140 | Air | 3.2 | Au |
| ssz493 | 3204 w/ AO-24 50 mg/l | 140 | Air | 1.0 | Au |
| pz151 | 2827 w/ 3185 120 mg/l | 140 | Air | 4.0 | Au |
| ssz494 | 3204 w/ AO-36 25 mg/l | 140 | Air | 0.2 | Au |
| pz152 | 2827 w/ 3186 100 mg/l | 140 | Air | 0.6 | Au |
| ssz495 | 3204 w/ AO-37 25 mg/l | 140 | Air | 1.1 | Au |
| pz153 | 2827 w/ 3187 100 mg/l | 140 | Air | 2.7 | Au |
| ssz496 | 3204 w/ Hitec 4702 25 mg/l | 140 | Air | 0.4 | Au |
| ssz497 | 3204 w/ Hitec 4703 25 mg/l | 140 | Air | No mass | Au |
| pz155 | 2827 w/ 3189 120 mg/l | 140 | Air | 4.4 | Au |
| ssz498 | 2922 w/ 1232 25 mg/l | 140 | Air | 2.2 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz156 | 3119 w/ 8Q406 125 mg/l and MDA 5.8 mg/l (83 hrs) | 140 | Air | 0.2 | Au |
| ssz499 | 3204 w/ Hitec 4703 25 mg/l | 140 | Air | No mass | Au |
| ssz500 | 3204 w/ Hitec 4763 25 mg/l | 140 | Air | 0.3 | Au |
| pz157 | 2827 w/ 3190 150 mg/l | 140 | Air | 0.6 | Au |
| ssz501 | 3204 w/ MDA 5.8 mg/l | 140 | Air | 0.8 | Au |
| pz158 | 2827 w/ 3191 150 mg/l | 140 | Air | 0.3 | Au |
| pz159 | 2827 w/ 3192 100 mg/l | 140 | Air | 0.6 | Au |
| ssz502 | 2922 w/ 3214 25 mg/l | 140 | Air | 3.4 | Au |
| pz160 | 2827 w/ 3193 100 mg/l | 140 | Air | 0.6 | Au |
| ssz503 | 2922 w/ 3213 25 mg/l | 140 | Air | 4.0 | Au |
| pz161 | 2827 w/ 3179 10 g/l | 140 | Air | 1.4 | Au |
| ssz504 | 2827 w/ 8Q405 100 mg/l, AO-31 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.8 | Au |
| pz162 | 2827 w/ triphenylphosphine 260 mg/l | 140 | Helium | 1.0 | Ag |
| ssz505 | 2827 w/ 3202 150 mg/l | 140 | Air | 0.7 | Au |
| ssz506 | 2827 w/ 3203 125 mg/l | 140 | Air | 0.6 | Au |
| pz163 | 2827 w/ 3195 100 mg/l | 140 | Air | 0.5 | Au |
| ssz507 | 2827 w/ 3088 125 mg/l | 140 | Air | 1.1 | Au |
| pz164 | 2827 w/ 3196 100 mg/l | 140 | Air | 0.7 | Au |
| ssz508 | 2827 | 140 | Air | 4.9 | Au |
| pz165 | 2827 w/ 3197 100 mg/l | 140 | Air | 0.5 | Au |
| pz166 | 2827 w/ 3199 100 mg/l | 140 | Air | 0.4 | Au |
| pz154 | 2827 w/ 3188 100 mg/l | 140 | Air | 1.4 | Au |
| ssz510 | 2827 w/ 3201 100 mg/l | 140 | Air | 0.9 | Au |
| pz167 | 2827 w/ 3200 100 mg/l | 140 | Air | 0.4 | Au |
| ssz509 | 2827 w/ 3198 100 mg/l | 140 | Air | 0.2 | Au |
| pz168 | 2827 w/ 3194 100 mg/l | 140 | Air | 0.2 | Au |
| ssz511 | 3119 w/ 3111 144 mg/l, BHT 25 mg/l, and MDA 2mg/l | 140 | Air | 2.0 | Au |
| pz169 | 2827 w/ 3111 144 mg/l, BHT 25 mg/l, and MDA 2 mg/l (bad run) | 140 | Air | 0.4 | Au |
| pz170 | 2827 w/ 3114 160 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.8 | Au |
| ssz512 | 3119 w/ 3114 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 5.0 | Au |
| pz171 | 3215 (JP-8 +100 Springfield ANG) | 140 | Air | 0.6 | Au |
| ssz513 | 3119 w/ 3111 144 mg/l and BHT 25 mg/l | 140 | Air | 0.9 | Au |
| pz172 | 2926 w/ 3111 144 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| ssz514 | 3119 w/ 3114 160 mg/l and BHT 25 mg/l | 140 | Air | 0.4 | Au |
| pz173 | 2926 w/ 3114 160 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.7 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| ssz515 | 2827 w/ 3111 144 mg/l and BHT 25 mg/l | 140 | Air | 0.3 | Au |
| pz174 | dodecane w/ elemental S 0.1 mg/l | 140 | Helium | 0.25 | Ag |
| ssz516 | 2827 w/ 3114 160 mg/l and BHT 25 mg/l | 140 | Air | 0.6 | Au |
| pz175 | dodecane w/ elemental S 1.05 mg/l | 140 | Air | 0.4 | Ag |
| ssz517 | 2926 w/ 3111 144 mg/l and BHT 25 mg/l | 140 | Air | 1.4 | Au |
| pz176 | dodecane w/ elemental S 10.5 mg/l | 140 | Helium | 5.8 | Ag |
| ssz518 | 2926 w/ 3114 160 mg/l and BHT 25 mg/l | 140 | Air | 0.4 | Au |
| pz177 | 2827 w/ 3111 144 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |
| ssz519 | 3119 w/ SDA, BHT, and MDA 627 mg/l | 140 | Air | 0.4 | Au |
| pz178 | 2827 w/ SDA, BHT, and MDA 627 mg/l | 140 | Air | 4.3 | Au |
| ssz520 | 2926 w/ SDA, BHT, and MDA 627 mg/l | 140 | Air | 1.2 | Au |
| pz179 | 2827 w/ SDA, BHT, and MDA 627 mg/l | 140 | Air | 3.0 | Au |
| pz180 | dodecane w/ elemental S 11 mg/l | 140 | Helium | 16.1 | Ag |
| pz181 | 2827 w/ SDA 600 mg/l | 140 | Air | 1.6 | Au |
| ssz521 | 3119 w/ SDA 600 mg/l | 140 | Air | 6.3 | Au |
| pz182 | dodecane w/ elemental S 1.1 mg/l | 140 | Helium | 15.2 | Ag |
| ssz522 | 2926 w/ SDA 600 mg/l | 140 | Air | 2.0 | Au |
| pz183 | dodecane w/ elemental sulfur 0.11 mg/l | 140 | Helium | 1.1 | Au |
| ssz523 | 3066 | 140 | Air | 10.7 | Au |
| pz184 | 2827 w/ SDA 10 ml/l | 140 | Air | 1.0 | Au |
| ssz524 | 3205 w/ AO-24 50 mg/l | 140 | Air | 1.3 | Au |
| pz185 | 2827 after SPE | 140 | Air | 1.0 | Au |
| ssz525 | 3205 w/ BHT 25 mg/l | 140 | Air | 0.2 | Au |
| pz186 | 3166 w/ BHT 25 mg/l | 140 | Air | 7.5 | Au |
| ssz526 | 3119 w/ 3171 125 mg/l | 140 | Air | 2.5 | Au |
| pz187 | 2922 w/ AO-24 50 mg/l | 140 | Air | 3.9 | Au |
| ssz527 | 2926 w/ 3171 125 mg/l | 140 | Air | 1.0 | Au |
| pz188 | 3166 w/ 8Q406 125 mg/l | 140 | Air | 1.2 | Au |
| pz189 | 3166 w/ MDA 5.8 mg/l | 140 | Air | 0.75 | Au |
| pz190 | 3166 w/ 8Q406 125 mg/l and MDA 2 mg/l (22 hrs) | 140 | Air | 0.2 | Au |
| ssz528 | 3119 w/ 3198 100 mg/l | 140 | Air | 4.3 | Au |
| pz191 | 3216 (JP-8 from Staniford Field, KY) | 140 | Air | 1.8 | Au |
| pz192 | 3217 (JP-8+100 from Staniford Field, KY) | 140 | Air | 0.1 | Au |
| pz193 | BP Bender treated outlet | 140 | Air | 2.6 | Au |
| pz194 | 3119 after I.C. chelate | 140 | Air | 7.4 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|---------------------------------------|------------------------|--|--|---------------------------|
| ssz529 | 3119 | 140 | Air | 15.3 | Au |
| pz195 | 3119 | 140 | Air | 7.4 | Au |
| ssz530 | 1-K kerosine from BP | 140 | Air | 0.4 | Au |
| pz196 | 3119 after I.C. chelate w/ MDA 2 mg/l | 140 | Air | 6.7 | Au |
| pz197 | 3119 w/ 3200 100 mg/l | 140 | Air | 3.1 | Au |
| ssz531 | 2827 w/ GTA additive 10 ppm | 140 | Air | 2.2 | Au |
| pz198 | 3145 after I.C. chelate | 140 | Air | 5.5 | Au |
| pz199 | 3119 w/ MDA 2 mg/l | 140 | Air | 10.8 | Au |
| ssz532 | 3084 | 160 | Air | 1.1 | Au |
| pz200 | 3145 w/ MDA 2 mg/l | 140 | Air | 6.4 | Au |
| ssz533 | 3084 | 140 | Oxygen 4 psi (Heat up with Nitrogen) | 7.7 | Au |
| pz201 | 3145 after I.C. chelate w/ MDA 2 mg/l | 140 | Air | 5.8 | Au |
| ssz534 | 3084 | 160 | Oxygen 4.8 psi (Heat up with Nitrogen) | 7.6 | Au |
| ssz535 | 3084 | 170 | Oxygen 4.8 psi (Heat up with Nitrogen) | 6.5 | Au |
| ssz536 | 3084 | 180 | Oxygen 4.8 psi (Heat up with Nitrogen) | 5.2 | Au |
| ssz537 | 3119 | 140 | Oxygen 4.2 psi (Heat up with Nitrogen) | 7.7 | Au |
| ssz538 | 3119 | 160 | Oxygen 4.3 psi (Heat up with Nitrogen) | 6.5 | Au |
| pz202 | 3166 | 140 | Air | 9.6 | Au |
| ssz539 | 3119 | 170 | Oxygen 4.5 psi (Heat up with Nitrogen) | 6.0 | Au |
| pz203 | 3166 (w/ dirty crystal) | 140 | Air | 5.4 | Au |
| ssz540 | 3119 | 180 | Oxygen 4.8 psi (Heat up with Nitrogen) | 3.0 | Au |
| pz204 | 3166 | 140 | Air | 6.5 | Au |
| ssz541 | 3119 | 170 | Oxygen 4.5 psi (Heat up with Nitrogen) | 4.1 | Au |
| pz205 | 3166 (w/ dirty system) | 140 | Air | 9.1 | Au |
| ssz542 | 3119 | 150 | Oxygen 4.3 psi (Heat up with Nitrogen) | 9.6 | Au |
| ssz543 | 3084 | 150 | Oxygen 4.4 psi (Heat up with Nitrogen) | 9.8 | Au |
| ssz544 | 3119 w/ 8Q406 125 mg/l | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 9.3 | Au |
| ssz545 | 3119 w/ 8Q406 125 mg/l | 150 | Oxygen 4.2 psi (Heat up with Nitrogen) | 5.8 | Au |
| pz206 | 2827 w/ SDA, BHT, and MDA | 140 | Air | 0.7 | Au |
| ssz546 | 3119 w/ 8Q406 125 mg/l | 160 | Oxygen 4.6 psi (Heat up with Nitrogen) | 4.8 | Au |
| ssz547 | 3119 w/ 8Q406 125 mg/l | 170 | Oxygen 4.4 psi (Heat up with Nitrogen) | 3.8 | Au |
| pz207 | 2926 | 140 | Air | 2.9 | Au |
| ssz548 | 3119 w/ 8Q406 125 mg/l | 180 | Oxygen 4.7 psi (Heat up with Nitrogen) | 2.5 | Au |
| pz208 | 2747 | 100 | Oxygen 4.0 psi (Heat up with Nitrogen) | 0.4 | Au |
| pz209 | 2747 w/ Co catalyst (22 hrs) | 100 | Oxygen 4.0 psi (Heat up with Nitrogen) | 6.1 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|--|--|-------------------------------|
| pz211 | 2747 | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 1.2 | Au |
| pz212 | 2747 w/ Co catalyst | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 4.2 | Au |
| pz213 | 2747 w/ Co catalyst and aldehyde | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 3.0 | Au |
| ssz549 | 2827 | 140 | Air | 3.4 | Au |
| pz210 | 2747 w/ Co catalyst and aldehyde | 100 | Oxygen 4.0 psi (Heat up with Nitrogen) | 1.4 | Au |
| pz214 | 2747 w/ Co catalyst and aldehyde(2x) | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 4.6 | Au |
| ssz550 | 3119 | 140 | Air | 9.6 | Au |
| pz215 | 2747 w/ Co catalyst and aldehyde(0.5x) | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 3.5 | Au |
| ssz551 | 3229 (JP-8+100 from Burlington, VT) | 140 | Air | 0.4 | Au |
| pz216 | 2747 w/ Co catalyst and isopropanol | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 4.0 | Au |
| ssz552 | 3230 (JP-8 from Burlington, VT) | 140 | Air | 3.0 | Au |
| pz217 | 2747 w/ Co catalyst, aldehyde, and isopropanol | 140 | Oxygen 4.1 psi (Heat up with Nitrogen) | 1.2 | Au |
| ssz553 | 3232 (JP-8 from Otis ANG) | 140 | Air | 2.9 | Au |
| pz218 | 3234 (JP-8 from Westfield, MA) | 140 | Air | 1.3 | Au |
| ssz554 | 3233 (JP-8+100 from Otis ANG) | 140 | Air | 0.4 | Au |
| pz219 | 3235 (JP-8+100 from Westfield, MA) | 140 | Air | 0.3 | Au |
| ssz555 | 3119 w/ 3199 100 mg/l | 140 | Air | 4.6 | Au |
| pz220 | 2926 w/ 3199 100 mg/l | 140 | Air | 1.0 | Au |
| ssz556 | 3119 w/ 3199 100 mg/l and BHT 25 mg/l | 140 | Air | 1.5 | Au |
| pz221 | 2926 w/ 3199 100 mg/l and BHT 25 mg/l | 140 | Air | 0.3 | Au |
| ssz557 | 3119 w/ 3199 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.2 | Au |
| pz222 | 2926 w/ 3199 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.1 | Au |
| pz223 | 2827 w/ 3199 100 mg/l and BHT 25 mg/l | 140 | Air | 0.4 | Au |
| ssz558 | 2747 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l (6 months) | 140 | Air | 1.3 | Au |
| pz224 | 2827 w/ 3199 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.4 | Au |
| ssz559 | 3119 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l (6 months) | 140 | Air | 5.5 | Au |
| pz225 | 3242 (JP-8 from Westfield, MA) | 140 | Air | 1.8 | Au |
| ssz560 | 2827 w/ MCP-1750 220 mg/l and 8Q406 65 mg/l (6 months) | 140 | Air | 0.5 | Au |
| pz226 | 3243 (JP-8+100 from Westfield, MA) | 140 | Air | 0.2 | Au |
| ssz561 | 2827 w/ 8Q462 256 mg/l | 140 | Air | 1.2 | Au |
| pz227 | 2926 w/ 3157 190 mg/l | 140 | Air | 0.7 | Au |
| ssz562 | 2926 w/ 8Q462 256 mg/l | 140 | Air | 0.4 | Au |
| pz228 | 3084 w/ 3157 190 mg/l | 140 | Air | 1.0 | Au |
| ssz563 | 3084 w/ 8Q462 256 mg/l | 140 | Air | 0.7 | Au |
| pz229 | 3119 w/ 3157 190 mg/l | 140 | Air | 0.5 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|--|--|-------------------------------|
| ssz564 | 3119 w/ 8Q462 256 mg/l | 140 | Air | 0.6 | Au |
| pzz30 | 2827 w/ 3237 165 mg/l | 140 | Air | 0.9 | Au |
| ssz565 | 3084 w/ 8Q405 100 mg/l | 140 | Oxygen 4.2 psi (Heat up with Nitrogen) | 3.6 | Au |
| pzz31 | 2827 w/ 3238 165 mg/l | 140 | Air | 2.7 | Au |
| ssz566 | 3084 w/ 8Q405 100 mg/l | 150 | Oxygen 4.2 psi (Heat up with Nitrogen) | 4.7 | Au |
| pzz32 | 2827 w/ 3239 165 mg/l | 140 | Air | 0.6 | Au |
| ssz567 | 3084 w/ 8Q405 100 mg/l | 160 | Oxygen 4.5 psi (Heat up with Nitrogen) | 3.2 | Au |
| pzz33 | 2827 w/ 3241 165 mg/l | 140 | Air | 0.5 | Au |
| ssz568 | 3084 w/ 8Q405 100 mg/l | 170 | Oxygen 5.0 psi (Heat up with Nitrogen) | 4.8 | Au |
| pzz34 | 2827 w/ 3240 165 mg/l | 140 | Air | 0.9 | Au |
| ssz569 | 3084 w/ 8Q405 100 mg/l | 180 | Oxygen 4.6 psi (Heat up with Nitrogen) | 3.0 | Au |
| pzz35 | 3204 w/ AO-24 50 mg/l | 140 | Air | 2.2 | Au |
| ssz570 | 3084 w/ 8Q405 100 mg/l | 170 | Oxygen 4.4 psi (Heat up with Nitrogen) | 3.8 | Au |
| pzz36 | 2827 w/ 3182 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| ssz571 | 2827 w/ 3188 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.3 | Au |
| pzz37 | 3204 w/ AO-24 20 mg/l | 140 | Air | 1.8 | Au |
| ssz572 | 2827 w/ 3190 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.7 | Au |
| pzz38 | 3204 w/ AO-24 10 mg/l | 140 | Air | 1.7 | Au |
| ssz573 | 2827 w/ Wynne's Additive | 140 | Air | 1.3 | Au |
| pzz39 | 3204 w/ BHT 25 mg/l | 140 | Air | 2.6 | Au |
| ssz574 | 2827 w/ 3129 190 mg/l | 140 | Air | 2.7 | Au |
| pzz40 | 3204 | 140 | Air | 1.6 | Au |
| ssz575 | 2827 w/ 3245 150 mg/l | 140 | Air | 0.7 | Au |
| ssz576 | 2827 w/ 3246 150 mg/l | 140 | Air | 0.6 | Au |
| ssz577 | 2827 w/ 3247 150 mg/l | 140 | Air | 0.6 | Au |
| ssz578 | 2827 w/ 3248 150 mg/l | 140 | Air | 0.8 | Au |
| ssz579 | 2827 w/ 3249 100 mg/l | 140 | Air | 0.7 | Au |
| ssz580 | 2926 w/ 3202 150 mg/l | 140 | Air | 0.9 | Au |
| ssz581 | 3119 w/ 3202 150 mg/l | 140 | Air | 2.9 | Au |
| ssz582 | 2827 w/ 3171 125 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |
| pzz41 | 3084 w/ 8Q405 100 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 0.1 | Au |
| ssz583 | 2926 w/ 3171 125 mg/l, BHT 25 mg/l and MDA 2 mg/l | 140 | Air | 0.8 | Au |
| pzz42 | 3119 w/ 8Q405 100 mg/l, AO-24 10 mg/l and MDA 2 mg/l | 140 | Air | 0.1 | Au |
| ssz584 | 3119 w/ 3171 125 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| pzz43 | 2827 w/ 8Q405 100 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz244 | 3119 w/ 8Q405 100 mg/l, AO-24 10 mg/l, and MDA 2 mg/l (95 hours) | 140 | Air | 7.0 | Au |
| ssz585 | 2827 w/ PL-1740 100 mg/l and BHT 25 mg/l | 140 | Air | 0.5 | Au |
| pz245 | 2926 w/ 8Q405 100 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 0.1 | Au |
| ssz586 | 2827 w/ PL-1740 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| pz246 | 2827 w/ MCP-1750B 962 mg/l | 140 | Air | 0.2 | Au |
| ssz587 | 2926 w/ PL-1740 100 mg/l | 140 | Air | 1.3 | Au |
| pz247 | 2827 w/ MCP-1750C 505 mg/l | 140 | Air | 0.3 | Au |
| ssz588 | 2926 w/ PL-1740 100 mg/l and BHT 25 mg/l | 140 | Air | 0.6 | Au |
| pz248 | 3145 | 140 | Air | 5.9 | Au |
| ssz589 | 2926 w/ PL-1740 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| pz249 | 3145 w/ MDA 5.8 mg/l | 140 | Air | 4.5 | Au |
| ssz590 | 3259 Jet-A from Staniford Field, KY | 140 | Air | 7.1 | Au |
| ssz591 | 3260 (JP-8 from Staniford Field, KY) | 140 | Air | 0.7 | Au |
| pz250 | 3265 (JP-8 from GE) | 140 | Air | 2.0 | Au |
| ssz592 | 3261 (JP-8+100 from Staniford Field, KY) | 140 | Air | 0.05 | Au |
| pz251 | 3266 (JP-8+100 from GE) | 140 | Air | 0.4 | Au |
| pz252 | 3119 w/ MCP-1750B 962 mg/l | 140 | Air | 0.4 | Au |
| ssz593 | 2827 w/ 3182 150 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 0.4 | Au |
| pz253 | 3119 w/ MCP-1750C 505 mg/l | 140 | Air | 0.4 | Au |
| ssz594 | 2827 w/ 3188 100 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 0.6 | Au |
| pz254 | 3267 (JP-8 from Kingsley Field) | 140 | Air | 1.5 | Au |
| ssz595 | 2827 w/ 3190 150 mg/l, AO-24 10 mg/l, and MDA 2 mg/l | 140 | Air | 1.4 | Au |
| ssz596 | 2827 w/ 3263 160 mg/l | 140 | Air | 0.3 | Au |
| pz256 | 3204 w/ 3264 5 mg/l | 140 | Air | 1.8 | Au |
| ssz597 | 2827 w/ 3262 0.6 wt% Wynne's Additive | 140 | Air | 4.0 | Au |
| pz257 | 2827 w/ 3244 1.0 wt% Soy diesel | 140 | Air | 3.0 | Au |
| pz258 | 2926 w/ MCP-1750B 962 mg/l | 140 | Air | 0.3 | Au |
| ssz598 | 3084 w/ 3245 150 mg/l | 140 | Air | 0.8 | Au |
| pz259 | 2926 w/ MCP-1750C 505 mg/l | 140 | Air | 0.5 | Au |
| ssz599 | 3119 w/ 3245 150 mg/l | 140 | Air | 1.0 | Au |
| pz260 | 3084 w/ MCP-1750B 962 mg/l | 140 | Air | 0.0 | Au |
| ssz600 | 2926 w/ 3245 150 mg/l | 140 | Air | 1.7 | Au |
| pz261 | 3084 w/ MCP-1750C 505 mg/l | 140 | Air | 0.2 | Au |
| ssz601 | 3119 Cu doped/stressed in EDTST preheater | 140 | Air | 4.2 | Au |
| pz262 | 3272 (JP-8 from Springfield) | 140 | Air | 2.8 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz263 | 3273 (JP-8+100 from Springfield) | 140 | Air | 0.2 | Au |
| ssz602 | Texaco TXB-54-176 | 140 | Air | 4.4 | Au |
| pz264 | Hunt 96-178-1, JP-8 | 140 | Air | 0.8 | Au |
| ssz603 | 3279 Hunt 96-178-7, JP-8 | 140 | Air | 4.2 | Au |
| pz265 | 3280 Hunt 96-178-6, JP-8 | 140 | Air | 2.3 | Au |
| ssz604 | 3281 Hunt 96-178-8, JP-8 | 140 | Air | 7.4 | Au |
| pz266 | 2827 w/ 3274 236 mg/l | 140 | Air | 1.7 | Au |
| ssz605 | 2926 w/ 3182 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| pz267 | 2827 w/ 3275 251 mg/l | 140 | Air | 0.6 | Au |
| pz268 | 2827 w/ 3276 256 mg/l | 140 | Air | 0.4 | Au |
| ssz606 | 2926 w/ 3188 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.4 | Au |
| pz269 | 2827 w/ 3177 100 mg/l | 140 | Air | 3.0 | Au |
| pz270 | 2926 w/ 3190 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| ssz607 | 2827 w/ 8Q405 100 mg/l | 140 | Air | 0.6 | Au |
| pz271 | 3119 w/ 3182 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.9 | Au |
| ssz608 | 3084 w/ 3182 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.6 | Au |
| pz272 | 3119 w/ 3188 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 1.2 | Au |
| ssz609 | 3084 w/ 3188 100 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.5 | Au |
| pz273 | 3119 w/ 3190 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.3 | Au |
| ssz610 | 3084 w/ 3190 150 mg/l, BHT 25 mg/l, and MDA 2 mg/l | 140 | Air | 0.1 | Au |
| pz274 | 2926 w/ 3263 160 mg/l | 140 | Air | 0.4 | Au |
| pz275 | 3119 w/ 3263 160 mg/l | 140 | Air | 0.5 | Au |
| pz276 | 3119 | 140 | Air | 10.3 | Au |
| pz277 | 3084 w/ 3263 160 mg/l | 140 | Air | 0.5 | Au |
| pz278 | 3281 w/ 8Q462 256 mg/l | 140 | Air | 0.1 | Au |
| ssz611 | 3084 w/ 3239 165 mg/l | 140 | Air | 0.6 | Au |
| pz279 | 3119 w/ 3239 165 mg/l | 140 | Air | 0.2 | Au |
| ssz612 | 3084 w/ 3241 165 mg/l | 140 | Air | 0.4 | Au |
| pz280 | 2926 w/ 3239 165 mg/l | 140 | Air | 1.1 | Au |
| pz281 | 3119 w/ 3241 165 mg/l | 140 | Air | 0.3 | Au |
| ssz613 | 2926 w/ 3241 165 mg/l | 140 | Air | 0.2 | Au |
| pz282 | 2827 w/ PL-1746 293 mg/l | 140 | Air | 0.2 | Au |
| pz255 | 3268 (JP-8+100 from Kingsley) | 140 | Air | 0.6 | Au |
| ssz614 | 2926 | 140 | Air | 3.4 | Au |
| pz283 | 2827 w/ PL-1747 458 mg/l | 140 | Air | 0.6 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| ssz615 | 3084 | 140 | Air | 11.8 | Au |
| ssz616 | 2827 w/ 3291 160 mg/l | 140 | Air | 0.3 | Au |
| pz284 | 3119 w/ 3291 160 mg/l | 140 | Air | 1.4 | Au |
| ssz617 | 2827 w/ 3292 160 mg/l | 140 | Air | 0.2 | Au |
| pz285 | 2827 w/ 3293 180 mg/l | 140 | Air | 0.6 | Au |
| ssz618 | 2827 w/ 3294 180 mg/l | 140 | Air | 0.4 | Au |
| pz286 | 3285 (JP-8 from Sheppard) | 140 | Air | 1.2 | Au |
| ssz619 | 2827 | 140 | Air | 2.8 | Au |
| pz287 | 3286 (JP-8+100 from Sheppard) | 140 | Air | 0.6 | Au |
| pz288 | Exxsol D-110 | 140 | Air | 0.9 | Au |
| pz289 | Exxsol D-110 w/ BHT 50 mg/l | 140 | Air | 0.2 | Au |
| ssz620 | 3296 (JP-8+100 from Louisville) | 140 | Air | 0.1 | Au |
| pz290 | Exxsol D-110 w/ BHT 25 mg/l | 140 | Air | 0.7 | Au |
| pz291 | Exxsol D-110 w/ BHT 10.7 mg/l | 140 | Air | 0.9 | Au |
| ssz621 | 3119 w/ POSF-3263 160 mg/l and POSF-3290 100 mg/l | 140 | Air | 1.0 | Au |
| pz292 | Exxsol D-110 w/ BHT 4.2 mg/l | 140 | Air | 1.3 | Au |
| ssz622 | 2827 w/ 3295 327 mg/l | 140 | Air | 1.0 | Au |
| pz293 | Exxsol D-110 w/ BHT 38.3 mg/l | 140 | Air | 0.3 | Au |
| pz294 | Exxsol D-110 w/ BHT 50 mg/l | 140 | Air | -0.4 | Au |
| ssz623 | 2827 w/ modified SDA | 140 | Air | 3.6 | Au |
| ssz624 | 2827 | 140 | Air | 3.9 | Au |
| pz295 | Exxsol D-110 w/ BHT 55.6 mg/l | 140 | Air | 0.8 | Au |
| pz296 | 2827 | 140 | Air | 1.7 | Au |
| pz297 | 2827 | 140 | Air | 1.3 | Au |
| ssz625 | 2827 | 140 | Air | 2.1 | Au |
| ssz626 | 2827 | 140 | Air | 3.4 | Au |
| pz298 | 2827 | 140 | Air | 1.4 | Au |
| ssz627 | 2827 | 140 | Air | 1.1 | Au |
| pz299 | 3084 | 140 | Air | 8.3 | Au |
| ssz628 | 3084 | 140 | Air | 7.8 | Au |
| pz300 | 3119 | 140 | Air | 11.6 | Au |
| ssz629 | 3119 | 140 | Air | 9.8 | Au |
| pz301 | 2747 | 140 | Air | 0.8 | Au |
| ssz630 | 2747 | 140 | Air | 0.9 | Au |
| pz302 | 3119 | 140 | Air | | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|--------------------------------------|------------------------|------------|--|-------------------------------|
| ssz631 | 3119 | 140 | Air | | Au |
| ssz632 | SPE 3119 | 140 | Air | 3.9 | Au |
| ssz633 | SPE of 2827 | 140 | Air | 0.8 | Au |
| ssz634 | SPE 3084 | 140 | Air | 2.8 | Au |
| ssz635 | 3166 | 140 | Air | 10.1 | Au |
| ssz636 | SPE 3166 | 140 | Air | 2.1 | Au |
| pz303 | 3119 | 140 | Air | 17.3 | Au |
| pz304 | 3119 | 140 | Air | 12.6 | Au |
| pz305 | 3119 - Switched clamps w/ QCM #1 | 140 | Air | 10 | Au |
| pz306 | 3119 - Switched clamps w/ QCM #1 | 140 | Air | 14.0 | Au |
| ssz637 | 3119 with original clamps | 140 | Air | 18.6 | Au |
| ssz638 | 3084 - w/ 3rd clamp | 140 | Air | 13.6 | Au |
| pz307 | 3084 | 140 | Air | 5.6 | Au |
| ssz639 | 3084 | 140 | Air | 13.6 | Au |
| pz308 | 3084 w/ original clamp | 140 | Air | 10.0 | Au |
| ssz640 | 3084 w/ original clamp | 140 | Air | 12.5 | Au |
| ssz641 | 3119 - Filtered 1 μm | 140 | Air | 19.5 | Au |
| pz309 | 3084 - Filtered 1 μm | 140 | Air | 7.5 | Au |
| pz310 | 3084 - Filtered 0.1 μm | 140 | Air | 12.6 | Au |
| pz311 | 3084 - Filtered 0.1 μm | 140 | Air | 9.5 | Au |
| ssz642 | 3119 - Filtered 0.1 μm | 140 | Air | 22.3 | Au |
| pz312 | 3084 - Filtered 0.7 μm | 140 | Air | 9.8 | Au |
| pz313 | SPE 2976 | 140 | Air | 0.3 | Au |
| ssz643 | 2976 | 140 | Air | 0.5 | Au |
| pz314 | 2827 w/ 3304 100 mg/L | 140 | Air | 3.1 | Au |
| ssz644 | 2827 w/ .6 wt% 3262 & 256 mg/L 8Q462 | 140 | Air | 7.3 | Au |
| pz315 | 2827 w/ 3300 160 mg/L | 140 | Air | 0.8 | Au |
| ssz645 | 2926 w/ 3300 160 mg/L | 140 | Air | 1.1 | Au |
| pz316 | 2827 w/ 3303 200 mg/L | 140 | Air | 0.8 | Au |
| ssz646 | 3084 w/ 3300 160 mg/L | 140 | Air | 0.9 | Au |
| ssz647 | 2926 w/ 3303 200 mg/L | 140 | Air | 3.6 | Au |
| pz317 | 3084 w/ 3303 200 mg/L | 140 | Air | 3.1 | Au |
| pz318 | 2827 w/ 3301 160 mg/L | 140 | Air | 1.1 | Au |
| ssz648 | 2926 w/ 3301 160 mg/L | 140 | Air | 1.0 | Au |
| pz319 | 3084 w/ 3301 160 mg/L | 140 | Air | 0.9 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------------------------------|--|-------------------------------|
| ssz649 | 3119 w/ 3295 327 mg/L | 140 | Air | 0.4 | Au |
| pz320 | 2827 w/ 3306 26 mL/L | 140 | Air | 0.2 | Au |
| ssz650 | 2827 w/ 3307 26 mL/L | 140 | Air | 1.1 | Au |
| pz321 | 2827 w/ Nalco 3203/BHT/MDA | 140 | Air | 1.7 | Au |
| pz322 | 3119 w/ PL-1747 458 mg/L | 140 | Air | 2.0 | Au |
| ssz651 | 2926 w/ PL-1747 458 mg/L | 140 | Air | 1.2 | Au |
| pz323 | 3119 w/ 3303 200 mg/L | 140 | Air | 0.5 | Au |
| ssz652 | 3119 w/ 3302 200 mg/L | 140 | Air | 3.0 | Au |
| ssz653 | 3119 w/ 3300 160 mg/L | 140 | Air | 0.5 | Au |
| pz324 | 3119 w/ 3301 160 mg/L | 140 | Air | 0.6 | Au |
| pz326 | Exxsol D-110 w/ 46.7 mg/L Butyl Sulfide | 140 | Air | 2.2 | Au |
| pz327 | Exxsol D-110 w/ 25.15 mg/L Butyl Sulfide | 140 | Air | 0.5 | Au |
| ssz654 | POSF-3323 - JP8+100 (8Q462) | 140 | Air | 0.8 | Au |
| ssz655 | POSF-3322 - JP8 | 140 | Air | 2.5 | Au |
| pz328 | Exxsol D-110 w/ 100 mg/L Butyl Sulfide | 140 | Air | 0.6 | Au |
| pz329 | Exxsol D-110 w/ 25 mg/L Butyl Sulfide | 140 | Air | 0.5 | Au |
| ssz656 | 2827 w/ 3312 26 mL/L | 140 | Air | 10.2 | Au |
| pz330 | Exxsol D-110 w/ 50 mg/L Butyl Sulfide | 140 | Air | 0.6 | Au |
| ssz657 | 2827 w/ 3310 26 mL/L | 140 | Air | 2.0 | Au |
| pz331 | Exxsol D-110 w/ 300 mg/L Butyl Sulfide | 140 | Air | 0.6 | Au |
| ssz658 | 2827 w/ 3311 26 mL/L | 140 | Air | 12.0 | Au |
| pz332 | Exxsol D-110 | 160 | Air 15 psi (Heat-up with Nitrogen) | 0.4 | Au |
| ssz659 | POSF-2827 | 140 | Air | 1.7 | Au |
| ssz660 | 2827 w/ 3313 26 mL/L | 140 | Air | 9.5 | Au |
| ssz661 | 2827 w/ 3314 26 mL/L | 140 | Air | 3.4 | Au |
| pz333 | Exxsol D-110 w/ 300 mg/L Butyl Sulfide | 160 | Air 15 psi (heat up with Nitrogen) | 1.0 | Au |
| ssz662 | 2827 w/ 3315 26 mL/L | 140 | Air | 0.3 | Au |
| ssz663 | 2827 w/ 3316 26 mL/L | 140 | Air | 4.7 | Au |
| pz334 | Exxsol D-110 w/ 300 mg/L Butyl Sulfide | 160 | Air | 1.0 | Au |
| ssz664 | 2827 w/ 3317 26 mL/L | 140 | Air | 2.0 | Au |
| pz335 | 2827 w/ 3318 26 mL/L | 140 | Air | 0.2 | Au |
| ssz665 | 2827 w/ 3319 26 mL/L | 140 | Air | 2.8 | Au |
| pz336 | 2827 w/ 3320 26 mL/L | 140 | Air | 9.3 | Au |
| pz337 | 2827 w/ 3321 26 mL/L | 140 | Air | 2.6 | Au |
| ssz666 | 2827 w/ 3309 100 mg/L | 140 | Air | 0.9 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|---|------------------------|------------|--|-------------------------------|
| ssz667 | 2827 w/ 3308 100 mg/L | 140 | Air | 1.2 | Au |
| ssz668 | 3272 (JP8) | 140 | Air | 3.0 | Au |
| pz338 | 3273 (JP8+100) | 140 | Air | 0.5 | Au |
| pz339 | 3289 (JP8+100) | 140 | Air | 0.4 | Au |
| ssz669 | 3288 (JP8) | 140 | Air | 3.5 | Au |
| pz341 | Exxsol D-110 w/ Hexyl Sulfide 3230 mg/L | 140 | Air | 0.2 | Au |
| pz342 | Exxsol D-110 w/ Hexyl Sulfide 1662 mg/L | 140 | Air | 0.6 | Au |
| pz343 | Exxsol D-110 w/ Hexyl Sulfide 2384 mg/L | 140 | Air | 1.1 | Au |
| ssz670 | 3305A w/ BHT+MDA+Cu - Stored @ 140 C for 30 days | 140 | Air | 3.6 | Au |
| pz344 | Exxsol D-110 w/ Hexyl Sulfide 3338 mg/L | 140 | Air | 0.2 | Au |
| pz345 | Exxsol D-110 w/ BHT 50 mg/L | 140 | Air | 0.5 | Au |
| pz346 | Exxsol D-110 w/ BHT 50 mg/L & Hexyl Sulfide 3017 mg/L | 140 | Air | 0.2 | Au |
| pz347 | Exxsol D-110 w/ BHT 23.9 mg/L & Hexyl Sulfide 3082 mg/L | 140 | Air | 0.5 | Au |
| pz348 | Exxsol D-110 w/ BHT 23.9 mg/L | 140 | Air | 0.0 | Au |
| ssz671 | 2827 w/ MDA 2.8 mg/L & 8Q406 125 mg/L | 140 | Air | 1.6 | Au |
| pz350 | 2985 w/ 8Q462 256 mg/L | 140 | Air | 6.4 | Au |
| pz351 | 2985 w/ 8Q462 256 mg/L (Heated for 4 hrs.) | 140 | Air | - | Au |
| ssz672 | 3084 - SPE | 140 | Air | 2.3 | Au |
| pz352 | 3145 w/ BHT 24 mg/L | 140 | Air | 7.9 | Au |
| ssz673 | 2827 | 140 | Air | 2.8 | Au |
| pz353 | SPE 3145 w/ BHT 24 mg/L | 140 | Air | 1.9 | Au |
| pz354 | SPE 3084 (prep. w/ heptane) | 140 | Air | 2.2 | Au |
| ssz674 | 3084 - Added Extract Back to Fuel | 140 | Air | 2.7 | Au |
| ssz675 | 2747 w/ 2827 Extract (SPE) | 140 | Air | 5.9 | Au |
| pz355 | SPE 3145 w/ BHT 24 mg/L (10g. silica) | 140 | Air | 3.9 | Au |
| pz356 | SPE 3166 (heptane wash) | 140 | Air | 2.8 | Au |
| ssz676 | 2926 w/ 3271 458 mg/L | 140 | Air | 0.5 | Au |
| ssz677 | 3119 w/ 3271 458 mg/L | 140 | Air | 1.7 | Au |
| pz357 | 2827 w/ 3346 160 mg/L | 140 | Air | 1.1 | Au |
| ssz678 | 2827 w/ 3345 160 mg/L | 140 | Air | 0.5 | Au |
| pz358 | 2827 w/ 3348 45 mg/L | 140 | Air | 2.8 | Au |
| pz359 | 2827 w/ 3309 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.5 | Au |
| ssz679 | 2827 w/ 3308 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.7 | Au |
| ssz680 | 3119 w/ 3307 26 mL/L | 140 | Air | 0.5 | Au |
| pz360 | 3351 (JP-8 - Edwards AFB) | 140 | Air | 7.0 | Au |

Table 1. List of QCM Experiments (continued)

| Run Number | Fuel and Additives | Temperature (C) | Gas | Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$) | Electrode Material |
|-------------------|--|------------------------|------------|--|-------------------------------|
| pz361 | 3326 (JP-8+100 - Kirtland AFB) | 140 | Air | 0.8 | Au |
| ssz681 | 3325 (JP-8 - Kirtland AFB) | 140 | Air | 1.7 | Au |
| pz362 | 3119 w/ 3309 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.3 | Au |
| ssz682 | 3119 w/ 3308 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.5 | Au |
| pz363 | 2926 w/ 3309 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.3 | Au |
| ssz683 | 2926 w/ 3308 100 mg/L & BHT 25 mg/L & MDA 2 mg/L | 140 | Air | 0.6 | Au |
| ssz684 | 2963 SPE Fuel (1 g./no C7 wash) | 140 | Air | 0.6 | Au |
| pz364 | 2963 | 140 | Air | 5.9 | Au |
| pz365 | 2963 SPE Fuel (10 g./no C7 wash) | 140 | Air | 0.5 | Au |
| ssz685 | 3329 (JP8+100 - Otis ANG) | 140 | Air | 0.1 | Au |
| pz367 | 3334 (JP8 - Otis ANG) | 140 | Air | 1.5 | Au |
| pz368 | 2980 w/ 500 ppb Cu | 140 | Air | 5.2 | Au |
| ssz686 | 3353 (JP8 - Kirtland AFB) | 140 | Air | 2.0 | Au |
| pz370 | 2980 w/ 1 ppm Cu | 140 | Air | 4.9 | Au |
| pz369 | 2980 | 140 | Air | 1.2 | Au |
| pz366 | 2963 SPE Fuel (10 g. bed; C7 Wash) | 140 | Air | 0.8 | Au |
| pz371 | 2980 SPE Fuel (10g;C7) | 140 | Air | 3.3 | Au |
| ssz687 | 3350 (JP8+100 - Sheppard AFB) | 140 | Air | 0.5 | Au |
| pz373 | 2827 w/ 3363 200 mg/L | 140 | Air | 0.7 | Au |
| ssz689 | 2827 w/ 3362 200 mg/L | 140 | Air | 0.6 | Au |
| pz374 | 2827 w/ 3365 220 mg/L | 140 | Air | 0.6 | Au |
| ssz690 | 2827 w/ 3361 200 mg/L | 140 | Air | 0.9 | Au |
| pz375 | 2827 w/ 3358 200 mg/L | 140 | Air | 0.6 | Au |
| ssz691 | 2827 w/ 3357 200 mg/L | 140 | Air | 0.7 | Au |
| pz376 | 2827 w/ 3366 200 mg/L | 140 | Air | 0.6 | Au |
| pz378 | 2827 w/ PL-1763 229 mg/L | 140 | Air | 2.9 | Au |
| pz377 | 2980 w/ 50 ppb Cu | 140 | Air | 1.0 | Au |
| ssz692 | 2827 w/ PL-1762 229 mg/L | 140 | Air | 1.5 | Au |
| pz379 | 2827 w/ PL-1764 229 mg/L | 140 | Air | 1.7 | Au |
| ssz693 | 2827 w/ PL-1755 458 mg/L | 140 | Air | 0.5 | Au |
| pz380 | 2827 w/ PL-1756 229 mg/L | 140 | Air | 0.5 | Au |
| ssz694 | 2827 w/ PL-1757 229 mg/L | 140 | Air | 0.6 | Au |
| pz382 | 2827 w/ PL-1758 229 mg/L | 140 | Air | 0.8 | Au |
| pz383 | 2827 w/ PL-1759 229 mg/L | 140 | Air | 0.5 | Au |
| ssz695 | 3352 (JP8+100 - Kirtland AFB) | 140 | Air | 0.7 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (µg/cm²)</u> | <u>Electrode Material</u> |
|-------------------|--|------------------------|------------|---|-------------------------------|
| ssz696 | 2827 w/ PL-1760 305 mg/L | 140 | Air | 0.6 | Au |
| pz384 | 2980 w/ 1 mL HMDS | 140 | Air | 0.4 | Au |
| pz385 | 100 mL 2747 w/ 1 mL Co Acetylacetonate & w/ 1 mL Benzaldehyde | 140 | Air | 1.9 | Au |
| ssz697 | 2827 w/ PL-1761 305 mg/L. | 140 | Air | 4.1 | Au |
| pz386 | 3119 w/ 1 mL HMDS (60:1) | 140 | Air | 0.7 | Au |
| ssz698 | 2827 w/ PL-1765 305 mg/L | 140 | Air | 1.3 | Au |
| pz387 | 2980 w/ 0.5 mL HMDS (60:0.5) | 140 | Air | 0.7 | Au |
| pz388 | 2980 w/ 0.1 ml HMDS | 140 | Air | 10.7 | Au |
| ssz699 | 2827 w/ PL-1766 229 mg/L | 140 | Air | 0.3 | Au |
| ssz700 | 3322 - JP8 - Kirtland AFB | 140 | Air | 1.5 | Au |
| pz389 | 2980 w/ 0.1 mL HMDS | 140 | Air | 9.5 | Au |
| pz390 | 3119 w/ 0.1 mL HMDS | 140 | Air | 1.3 (?) | Au |
| pz391 | 100 mL 2747 w/ 1 mL Co Acetylacetonate (OLD) & w/ 1 mL | 140 | Air | 0.9 | Au |
| ssz701 | 3323 - JP8+100 - Kirtland AFB | 140 | Air | 0.5 | Au |
| ssz702 | 3349 - JP8 - Sheppard AFB | 140 | Air | 1.5 | Au |
| pz392 | 100 mL 2747 w/ 1 mL Co Benzylacetonate w/ 1 mL Benzaldehyde | 140 | Air | 0.8 | Au |
| pz393 | 100 mL 2747 w/ Co Benzylacetonate (OLD) & w/ 1 mL Benzaldehyde | 140 | Air | 0.9 | Au |
| ssz703 | 3342 - JP8+100 - Nashville | 140 | Air | 0.7 | Au |
| ssz704 | 3343 - JP8 - Nashville | 140 | Air | 1.0 | Au |
| pz394 | 3305 | 140 | Air | 3.5 | Au |
| pz395 | 3219 | 140 | Air | 3.1 | Au |
| pz396 | 3119 w/ 0.1 mL HMDS | 140 | Air | 5.5 | Au |
| pz397 | 3119 w/ HMDS 50 µL | 140 | Air | 9.5 | Au |
| ssz706 | 3324 | 140 | Air | 0.3 | Au |
| pz398 | 2980 w/ 0.2 mL HMDS | 140 | Air | 6.3 | Au |
| ssz705 | 3379 - JP8+100 | 140 | Air | 0.8 | Au |
| pz399 | 2980 w/ 0.3 mL HMDS | 140 | Air | 2.7 | Au |
| ssz707 | 3393 - JP8+100 | 140 | Air | 1.3 | Au |
| pz400 | 2980 w/ 0.4 mL HMDS | 140 | Air | 1.4 | Au |
| ssz708 | 2926 w/ 3357 200 mg/L | 140 | Air | 0.1 | Au |
| pz401 | 3084 w/ 0.5 mL HMDS | 140 | Air | 0.7 | Au |
| pz402 | 3084 w/ 0.1 mL HMDS | 140 | Air | 7.9 | Au |
| ssz709 | 2926 w/ 3358 200 mg/L | 140 | Air | 0.7 | Au |
| pz403 | 2980 (neat - 80 hours) | 140 | Air | 1.0 | Au |
| ssz710 | 2926 w/ 3359 200 mg/L | 140 | Air | 2.0 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours (ug/cm²)</u> | <u>Electrode Material</u> |
|-------------------|--------------------------------|------------------------|------------|---|-------------------------------|
| pz404 | 2926 w/ 3360 200 mg/L | 140 | Air | 0.7 | Au |
| pz406 | 2926 w/ 3363 200 mg/L | 140 | Air | 1.1 | Au |
| ssz712 | 2926 w/ 3362 200 mg/L | 140 | Air | 0.9 | Au |
| ssz711 | 2926 w/ 3361 200 mg/L | 140 | Air | 0.8 | Au |
| pz407 | 2926 w/ 3366 200 mg/L | 140 | Air | 0.8 | Au |
| ssz713 | 2926 w/ 3365 200 mg/L | 140 | Air | 1.3 | Au |
| pz408 | 2980 w/ 100 µL TMSI (Filtered) | 140 | Air | 1.2 | Au |
| pz409 | 3119 w/ 3359 200 mg/L | 140 | Air | 0.4 | Au |
| ssz714 | 3119 w/ 3358 200 mg/L | 140 | Air | 1.8 | Au |
| ssz715 | 3119 w/ 3360 200 mg/L | 140 | Air | 0.2 | Au |
| pz410 | 3119 w/ 3361 200 mg/L | 140 | Air | 0.5 | Au |
| pz405 | 2980 w/ 5 uL TMSI | 140 | Air | 0.9 | Au |
| pz411 | 3119 w/ 3363 200 mg/L | 140 | Air | 0.3 | Au |
| pz412 | 2980 w/ 0.4 mL HMDS | 140 | Air | 0.4 | Au |
| ssz716 | 3119 w/ 3365 200 mg/L | 140 | Air | 0.6 | Au |
| pz413 | 3119 w/ 3362 200 mg/L | 140 | Air | 0.4 | Au |
| ssz717 | 3119 w/ 3357 200 mg/L | 140 | Air | 0.5 | Au |
| pz414 | 3119 w/ 3366 200 mg/L | 140 | Air | 0.3 | Au |
| pz415 | 100 µL HMDS after SPE 3084 | 140 | Air | 4.3 | Au |
| ssz718 | 2827 w/ 3407 200 mg/L | 140 | Air | 0.8 | Au |
| pz416 | 2827 w/ 3408 200 mg/L | 140 | Air | 0.9 | Au |
| pz417 | SPE 3084 (w/ SPE C7 Prep.) | 140 | Air | 10.2 | Au |
| pz418 | SPE 3084 (w/ SPE C7 Prep.) | 140 | Air | 3.8 | Au |
| pz419 | 2980 w/ 100 µL BSA | 140 | Air | 1.7 | Au |
| ssz720 | 2747 | 140 | Air | 0.5 | Au |
| ssz719 | 2980 | 140 | Air | 0.9 | Au |
| pz420 | 2980 w/ 400 µL HMDS | 140 | Air | 0.8 | Au |
| ssz721 | 3419 - JP8 - Kirtland AFB | 140 | Air | 1.9 | Au |
| pz421 | 3423 - JP8 - GE | 140 | Air | 2.6 | Au |
| ssz722 | 3420 - JP8+100 - Kirtland AFB | 140 | Air | 0.8 | Au |
| ssz723 | 2985 | 140 | Air | 8.0 | Au |
| pz422 | POSF-3411 | 140 | Air | 0.5 | Au |
| ssz724 | POSF-3412 | 140 | Air | 8.7 | Au |
| pz423 | POSF-3428 | 140 | Air | 4.3 | Au |
| pz424 | 3428 w/ AO-30 25.75 mg/L | 140 | Air | 1.3 | Au |

Table 1. List of QCM Experiments (continued)

| <u>Run Number</u> | <u>Fuel and Additives</u> | <u>Temperature (C)</u> | <u>Gas</u> | <u>Deposition at 15 Hours ($\mu\text{g}/\text{cm}^2$)</u> | <u>Electrode Material</u> |
|-------------------|------------------------------|------------------------|------------|--|-------------------------------|
| ssz725 | 3428 w/ AO-29 25.65 mg/L | 140 | Air | 5.2 | Au |
| ssz726 | POSF-3430 | 140 | Air | 4.8 | Au |
| pz425 | 3428 w/ AO-23 25 mg/L | 140 | Air | 5.4 | Au |
| pz426 | 3428 w/ AO-31 25.65 mg/L | 140 | Air | 1.4 | Au |
| pz427 | 3428 w/ AO-32 26.05 mg/L | 140 | Air | 1.2 | Au |
| ssz727 | POSF-3430 | 140 | Air | 4.3 | Au |
| pz428 | 3428 w/ AO-36 24.95 mg/L | 140 | Air | 1.1 | Au |
| pz429 | 3428 w/ AO-37 25.55 mg/L | 140 | Air | 1.3 | Au |
| pz430 | 3428 w/ AO-46 24.65 mg/L | 140 | Air | 1.1 | Au |
| pz431 | 3428 w/ Hitec 4733 25 mg/L | 140 | Air | 0.8 | Au |
| pz432 | 3428 w/ Hitec 4702 25.9 mg/L | 140 | Air | 0.1 | Au |

This page intentionally left blank.

3. ISOTHERMAL CORROSION OXIDATION TEST DATA

The Isothermal Corrosion Oxidation Tester (ICOT) is a static test that has been used to evaluate the effectiveness of additives in jet fuel (9). The apparatus consists of an aluminum heating block, a temperature controller, and a flow controller. In a typical run a 100 mL fuel sample is stressed at 180C for 5 hours in a glass test tube with air bubbling through the sample at 1.3 L/hr. After 5 hours the air supply is discontinued and the test tube is removed from the heating block. The next day the sample is filtered through a pre-weighed 1 μ m glass microfiber filter. The filter is placed in an oven at 100F for several hours then cooled in a desiccator and re-weighed. The result is reported as milligrams of solids per liter of fuel. The effectiveness of an additive is based on its ability to reduce the amount of deposits collected on the filter. The deposition data for nearly all of the jet fuels and jet fuel blends that were tested between January 1994 and September 1997 are listed in Table 2.

This page intentionally left blank.

Table 2. List of ICOT Experiments

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2747 | 5 |
| 2799 | 0 |
| 2827 | 84 |
| 2922 | 104 |
| 2926 | 64 |
| 2928 | 76 |
| 2934 | 346 |
| 2936 | 72 |
| 2959 | 21 |
| 2963 | 409 |
| 2976 | 0 |
| 2980 | 70 |
| 2985 | 755 |
| 2827 with AF-114 (POSF-2895) at 100 mg/L | 110 |
| 2827 with Inhibitor A (POSF-2901) at 100 mg/L | 48 |
| 2827 with Prochem 3F29 (POSF-2790) at 100 mg/L | 77 |
| 2827 with Prochem 3F33 (POSF-2903) at 100 mg/L | 84 |
| 2827 with 3275008C (POSF-3022) at 200 mg/L | 157 |
| 2827 with 3275008D (POSF-3023) at 100 mg/L | 88 |
| 2827 with 3275008E (POSF-3024) at 100 mg/L | 50 |
| 2827 with 3275059B (POSF-3053) at 100 mg/L | 68 |
| 2827 with 3275059C (POSF-3054) at 100 mg/L | 33 |
| 2827 with 7R30 (POSF-3007) at 100 mg/L | 51 |
| 2827 with 8Q400 (POSF-2787) at 10 mg/L | 154 |
| 2827 with 8Q405 (POSF-2894) at 100 mg/L | 7 |
| 2922 with 8Q405 at 100 mg/L | 160 |
| 2926 with 8Q405 at 100 mg/L | 82 |
| 2928 with 8Q405 at 100 mg/L | 78 |
| 2934 with 8Q405 at 100 mg/L | 421 |
| 2936 with 8Q405 at 100 mg/L | 100 |
| 2959 with 8Q405 at 100 mg/L | 0 |
| 2963 with 8Q405 at 100 mg/L | 180 |
| 2980 with 8Q405 at 100 mg/L | 38 |
| 2985 with 8Q405 at 100 mg/L | 772 |
| 2827 with 8Q405 and BHT at 100 and 25 mg/L | 42 |
| 2922 with 8Q405 and BHT at 100 and 25 mg/L | 118 |
| 2926 with 8Q405 and BHT at 100 and 25 mg/L | 45 |
| 2928 with 8Q405 and BHT at 100 and 25 mg/L | 80 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2934 with 8Q405 and BHT at 100 and 25 mg/L | 177 |
| 2936 with 8Q405 and BHT at 100 and 25 mg/L | 105 |
| 2959 with 8Q405 and BHT at 100 and 25 mg/L | 2 |
| 2963 with 8Q405 and BHT at 100 and 25 mg/L | 124 |
| 2980 with 8Q405 and BHT at 100 and 25 mg/L | 3 |
| 2985 with 8Q405 and BHT at 100 and 25 mg/L | 901 |
| 2827 with 8Q405 and Exxon #12 (POSF-2843) at 100 and 25 mg/L | 22 |
| 2922 with 8Q405 and Exxon #12 at 100 and 25 mg/L | 109 |
| 2926 with 8Q405 and Exxon #12 at 100 and 25 mg/L | 44 |
| 2963 with 8Q405 and Exxon #12 at 100 and 25 mg/L | 150 |
| 2980 with 8Q405 and Exxon #12 at 100 and 25 mg/L | 11 |
| 2827 with 8Q405 (70%) and 8Q400 (30%) at 100 mg/L | 13 |
| 2922 with 8Q405 (70%) and 8Q400 (30%) at 100 mg/L | 80 |
| 2980 with 8Q405 (70%) and 8Q400 (30%) at 100 mg/L | 8 |
| 2827 with 8Q405 (70%), 8Q400 (20%) and 3F29 (10%) at 100 mg/L | 11 |
| 2922 with 8Q405 (70%), 8Q400 (20%) and 3F29 (10%) at 100 mg/L | 103 |
| 2980 with 8Q405 (70%), 8Q400 (20%) and 3F29 (10%) at 100 mg/L | 29 |
| 2922 with 7R30 (POSF-3007) at 100 mg/L | 127 |
| 2926 with 7R30 at 100 mg/L | 52 |
| 2928 with 7R30 at 100 mg/L | 83 |
| 2934 with 7R30 at 100 mg/L | 119 |
| 2936 with 7R30 at 100 mg/L | 79 |
| 2959 with 7R30 at 100 mg/L | 32 |
| 2963 with 7R30 at 100 mg/L | 363 |
| 2980 with 7R30 at 100 mg/L | 37 |
| 2827 with FOA-2A (POSF-2912) at 50 mg/L | 80 |
| 2827 with FOA-2 (POSF-2913) at 50 mg/L | 94 |
| 2827 with FOA-5 (POSF-2914) at 50 mg/L | 47 |
| 2827 with MDA (POSF-2904) at 10 mg/L | 9 |
| 2827 with PL-1517 (POSF-2852) at 25 mg/L | 108 |
| 2827 with PL-1601 (POSF-2853) at 25 mg/L | 100 |
| 2827 with PL-1602 (POSF-2854) at 25 mg/L | 40 |
| 2827 with PL-1605 (POSF-2906) at 25 mg/L | 17 |
| 2827 with PL-1606 (POSF-2907) at 25 mg/L | 5 |
| 2827 with PL-1607 (POSF-2908) at 25 mg/L | 0 |
| 2827 with PL-1608 (POSF-2909) at 25 mg/L | 14 |
| 2827 with PL-1610 (POSF-2910) at 25 mg/L | 27 |
| 2827 with PL-1614 (POSF-2911) at 25 mg/L | 16 |
| 2827 with PL-1642 (POSF-2921) at 25 mg/L | 8 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2827 with PL-1700 (POSF-2998) at 15 mg/L | 105 |
| 2980 with PL-1606 at 25 mg/L | 115 |
| 2980 with PL-1607 at 25 mg/L | 27 |
| 2926 with PL-1606 at 25 mg/L | 151 |
| 2926 with PL-1607 at 25 mg/L | 61 |
| 2980 with PL-1642 at 25 mg/L | 10 |
| 2926 with PL-1642 at 25 mg/L | 25 |
| 2922 with PL-1642 at 25 mg/L | 154 |
| 2934 with PL-1642 at 25 mg/L | 290 |
| 2827 with Exxon #12 (POSF-2843) at 25 mg/L | 17 |
| 2827 with Exxon #14 (POSF-2845) at 100 mg/L | 98 |
| 2827 with Exxon #15 (POSF-2846) at 100 mg/L | 108 |
| 2827 with Exxon #16 (POSF-2847) at 100 mg/L | 71 |
| 2827 with Exxon #17 (POSF-2848) at 100 mg/L | 52 |
| 2827 with Exxon #18 (POSF-2849) at 100 mg/L | 51 |
| 2827 with MCP-147B (POSF-2726) at 300 mg/L | 0 |
| 2827 with MCP-477 (POSF-2727) at 300 mg/L | 14 |
| 2827 with MCP-750 (POSF-3040) at 300 mg/L | 122 |
| 2827 with MCP-751 (POSF-3039) at 300 mg/L | 119 |
| 2827 with MCP-753 (POSF-3043) at 300 mg/L | 120 |
| 2827 with MCP-758 (POSF-3044) at 300 mg/L | 73 |
| 2827 with MCP-759 (POSF-3045) at 300 mg/L | 125 |
| 2827 with MCP-867 (POSF-3041) at 300 mg/L | 69 |
| 2827 with MCP-873 (POSF-2733) at 300 mg/L | 98 |
| 2827 with MCP-880 (POSF-3046) at 300 mg/L | 69 |
| 2827 with MCP-902 (POSF-3038) at 300 mg/L | 52 |
| 2827 with MCP-1020 (POSF-2735) at 300 mg/L | 80 |
| 2827 with MCP-1025 (POSF-2732) at 300 mg/L | 3 |
| 2827 with MCP-1395 (POSF-3042) at 300 mg/L | 0 |
| 2827 with MCP-1408B (POSF-2940) at 300 mg/L | 63 |
| 2827 with MCP-1409B (POSF-2943) at 300 mg/L | 26 |
| 2827 with MCP-1411 (POSF-2950) at 300 mg/L | 21 |
| 2827 with MCP-1412 (POSF-2945) at 300 mg/L | 85 |
| 2827 with MCP-1412B (POSF-2949) at 300 mg/L | 76 |
| 2827 with MCP-1413 (POSF-2946) at 300 mg/L | 10 |
| 2827 with MCP-1413B (POSF-2947) at 300 mg/L | 115 |
| 2827 with RT-1694E (POSF-2730) at 300 mg/L | 69 |
| 2827 with RT-1912 (POSF-2731) at 300 mg/L | 37 |
| 2827 with RT-1928A (POSF-2728) at 300 mg/L | 37 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2926 with MCP-1020 at 300 mg/L | 148 |
| 2926 with MCP-1025 at 300 mg/L | 129 |
| 2926 with MCP-147B at 300 mg/L | 10 |
| 2926 with RT-1912 at 300 mg/L | 128 |
| 2926 with MCP-1413 at 300 mg/L | 14 |
| 2926 with MCP-1020 and 8Q405 at 300 and 100 mg/L | 80 |
| 2926 with MCP-1025 and 8Q405 at 300 and 100 mg/L | 5 |
| 2926 with MCP-147B and 8Q405 at 300 and 100 mg/L | 2 |
| 2926 with RT-1912 and 8Q405 at 300 and 100 mg/L | 83 |
| 2922 with MCP-1020 at 300 mg/L | 124 |
| 2922 with MCP-1025 at 300 mg/L | 159 |
| 2922 with MCP-147B at 300 mg/L | 145 |
| 2922 with RT-1912 at 300 mg/L | 143 |
| 2922 with MCP-1413 at 300 mg/L | 200 |
| 2922 with MCP-1020 and 8Q405 at 300 and 100 mg/L | 144 |
| 2922 with MCP-1025 and 8Q405 at 300 and 100 mg/L | 34 |
| 2922 with MCP-147B and 8Q405 at 300 and 100 mg/L | 76 |
| 2922 with RT-1912 and 8Q405 at 300 and 100 mg/L | 192 |
| 2980 with MCP-1020 at 300 mg/L | 179 |
| 2980 with MCP-1025 at 300 mg/L | 10 |
| 2980 with MCP-147B at 300 mg/L | 39 |
| 2980 with RT-1912 at 300 mg/L | 109 |
| 2980 with MCP-1413 at 300 mg/L | 5 |
| 2980 with MCP-1020 and 8Q405 at 300 and 100 mg/L | 151 |
| 2980 with MCP-1025 and 8Q405 at 300 and 100 mg/L | 5 |
| 2980 with MCP-147B and 8Q405 at 300 and 100 mg/L | 2 |
| 2980 with RT-1912 and 8Q405 at 300 and 100 mg/L | 76 |
| 2827 with TFA-4650 (POSF-2957) at 0.006% volume | 27 |
| 2827 with TFA-4681 (POSF-2958) at 0.019% weight | 91 |
| 2922 with TFA-4650 at 0.006% volume | 116 |
| 2922 with TFA-4681 at 0.019% weight | 148 |
| 2934 with TFA-4650 at 0.006% volume | 85 |
| 2934 with TFA-4681 at 0.019% weight | 80 |
| 2747 with JFA-5 at 12 mg/L | 11 |
| 2827 with JFA-5 at 12 mg/L | 22 |
| 2922 with JFA-5 at 12 mg/L | 170 |
| 2926 with JFA-5 at 12 mg/L | 89 |
| 2928 with JFA-5 at 12 mg/L | 151 |
| 2934 with JFA-5 at 12 mg/L | 129 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2936 with JFA-5 at 12 mg/L | 164 |
| 2959 with JFA-5 at 12 mg/L | 7 |
| 2963 with JFA-5 at 12 mg/L | 420 |
| 2980 with JFA-5 at 12 mg/L | 20 |
| 2985 with JFA-5 at 12 mg/L | 790 |
| 2827 with Diegme at 0.15% volume | 168 |
| 2827 with Stadis 450 at 2 mg/L | 57 |
| 2827 with DCI-4A at 9 mg/L | 23 |
| 2827 with Diegme, Stadis 450 and DCI-4A (JP-8 additives) | 142 |
| 2922 with Diegme, Stadis 450 and DCI-4A (JP-8 additives) | 124 |
| 2926 with Diegme, Stadis 450 and DCI-4A (JP-8 additives) | 144 |
| 2980 with Diegme, Stadis 450 and DCI-4A (JP-8 additives) | 198 |
| 2827 with JP-8 additives and 8Q405 at 100 mg/L | 106 |
| 2922 with JP-8 additives and 8Q405 at 100 mg/L | 136 |
| 2926 with JP-8 additives and 8Q405 at 100 mg/L | 95 |
| 2980 with JP-8 additives and 8Q405 at 100 mg/L | 33 |
| 2827 with JP-8 additives, 8Q405 and BHT at 100 and 25 mg/L | 6 |
| 2922 with JP-8 additives, 8Q405 and BHT at 100 and 25 mg/L | 100 |
| 2926 with JP-8 additives, 8Q405 and BHT at 100 and 25 mg/L | 5 |
| 2980 with JP-8 additives, 8Q405 and BHT at 100 and 25 mg/L | 5 |
| 2827 with 8Q405 and MCP-477 at 100 and 300 mg/L | 2 |
| 2922 with 8Q405 and MCP-477 at 100 and 300 mg/L | 55 |
| 2926 with 8Q405 and MCP-477 at 100 and 300 mg/L | 66 |
| 2928 with 8Q405 and MCP-477 at 100 and 300 mg/L | 53 |
| 2934 with 8Q405 and MCP-477 at 100 and 300 mg/L | 0 |
| 2936 with 8Q405 and MCP-477 at 100 and 300 mg/L | 6 |
| 2959 with 8Q405 and MCP-477 at 100 and 300 mg/L | 3 |
| 2963 with 8Q405 and MCP-477 at 100 and 300 mg/L | 143 |
| 2980 with 8Q405 and MCP-477 at 100 and 300 mg/L | 0 |
| 2827 with 8Q405 and MCP-477 at 50 and 150 mg/L | 103 |
| 2922 with 8Q405 and MCP-477 at 50 and 150 mg/L | 92 |
| 2926 with 8Q405 and MCP-477 at 50 and 150 mg/L | 90 |
| 2928 with 8Q405 and MCP-477 at 50 and 150 mg/L | 94 |
| 2934 with 8Q405 and MCP-477 at 50 and 150 mg/L | 6 |
| 2936 with 8Q405 and MCP-477 at 50 and 150 mg/L | 22 |
| 2959 with 8Q405 and MCP-477 at 50 and 150 mg/L | 21 |
| 2827 with 8Q405 and MCP-477 at 100 and 150 mg/L | 10 |
| 2922 with 8Q405 and MCP-477 at 100 and 150 mg/L | 138 |
| 2926 with 8Q405 and MCP-477 at 100 and 150 mg/L | 3 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2928 with 8Q405 and MCP-477 at 100 and 150 mg/L | 15 |
| 2934 with 8Q405 and MCP-477 at 100 and 150 mg/L | 90 |
| 2936 with 8Q405 and MCP-477 at 100 and 150 mg/L | 89 |
| 2959 with 8Q405 and MCP-477 at 100 and 150 mg/L | 3 |
| 2959 with 8Q405 and MCP-477 at 100 and 75 mg/L | 7 |
| 2827 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 3 |
| 2922 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 162 |
| 2926 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 60 |
| 2928 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 43 |
| 2934 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 2 |
| 2936 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 18 |
| 2959 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 2 |
| 2963 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 131 |
| 2980 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 7 |
| 2981 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 7 |
| 2985 with 8Q405, MCP-477 and BHT at 100, 300 and 25 mg/L | 777 |
| 2827 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 0 |
| 2922 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 110 |
| 2926 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 0 |
| 2928 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 46 |
| 2934 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 325 |
| 2936 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 0 |
| 2959 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 0 |
| 2963 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 27 |
| 2980 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 0 |
| 2985 with 8Q405, MDA and BHT at 100, 10 and 25 mg/L | 771 |
| 2827 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2922 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 168 |
| 2926 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2928 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 16 |
| 2934 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 385 |
| 2936 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2959 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2963 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 337 |
| 2980 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2985 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 754 |
| 2827 with MCP-147B, MDA and BHT at 100, 10 and 25 mg/L | 2 |
| 2922 with MCP-147B, MDA and BHT at 100, 10 and 25 mg/L | 132 |
| 2926 with MCP-147B, MDA and BHT at 100, 10 and 25 mg/L | 16 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2959 with MCP-147B, MDA and BHT at 300, 10 and 25 mg/L | 0 |
| 2990 | 306 |
| 2991 | 262 |
| 2992 | 153 |
| 2993 | 77 |
| 2994 | 348 |
| 2995 | 70 |
| 2999 | 47 |
| 3000 | 386 |
| 3001 | 172 |
| 3002 | 893 |
| 3019 | 658 |
| 3020 | 94 |
| 3029 | 255 |
| 3030 | 175 |
| 3031 | 445 |
| 3036 | 142 |
| 3037 | 81 |
| 3047 | 124 |
| 3048 | 645 |
| 3049 | 4 |
| 3061 | 177 |
| 3062 | 250 |
| 3082 | 34 |
| 3083 | 107 |
| 3102 | 817 |
| 3108 | 184 |
| 3109 | 111 |
| 3110 | 172 |
| 2990 with 8Q405 and BHT at 100 and 25 mg/L | 138 |
| 2990 with 8Q405 and BHT at 100 and 25 mg/L | 150 |
| 2991 with 8Q405 and BHT at 100 and 25 mg/L | 242 |
| 2991 with 8Q405 and BHT at 100 and 25 mg/L | 165 |
| 2992 with 8Q405 and BHT at 100 and 25 mg/L | 104 |
| 2993 with 8Q405 and BHT at 100 and 25 mg/L | 22 |
| 2994 with 8Q405 and BHT at 100 and 25 mg/L | 67 |
| 2995 with 8Q405 and BHT at 100 and 25 mg/L | 33 |
| 2999 with 8Q405 and BHT at 100 and 25 mg/L | 32 |
| 3000 with 8Q405 and BHT at 100 and 25 mg/L | 172 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 3001 with 8Q405 and BHT at 100 and 25 mg/L | 91 |
| 3002 with 8Q405 and BHT at 100 and 25 mg/L | 1120 |
| 3019 with 8Q405 and BHT at 100 and 25 mg/L | 534 |
| 3020 with 8Q405 and BHT at 100 and 25 mg/L | 52 |
| 3029 with 8Q405 and BHT at 100 and 25 mg/L | 162 |
| 3030 with 8Q405 and BHT at 100 and 25 mg/L | 51 |
| 3031 with 8Q405 and BHT at 100 and 25 mg/L | 217 |
| 3036 with 8Q405 and BHT at 100 and 25 mg/L | 51 |
| 3037 with 8Q405 and BHT at 100 and 25 mg/L | 105 |
| 3047 with 8Q405 and BHT at 100 and 25 mg/L | 44 |
| 3048 with 8Q405 and BHT at 100 and 25 mg/L | 846 |
| 3049 with 8Q405 and BHT at 100 and 25 mg/L | 0 |
| 3061 with 8Q405 and BHT at 100 and 25 mg/L | 115 |
| 3062 with 8Q405 and BHT at 100 and 25 mg/L | 62 |
| 3082 with 8Q405 and BHT at 100 and 25 mg/L | 24 |
| 3083 with 8Q405 and BHT at 100 and 25 mg/L | 56 |
| 3102 with 8Q405 and BHT at 100 and 25 mg/L | 722 |
| 3108 with 8Q405 and BHT at 100 and 25 mg/L | 55 |
| 3109 with 8Q405 and BHT at 100 and 25 mg/L | 98 |
| 3110 with 8Q405 and BHT at 100 and 25 mg/L | 55 |
| 2990 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 7 |
| 2991 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 3 |
| 2992 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 94 |
| 2993 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 2994 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 2995 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 67 |
| 2999 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 4 |
| 3000 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 3 |
| 3001 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 0 |
| 3002 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 330 |
| 3019 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 181 |
| 3020 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 12 |
| 3029 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3030 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3031 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 7 |
| 3036 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3037 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 18 |
| 3047 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3048 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 93 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 3049 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 0 |
| 3061 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 8 |
| 3062 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3082 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 2 |
| 3083 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 3 |
| 3102 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 117 |
| 3108 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 1 |
| 3109 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 87 |
| 3110 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 55 |
| 2990 with MCP-147B and BHT at 300 and 25 mg/L | 264 |
| 2991 with MCP-147B and BHT at 300 and 25 mg/L | 248 |
| 2990 with MCP-147B, BHT and MDA at 300, 25 and 10 mg/L | 5 |
| 2991 with MCP-147B, BHT and MDA at 300, 25 and 10 mg/L | 5 |
| 3037 with MCP-147B and BHT at 300 and 25 mg/L | 251 |
| 3048 with MCP-147B and BHT at 300 and 25 mg/L | 583 |
| 3056 | 190 |
| 2922 with MCP-1395 and BHT at 300 and 25 mg/L | 0 |
| 2926 with MCP-1395 and BHT at 300 and 25 mg/L | 126 |
| 2985 with MCP-1395 and BHT at 300 and 25 mg/L | 830 |
| 2827 with SDA-722-1 (POSF-3063) | 195 |
| 2827 with SDA-722-2 (POSF-3064) | 59 |
| 2827 with SDA-722-3 (POSF-3065) | 74 |
| 2827 with SDA-722-4 (POSF-3066) | 286 |
| 3011 | 486 |
| 3012 | 707 |
| 3056 with 8Q405 and BHT at 100 and 25 mg/L | 39 |
| 3056 with MCP-147B and BHT at 300 and 25 mg/L | 140 |
| 2827 with POSF-3054 at 100 mg/L | 68 |
| 2827 with POSF-3055 at 100 mg/L | 33 |
| 3056 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 26 |
| 3056 with MCP-147B, BHT and MDA at 300, 25 and 10 mg/L | 5 |
| 3067 | 263 |
| 3067 | 284 |
| 2980 with 50 ppb copper | 361 |
| 2980 with 40 ppb copper | 202 |
| 2980 with 30 ppb copper | 245 |
| 2980 with 20 ppb copper | 155 |
| 2980 with 10 ppb copper | 114 |
| 2990 with MDA at 10 mg/L | 20 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2827 with PL-1707 (POSF-3068) at 125 mg/L | 10 |
| 2827 with PL-1708 (POSF-3069) at 112.5 mg/L | 12 |
| 2827 with PL-1709 (POSF-3070) at 392 mg/L | 4 |
| 2827 with PL-1710 (POSF-3071) at 87 mg/L | 4 |
| 2827 with PL-1711 (POSF-3072) at 235 mg/L | 4 |
| 2827 with PL-1712 (POSF-3073) at 308 mg/L | 4 |
| 2827 with PL-1713 (POSF-3074) at 125 mg/L | 36 |
| 2827 with PL-1714 (POSF-3075) at 123 mg/L | 35 |
| 2827 with PL-1715 (POSF-3076) at 135 mg/L | 4 |
| 2980 with PL-1709 (POSF-3070) at 392 mg/L | 11 |
| 2980 with PL-1710 (POSF-3071) at 87 mg/L | 15 |
| 2980 with PL-1711 (POSF-3072) at 235 mg/L | 10 |
| 2980 with PL-1712 (POSF-3073) at 308 mg/L | 8 |
| 2980 with PL-1715 (POSF-3076) at 135 mg/L | 12 |
| 2926 with PL-1709 (POSF-3070) at 392 mg/L | 7 |
| 2926 with PL-1710 (POSF-3071) at 87 mg/L | 20 |
| 2827 with MCP-1309 (POSF-3077) at 300 mg/L | 0 |
| 2827 with MCP-1521 (POSF-3078) at 300 mg/L | 0 |
| 2980 with MCP-1309 at 300 mg/L | 0 |
| 2980 with MCP-1521 at 300 mg/L | 0 |
| 2985 with MCP-1309 and BHT at 300 and 25 mg/L | 855 |
| 2985 with MCP-1521 and BHT at 300 and 25 mg/L | 800 |
| 2827 with POSF-3095 at 27 mL/L | 5 |
| 2827 with POSF-3091 at 27 mL/L | 4 |
| 2827 with POSF-3094 at 27 mL/L | 4 |
| 2827 with 8Q405-1591 at 100 mg/L | 1 |
| 2827 with 8Q405-1641 at 100 mg/L | 18 |
| 2827 with 8Q405-1671 at 100 mg/L | 6 |
| 2827 with 8Q405-1571 at 100 mg/L | 9 |
| 2827 with 8Q405-1621 at 100 mg/L | 8 |
| 2827 with 8Q405-1651 at 100 mg/L | 40 |
| 2827 with POSF-3090 at 27 mL/L | 3 |
| 2827 with POSF-3091 at 27 mL/L | 4 |
| 2827 with POSF-3092 at 27 mL/L | 40 |
| 2827 with POSF-3093 at 27 mL/L | 7 |
| 2827 with POSF-3094 at 27 mL/L | 4 |
| 2827 with POSF-3095 at 27 mL/L | 5 |
| 2827 with POSF-3096 at 27 mL/L | 2 |
| 2827 with POSF-3097 at 27 mL/L | 14 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2827 with 8Q406 at 125 mg/L | 18 |
| 2980 with 8Q406 at 125 mg/L | 6 |
| 2926 with 8Q406 at 125 mg/L | 48 |
| 2827 solid phase extracted | 178 |
| 2827 solid phase extracted | 190 |
| 2827 | 53 |
| 2980 with 8Q405-1591 and BHT at 100 and 25 mg/L | 2 |
| 2926 with 8Q405-1591 and BHT at 100 and 25 mg/L | 10 |
| 2827 with 8Q405-1591 and BHT at 100 and 25 mg/L | 6 |
| 2827 with VX-4013 (POSF-3086) at 25 mg/L | 32 |
| 2827 with VX-4973 (POSF-3088) at 25 mg/L | 70 |
| 2827 with VX-4139 (POSF-3087) at 25 mg/L | 53 |
| 2827 with PL-1707 (POSF-3068) at 125 mg/L | 4 |
| 2827 with PL-1709 (POSF-3070) at 392 mg/L | 2 |
| 2827 with PL-1710 (POSF-3071) at 87 mg/L | 2 |
| 2827 with PL-1713 (POSF-3074) at 125 mg/L | 47 |
| 2827 with MCP-1521 (POSF-3078) at 150 mg/L | 2 |
| 2980 with PL-1712 (POSF-3073) at 308 mg/L | 2 |
| 3098 | 0 |
| 3099 | 120 |
| 3100 | 103 |
| 3101 | 111 |
| 3098 with 8Q405 and 8Q203 at 100 and 70 mg/L | 0 |
| 3098 with 8Q405 and BHT at 100 and 25 mg/L | 0 |
| 2827 with ILFC 1002 (POSF-3107) at 125 mg/L | 20 |
| 2926 with PL-1709 (POSF-3070) at 392 mg/L | 7 |
| 2926 with PL-1710 (POSF-3071) at 87 mg/L | 20 |
| 2926 with MCP-1521 (POSF-3078) at 150 mg/L | 15 |
| 2980 with MCP-1521 at 150 mg/L | 2 |
| 2962 | 179 |
| 2962 with 8Q405 and BHT at 100 and 25 mg/L | 84 |
| 2962 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 7 |
| 2962 with 8Q405, BHT and MDA at 100, 25 and 5 mg/L | 11 |
| 2962 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 23 |
| 2963 | 300 |
| 2963 with 8Q405 and BHT at 100 and 25 mg/L | 158 |
| 2963 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 52 |
| 2963 with 8Q405, BHT and MDA at 100, 25 and 5 mg/L | 50 |
| 2963 with 8Q405, BHT and MDA at 100, 25 and 10 mg/L | 20 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2934 | 48 |
| 2827 with POSF-3111 at 144 mg/L | 6 |
| 2827 with POSF-3112 at 135 mg/L | 4 |
| 2827 with POSF-3113 at 160 mg/L | 10 |
| 2827 | 67 |
| 2827 with POSF-3114 at 160 mg/L | 16 |
| 2827 with POSF-3115 at 160 mg/L | 10 |
| 2827 with POSF-3116 at 145 mg/L | 45 |
| 2827 with POSF-3117 at 135 mg/L | 15 |
| 2827 with MCP-1521, BHT and MDA at 150, 25 and 2 mg/L | 3 |
| 2926 with MCP-1521, BHT and MDA at 150, 25 and 2 mg/L | 12 |
| 2980 with MCP-1521, BHT and MDA at 150, 25 and 2 mg/L | 6 |
| 2962 with 8Q406 at 125 mg/L | 172 |
| 3084 | 55 |
| 3084 with 8Q405 and BHT at 100 and 25 mg/L | 53 |
| 3110 | 172 |
| 3109 | 111 |
| 3108 | 184 |
| 3102 | 817 |
| 3083 | 107 |
| 3084 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 7 |
| 3082 with 8Q405 and BHT at 100 and 25 mg/L | 24 |
| 3083 with 8Q405 and BHT at 100 and 25 mg/L | 56 |
| 3102 with 8Q405 and BHT at 100 and 25 mg/L | 722 |
| 3108 with 8Q405 and BHT at 100 and 25 mg/L | 55 |
| 3109 with 8Q405 and BHT at 100 and 25 mg/L | 98 |
| 3110 with 8Q405 and BHT at 100 and 25 mg/L | 55 |
| 3082 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 2 |
| 3083 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 3 |
| 3102 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 117 |
| 3108 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 1 |
| 3109 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 87 |
| 3110 with 8Q405, BHT and MDA at 100, 25 and 2 mg/L | 55 |
| 2827 with MCP-147B, BHT and MDA at 150, 25 and 2 mg/L | 4 |
| 2926 with MCP-147B, BHT and MDA at 150, 25 and 2 mg/L | 10 |
| 2980 with MCP-147B, BHT and MDA at 150, 25 and 2 mg/L | 5 |
| 3082 with MCP-147B, BHT and MDA at 150, 25 and 2 mg/L | 34 |
| 2926 with POSF-3096 at 5 mL/L | 47 |
| 2980 with POSF-3096 at 5 mL/L | 83 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 2926 with POSF-3096 at 10 mL/L | 60 |
| 2926 with POSF-3096 at 20 mL/L | 4 |
| 2980 with POSF-3096 at 10 mL/L | 1 |
| 2980 with POSF-3096 at 20 mL/L | 1 |
| 2926 with POSF-3096 at 27 mL/L | 9 |
| 2980 with POSF-3096 at 27 mL/L | 3 |
| 3119 | 55 |
| 3123 | 85 |
| 3122 | 81 |
| 2827 with Mobile Blend 2 at 437.5 mg/L | 23 |
| 2827 with Mobile Blend 3 at 500 mg/L | 5 |
| 2827 with POSF-3124 at 160 mg/L | 4 |
| 2827 with POSF-3125 at 160 mg/L | 66 |
| 2827 with POSF-3126 at 160 mg/L | 70 |
| 2827 with POSF-3127 at 160 mg/L | 50 |
| 2827 with POSF-3128 at 190 mg/L | 25 |
| 2827 with POSF-3129 at 190 mg/L | 1 |
| 3131 | 90 |
| 3132 | 102 |
| 3134 | 58 |
| 3135 | 71 |
| 3139 | 230 |
| 2926 with POSF-3124 at 160 mg/L | 34 |
| 2926 with POSF-3129 at 160 mg/L | 27 |
| 3084 with POSF-3124 at 160 mg/L | 37 |
| 3084 with POSF-3129 at 160 mg/L | 8 |
| 2747 with MCP-1750 at 438 mg/L | 0 |
| 2747 with MCP-1750 and 8Q406 at 220 and 65 mg/L | 0 |
| 2827 with MCP-1750 at 438 mg/L | 10 |
| 3119 with MCP-1750 at 438 mg/L | 31 |
| 2747 with 8Q406 at 125 mg/L | 0 |
| 2827 with 8Q406 at 125 mg/L | 30 |
| 3119 with 8Q406 at 125 mg/L | 54 |
| 2827 with 8Q406 and MCP-1750 at 65 and 220 mg/L | 14 |
| 3119 with 8Q406 and MCP-1750 at 65 and 220 mg/L | 34 |
| 3145 with 8Q406 at 125 mg/L | 700 |
| 3145 with 8Q406 and MDA at 125 and 2 mg/L | 410 |
| 3145 | 831 |
| 2827 with POSF-3154 at 190 mg/L | 3 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2827 with POSF-3155 at 190 mg/L | 5 |
| 2827 with POSF-3156 at 190 mg/L | 5 |
| 2827 with POSF-3157 at 190 mg/L | 0 |
| 2827 with 8Q460 at 127 mg/L | 3 |
| 2827 with POSF-3177 at 100 mg/L | 26 |
| 2827 with POSF-3172 at 125 mg/L | 24 |
| 2827 with POSF-3171 at 125 mg/L | 24 |
| 2827 with POSF-3180 at 120 mg/L | 110 |
| 2827 with POSF-3181 at 120 mg/L | 76 |
| 2827 with POSF-3182 at 150 mg/L | 10 |
| 2827 with POSF-3183 at 120 mg/L | 39 |
| 2827 with POSF-3184 at 120 mg/L | 58 |
| 2827 with POSF-3185 at 120 mg/L | 53 |
| 2827 with POSF-3186 at 100 mg/L | 102 |
| 2827 with POSF-3187 at 100 mg/L | 12 |
| 2827 with POSF-3188 at 100 mg/L | 3 |
| 2827 with POSF-3189 at 120 mg/L | 7 |
| 2827 with POSF-3190 at 150 mg/L | 18 |
| 2827 with POSF-3191 at 150 mg/L | 13 |
| 2827 with PL-1733 (POSF-3192) at 100 mg/L | 49 |
| 2827 with PL-1734 (POSF-3193) at 100 mg/L | 72 |
| 2827 with PL-1735 (POSF-3194) at 100 mg/L | 63 |
| 2827 with PL-1736 (POSF-3195) at 100 mg/L | 50 |
| 2827 with PL-1737 (POSF-3196) at 100 mg/L | 60 |
| 2827 with PL-1738 (POSF-3197) at 100 mg/L | 43 |
| 2827 with PL-1739 (POSF-3198) at 100 mg/L | 74 |
| 2827 with PL-1740 (POSF-3199) at 100 mg/L | 6 |
| 2827 with PL-1741 (POSF-3200) at 100 mg/L | 68 |
| 2827 with PL-1742 (POSF-3201) at 100 mg/L | 70 |
| 2827 with VX-4973 (POSF-3088) at 125 mg/L | 94 |
| 2827 with NEL-75-38 (POSF-3203) at 125 mg/L | 50 |
| 2827 with NEL-75-37 (POSF-3202) at 150 mg/L | 4 |
| 2827 with POSF-3179 at 10 g/L | 116 |
| 2827 with 8Q405, MDA and AO#31 at 100, 2 and 25 mg/L | 1 |
| 3119 with POSF-3114, BHT and MDA at 160, 25 and 2 mg/L | 53 |
| 3119 with POSF-3114 and BHT at 160 and 25 mg/L | 50 |
| 2827 with POSF-3114, BHT and MDA at 160, 25 and 2 mg/L | 20 |
| 2827 with POSF-3114 and BHT at 160 and 25 mg/L | 19 |
| 2926 with POSF-3114 and BHT at 160 and 25 mg/L | 42 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2827 with POSF-3096, BHT and MDA at 627 mg/L | 10 |
| 2926 with POSF-3096, BHT and MDA at 627 mg/L | 16 |
| 3119 with POSF-3096, BHT and MDA at 627 mg/L | 59 |
| 2827 with POSF-3096 at 600 mg/L | 78 |
| 3119 with POSF-3096 at 600 mg/L | 81 |
| 2926 with POSF-3096 at 600 mg/L | 156 |
| 2926 with POSF-3114, BHT and MDA at 160, 25 and 2 mg/L | 53 |
| 2827 with POSF-3111, BHT and MDA at 144, 25 and 2 mg/L | 3 |
| 3119 with POSF-3111, BHT and MDA at 144, 25 and 2 mg/L | 60 |
| 2926 with POSF-3111, BHT and MDA at 144, 25 and 2 mg/L | 20 |
| 2926 with POSF-3096 at 627 mg/L | 156 |
| 2827 with POSF-3111 and BHT at 144 and 25 mg/L | 3 |
| 2926 with POSF-3111 and BHT at 144 and 25 mg/L | 72 |
| 3119 with POSF-3111 and BHT at 144 and 25 mg/L | 81 |
| 2926 with POSF-3171 at 125 mg/L | 72 |
| 3119 with POSF-3171 at 125 mg/L | 84 |
| 3229 | 6 |
| 3230 | 100 |
| 3232 | 100 |
| 3233 | 7 |
| 3234 | 90 |
| 3235 | 30 |
| 3119 | 65 |
| 3119 with PL-1740 (POSF-3199) at 100 mg/L | 75 |
| 3119 with PL-1740 and BHT at 100 and 25 mg/L | 90 |
| 3119 with PL-1740, BHT and MDA at 100, 25 and 2 mg/L | 53 |
| 3242 | 157 |
| 3243 | 41 |
| 2926 | 96 |
| 2926 with PL-1740 at 100 mg/L | 36 |
| 2926 with PL-1740 and BHT at 100 and 25 mg/L | 71 |
| 2926 with PL-1740, BHT and MDA at 100, 25 and 2 mg/L | 39 |
| 2827 | 140 |
| 2827 with PL-1740 and BHT at 100 and 25 mg/L | 50 |
| 2827 with PL-1740, BHT and MDA at 100, 25 and 2 mg/L | 5 |
| 2827 with POSF-3186 at 100 mg/L | 55 |
| 2827 with POSF-3237 at 165 mg/L | 21 |
| 2827 with POSF-3238 at 165 mg/L | 8 |
| 2827 with POSF-3239 at 165 mg/L | 1 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2827 with POSF-3241 at 165 mg/L | 10 |
| 2827 with 8Q462 at 256 mg/L | 8 |
| 2827 with POSF-3240 at 165 mg/L | 40 |
| 2827 with POSF-3182, BHT and MDA at 150, 25 and 2 mg/L | 1 |
| 2827 with POSF-3188, BHT and MDA at 150, 25 and 2 mg/L | 4 |
| 2827 with POSF-3190, BHT and MDA at 150, 25 and 2 mg/L | 2 |
| 2827 with POSF-3245 at 150 mg/L | 9 |
| 2827 with POSF-3246 at 150 mg/L | 41 |
| 2827 with POSF-3247 at 150 mg/L | 51 |
| 2827 with POSF-3248 at 150 mg/L | 45 |
| 2827 with POSF-3249 at 100 mg/L | 126 |
| 2926 with 8Q462 at 256 mg/L | 22 |
| 3119 with 8Q462 at 256 mg/L | 63 |
| 2926 with POSF-3157 at 190 mg/L | 93 |
| 3084 with POSF-3157 at 190 mg/L | 61 |
| 3119 with POSF-3157 at 190 mg/L | 34 |
| 3084 | 86 |
| 2827 with POSF-3171, BHT and MDA at 125, 25 and 2 mg/L | 8 |
| 2926 with POSF-3171, BHT and MDA at 125, 25 and 2 mg/L | 60 |
| 3119 with POSF-3202 at 150 mg/L | 67 |
| 3259 | 192 |
| 3260 | 105 |
| 3261 | 91 |
| 3265 | 134 |
| 3266 | 136 |
| 3267 | 158 |
| 3268 | 221 |
| 3119 with POSF-3171, BHT and MDA at 125, 25 and 2 mg/L | 79 |
| 2926 with POSF-3202 at 150 mg/L | 10 |
| 2827 with 8Q405, MDA and AO#24 at 100, 2 and 10 mg/L | 20 |
| 2926 with 8Q405, MDA and AO#24 at 100, 2 and 10 mg/L | 43 |
| 3084 with 8Q405, MDA and AO#24 at 100, 2 and 10 mg/L | 28 |
| 3119 with 8Q405, MDA and AO#24 at 100, 2 and 10 mg/L | 54 |
| 2827 with MCP-1750B at 962 mg/L | 2 |
| 2926 with MCP-1750B at 962 mg/L | 6 |
| 3119 with MCP-1750B at 962 mg/L | 4 |
| 3084 with MCP-1750B at 962 mg/L | 3 |
| 2827 with MCP-1750C at 505 mg/L | 4 |
| 2926 with MCP-1750C at 505 mg/L | 69 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 3119 with MCP-1750C at 505 mg/L | 61 |
| 3084 with MCP-1750C at 505 mg/L | 7 |
| 2827 with POSF-3244 at 1.0 weight % | 93 |
| 2827 with POSF-3262 at 0.6 weight % | 193 |
| 2827 with POSF-3263 at 160 mg/L | 7 |
| 2827 with POSF-3182, AO#24 and MDA at 150, 10 and 2 mg/L | 7 |
| 2827 with POSF-3188, AO#24 and MDA at 100, 10 and 2 mg/L | 15 |
| 2827 with POSF-3190, AO#24 and MDA at 150, 10 and 2 mg/L | 5 |
| 2926 with POSF-3245 at 150 mg/L | 65 |
| 3084 with POSF-3245 at 150 mg/L | 57 |
| 3119 with POSF-3245 at 150 mg/L | 83 |
| 3272 | 253 |
| 3273 | 114 |
| 3284 | 171 |
| 3278 | 88 |
| 3279 | 359 |
| 3280 | 270 |
| 3281 | 213 |
| 2926 with POSF-3263 at 160 mg/L | 54 |
| 3084 with POSF-3263 at 160 mg/L | 52 |
| 3119 with POSF-3263 at 160 mg/L | 92 |
| 2827 with PL-1746 (POSF-3270) at 293 mg/L | 10 |
| 2827 with PL-1747 (POSF-3271) at 458 mg/L | 7 |
| 3182 with 8Q462 at 256 mg/L | 3 |
| 2926 with POSF-3182 at 150 mg/L | 15 |
| 2926 with POSF-3188 at 100 mg/L | 47 |
| 2926 with POSF-3190 at 150 mg/L | 11 |
| 3084 with POSF-3182 at 150 mg/L | 33 |
| 3084 with POSF-3188 at 100 mg/L | 40 |
| 3084 with POSF-3190 at 150 mg/L | 3 |
| 3119 with POSF-3182 at 150 mg/L | 8 |
| 3119 with POSF-3188 at 100 mg/L | 5 |
| 3119 with POSF-3190 at 150 mg/L | 4 |
| 2926 with POSF-3239 at 165 mg/L | 44 |
| 3119 with POSF-3239 at 165 mg/L | 43 |
| 3084 with POSF-3239 at 165 mg/L | 31 |
| 2926 with POSF-3241 at 165 mg/L | 35 |
| 3119 with POSF-3241 at 165 mg/L | 7 |
| 3084 with POSF-3241 at 165 mg/L | 6 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 3285 | 200 |
| 3286 | 2 |
| 2827 with POSF-3274 at 236 mg/L | 23 |
| 2827 with POSF-3275 at 251 mg/L | 25 |
| 2827 with POSF-3276 at 256 mg/L | 10 |
| 2827 with POSF-3177 at 100 mg/L | 93 |
| 2827 with POSF-3291 at 160 mg/L | 13 |
| 2827 with POSF-3292 at 160 mg/L | 6 |
| 2827 with POSF-3293 at 180 mg/L | 87 |
| 2827 with POSF-3294 at 180 mg/L | 5 |
| 3119 | 82 |
| 3119 with POSF-3291 at 160 mg/L | 65 |
| 2827 | 30 |
| 3119 with POSF-3300 at 160 mg/L | 3 |
| 3119 with POSF-3301 at 160 mg/L | 3 |
| 3119 with POSF-3302 at 200 mg/L | 44 |
| 3119 with POSF-3303 at 200 mg/L | 8 |
| 2827 with POSF-3262 and 8Q462 at 0.6 weight % and 256 mg/L | 34 |
| 2827 with POSF-3304 at 100 mg/L | 190 |
| 2827 with POSF-3300 at 160 mg/L | 0 |
| 2926 with POSF-3300 at 160 mg/L | 13 |
| 3084 with POSF-3300 at 160 mg/L | 9 |
| 2827 with POSF-3301 at 160 mg/L | 5 |
| 2926 with POSF-3301 at 160 mg/L | 14 |
| 3084 with POSF-3301 at 160 mg/L | 1 |
| 2827 with POSF-3303 at 200 mg/L | 1 |
| 2926 with POSF-3303 at 200 mg/L | 12 |
| 3084 with POSF-3303 at 200 mg/L | 1 |
| 2827 with POSF-3306 at 26 mL/L | 0 |
| 2827 with POSF-3307 at 26 mL/L | 0 |
| 3119 with POSF-3295 at 327 mg/L | 9 |
| 2926 with PL-1747 (POSF-3271) at 458 mg/L | 4 |
| 3119 with PL-1747 (POSF-3271) at 458 mg/L | 3 |
| 2827 with POSF-3203, BHT and MDA at 125, 25 and 2 mg/L | 3 |
| 3119 with POSF-3292 at 160 mg/L | 0 |
| 3119 with POSF-3294 at 180 mg/L | 6 |
| 3119 with POSF-3171, BHT and MDA at 125, 25 and 2 mg/L | 1 |
| 3119 | 165 |
| 2827 | 52 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|--|----------------------|
| 2926 | 81 |
| 3322 | 78 |
| 3323 | 50 |
| 2827 | 74 |
| 2827 with POSF-3310 at 26 mL/L | 35 |
| 2827 with POSF-3311 at 26 mL/L | 99 |
| 2827 with POSF-3312 at 26 mL/L | 187 |
| 2827 with POSF-3313 at 26 mL/L | 111 |
| 2827 with POSF-3314 at 26 mL/L | 14 |
| 2827 with POSF-3315 at 26 mL/L | 12 |
| 2827 with POSF-3316 at 26 mL/L | 49 |
| 2827 with POSF-3317 at 26 mL/L | 28 |
| 2827 with POSF-3318 at 26 mL/L | 3 |
| 2827 with POSF-3319 at 26 mL/L | 51 |
| 2827 with POSF-3320 at 26 mL/L | 153 |
| 2827 with POSF-3321 at 26 mL/L | 57 |
| 2827 with POSF-3308 at 100 mg/L | 60 |
| 2827 with POSF-3309 at 100 mg/L | 14 |
| 3273 | 60 |
| 3272 | 179 |
| 3289 | 92 |
| 3288 | 92 |
| 3305A (Copper doped) | 368 |
| 2827 with POSF-3345 at 160 mg/L | 0 |
| 2827 with POSF-3346 at 160 mg/L | 2 |
| 2827 with POSF-3308, BHT and MDA at 100, 25 and 2 mg/L | 4 |
| 2827 with POSF-3309, BHT and MDA at 100, 25 and 2 mg/L | 3 |
| 3119 with POSF-3307 at 26 mL/L | 5 |
| 3119 with POSF-3271 at 458 mg/L | 0 |
| 2926 with POSF-3271 at 458 mg/L | 141 |
| 2926 with POSF-3308, BHT and MDA at 100, 25 and 2 mg/L | 37 |
| 2926 with POSF-3309, BHT and MDA at 100, 25 and 2 mg/L | 3 |
| 3119 with POSF-3308, BHT and MDA at 100, 25 and 2 mg/L | 53 |
| 3119 with POSF-3309, BHT and MDA at 100, 25 and 2 mg/L | 3 |
| 3350 | 8 |
| 3352 | 92 |
| 3322 | 197 |
| 2985 | 1398 |
| 3351 | 183 |

Table 2: List of ICOT Experiments (continued)

| Fuels and Additives | Solids (mg/L) |
|---|----------------------|
| 3352 | 147 |
| 3326 | 62 |
| 3353 | 56 |
| 3325 | 95 |
| 2976 | 46 |
| 2827 with POSF-3357 at 200 mg/L | 0 |
| 2827 with POSF-3358 at 200 mg/L | 1 |
| 2827 with POSF-3359 at 200 mg/L | 2 |
| 2827 with POSF-3360 at 200 mg/L | 4 |
| 2827 with POSF-3361 at 200 mg/L | 0 |
| 2827 with POSF-3362 at 200 mg/L | 0 |
| 2827 with POSF-3363 at 200 mg/L | 4 |
| 2827 with POSF-3365 at 200 mg/L | 3 |
| 2827 with POSF-3366 at 200 mg/L | 5 |
| 2827 with PL-1755 (POSF-3367) at 458 mg/L | 1 |
| 2827 with PL-1756 (POSF-3368) at 229 mg/L | 2 |
| 2827 with PL-1757 (POSF-3369) at 229 mg/L | 3 |
| 2827 with PL-1758 (POSF-3370) at 229 mg/L | 0 |
| 2827 with PL-1759 (POSF-3371) at 229 mg/L | 0 |
| 2827 with PL-1760 (POSF-3372) at 305 mg/L | 5 |
| 2827 with PL-1761 (POSF-3373) at 305 mg/L | 80 |
| 2827 with PL-1762 (POSF-3374) at 229 mg/L | 8 |
| 2827 with PL-1763 (POSF-3375) at 229 mg/L | 10 |
| 2827 with PL-1764 (POSF-3376) at 229 mg/L | 5 |
| 2827 with PL-1765 (POSF-3377) at 305 mg/L | 8 |
| 2827 with PL-1766 (POSF-3378) at 229 mg/L | 2 |
| 3352 | 72 |
| 3352 | 50 |
| 3392 | 26 |
| 3391 | 314 |
| 3296 | 105 |
| 3349 | 168 |
| 3328 | 247 |
| 3343 | 17 |
| 3342 | 198 |
| 3324 | 4 |
| 3389 | 386 |
| 3390 | 258 |
| 3397 | 3 |

4. PHOENIX RIG DATA

The Phoenix Rig was a flowing system developed by UDRI and used for the study of jet fuel thermal and oxidative stabilities (10). Fuel was pumped at relatively high pressure (up to 3.45 MPa) through stainless-steel tubing held within copper blocks that were used for both the heating and cooling of jet fuel. For heating, the copper blocks contained internal heating elements. For cooling, passages were machined within the copper blocks through which either water or air passed. Bulk fuel temperatures up to 625C and Reynolds numbers up to 11,000 could be attained. As found in actual aircraft, the oxygen availability was limited, and the oxygen concentration was measured at three different locations by gas chromatography. In addition, the mass of surface deposits were measured by carbon burnoff analysis. The Phoenix Rig was used for additive evaluation and fundamental studies of fuel oxidation and surface deposition. The capabilities of dissolved oxygen, deposition, and temperature measurement were extremely fruitful in the development of global (10-14) and pseudo-detailed chemical kinetic models (15, 16) for computational fluid dynamics simulations.

Several JP-8+100 additive candidates were tested using the Phoenix Rig (13, 17) with some results presented in a series of technical reports (18, 19). The Phoenix Rig was also used in the development of an on-line technique to measure dissolved oxygen concentration in a flowing system (20) and in the testing of coatings designed to reduce deposition.

Normal testing consisted of two general types of tests, deposition and oxygen consumption. Phoenix rig test name coding is described in Table 3. Table 4 contains a list of deposition experiments performed on the Phoenix Rig. The table lists the file code name, the fuel number, the flow rate, block temperature, test duration, sparge gas mixture, bulk outlet temperature, total carbon for the heating & cooling sections, additive names. Table 5 contains a list of oxygen experiments performed on the Phoenix Rig. The table lists the file code name, the fuel number & additive, the flow rate, block temperature, sparge gas mixture, bulk outlet temperature, and the amount of dissolved oxygen consumed.

Fuel and additive numbers (POSF codes) are assigned by the Fuels Branch of the Fuels and Lubrication Division of Wright Laboratory (WL/POSF), WPAFB, OH:

JP-8 additives here are DCI4A, Stadis 450, and DiEGME

DCI4A is a corrosion inhibitor/lubricity enhancer

Stadis 450 is a static charge inhibitor

DiEGME inhibits ice formation

Betz 8Q405 is a proprietary detergent-dispersant

Mobil 147B is a proprietary detergent-dispersant

BHT is an antioxidant

MDA is a metal deactivator

Mobil MCP-477 is a proprietary detergent

Table 3. Phoenix Rig Test Name Code

TEST TYPE: D = DEPOSITION TEST
O = OXYGEN DEPLETION TEST

FUEL IDENTIFICATION:
1 = POSF-2747 6 = POSF-2980
2 = POSF-2799 7 = POSF- 3119
3 = POSF-2827 8 = POSF-
4 = POSF-2926 9 = POSF-2976 (JPTS)
5 = POSF-2827 + DCI4A + S-450 + DiEGME

ADDITIVE IDENTIFICATION:
A = JP8 + M 147B + BHT + MDA H = JP8+BHT P = DCI4A+STADIS 450+DiEGME
B = JP8+8Q405+BHT+MDA J = JFA-5 Q =NA
C = 8Q405 + MCP477 + BHT. K=JP8+BHT+MDA R = Betz 8Q405 @ 100 mg/L
D = JP8 + 8Q405 + BHT . L =NA S = P+R= (JP8 + 8Q405)
E = ANTIOXIDANT "C" M = METAL DEACTIVATOR T = ANTIOXIDANT "A"
F = 8Q405 + BHT N = NONE
G = Triphenylphosphine O = ANTIOXIDANT "B"

TEST TEMPERATURE: 23 = 227 C
(DIVIDE TEMPERATURE 27 = 270 C
BY 10 AND ROUND OFF) 30 = 300 C
V = VARIABLE (AS IN OXYGEN DEPLETION TESTS)

TEST DURATION (HRS): 2 = 6 HOURS (DIVIDE HOURS BY 3
3 = 8 HOURS AND ROUND OFF)
4 = 12 HOURS
8 = 24 HOURS
OMIT FOR OXYGEN DEPLETION TEST

SPARGE GAS: A = AIR OR NITROGEN/OXYGEN EQUIVALENT
N = NITROGEN
P = PARTIAL OXYGEN

REPEAT TESTS: 1 = FIRST
2 = SECOND
3 = THIRD
ETC

EXAMPLES:
D1N574A3 O3JVA1
D = DEPOSITION TEST O = OXY. DEPLETION TEST
1 = FUEL POSF-2747 3 = FUEL POSF 2827
N = NO ADDITIVE J = ADDITIVE JFA-5
57 = 573 K TEST TEMPERATURE V = VARIABLE TEST TEMPERATURE
4 = 12 HOUR DURATION A = AIR SPARGE
A = AIR SPARGED 1 = FIRST TEST
3 = THIRD TEST OF THIS TYPE

This page intentionally left blank.

Table 4. Phoenix Rig Deposition Tests

| Test Name | Fuel | Flow Rate (ml/min) | Block Temp. C | Test Duration (hrs) | Purge Gas Mixture % Oxygen of Total Volume | Temp. C | Bulk Out Heated Section (micrograms) | Cooled Section Total Carbon (micrograms) | Additives* |
|-----------|----------|--------------------|---------------|---------------------|--|---------|--------------------------------------|--|------------|
| dlN542a4 | posf2747 | 16 | 270 | 6 | 21% | 237 | 1632 | 165 | NA |
| dlN542a5 | posf2747 | 16 | 270 | 6 | 21% | NA | 638 | 329 | NA |
| dlN572a2 | posf2747 | 16 | 300 | 6 | 21% | 272 | 1279 | 155 | NA |
| dlN572a3 | posf2747 | 16 | 300 | 6 | 21% | 272 | 998 | 99 | NA |
| dlN572a4 | posf2747 | 16 | 300 | 6 | 21% | NA | 701 | 163 | NA |
| dlN572p1 | posf2747 | 16 | 300 | 6 | 21% | 272 | 2548 | 110 | NA |
| dlN572p2 | posf2747 | 16 | 300 | 6 | 3% | 268 | 1952 | 90 | NA |
| dlN572p3 | posf2747 | 16 | 300 | 6 | 3% | 272 | 1338 | 137 | NA |
| dlN512a1 | posf2747 | 16 | 240 | 6 | AIR | 218 | 123 | 103 | NA |
| dlN512a2 | posf2747 | 4 | 240 | 6 | AIR | 224 | 118 | 107 | NA |
| dlN522a1 | posf2747 | 16 | 250 | 6 | AIR | 228 | 132 | 132 | NA |
| dlN542a6 | posf2747 | 16 | 270 | 6 | AIR | 245 | 163 | 146 | NA |
| dlN542a7 | posf2747 | 16 | 270 | 6 | AIR | 246 | 102 | 111 | NA |
| dlN562a1 | posf2747 | 16 | 285 | 6 | AIR | 258 | 150 | 120 | NA |
| dlN572a5 | posf2747 | 16 | 300 | 6 | AIR | 265 | 442 | 119 | NA |
| dlN572a6 | posf2747 | 16 | 300 | 6 | AIR | 271 | 221 | 95 | NA |
| d3N234a1 | posf2827 | 4 | 227 | 12 | AIR | 210 | 198 | 356 | NA |
| d3N234a2 | posf2827 | 4 | 227 | 12 | AIR | 201 | 204 | 222 | NA |
| d3N2716a | posf2827 | 32 | 270 | 48 | AIR | NA | 20400 | 63970 | NA |
| d3N272a1 | posf2827 | 16 | 270 | 6 | AIR | 245 | 659 | 2299 | NA |
| d3N272a2 | posf2827 | 16 | 270 | 6 | AIR | 251 | 751 | 1933 | NA |
| d3N272a3 | posf2827 | 16 | 270 | 6 | AIR | 247 | 767 | 2230 | NA |
| d3N302a1 | posf2827 | 16 | 300 | 6 | AIR | 277 | 2140 | 288 | NA |
| d3N302a2 | posf2827 | 16 | 300 | 6 | AIR | 237 | 3223 | 587 | NA |
| d3N302a3 | posf2827 | 16 | 300 | 6 | AIR | 255 | 3960 | 355 | NA |
| d3N302a4 | posf2827 | 16 | 300 | 6 | AIR | 276 | 2288 | 220 | NA |
| d3N302a5 | posf2827 | 16 | 300 | 6 | AIR | 275 | 2094 | 63 | NA |
| d3N302a6 | posf2827 | 16 | 300 | 6 | AIR | NA | 2152 | 96 | NA |
| d4N234a2 | posf2926 | 4 | 227 | 12 | AIR | 199 | 445 | 55 | NA |
| d4N234a3 | posf2926 | 4 | 227 | 12 | AIR | 199 | 470 | 70 | NA |
| d4N272a4 | posf2926 | 16 | 270 | 6 | AIR | 245 | 876 | 109 | NA |
| d4N302a4 | posf2926 | 16 | 300 | 6 | AIR | 282 | 1240 | 71 | NA |
| d4N302a5 | posf2926 | 16 | 300 | 6 | AIR | 277 | 1579 | 83 | NA |
| d4N504a1 | posf2926 | 4 | 227 | 12 | AIR | 205 | 326 | 91 | NA |
| d4N512a1 | posf2926 | 16 | 240 | 6 | AIR | 223 | 150 | 182 | NA |

Table 4. Phoenix Rig Deposition Tests

| Test Name | Fuel | Flow Rate (ml/min) | Block Temp. C | Test Duration (hrs) | Purge Gas Mixture % Oxygen of Total Volume | Bulk Out Heated Section Temp. C | Cooled Section Total Carbon (micrograms) | Additives* |
|-----------|----------|--------------------|---------------|---------------------|--|---------------------------------|--|------------|
| d4n512a2 | posf2926 | 4 | 240 | 6 | AIR | 226 | 270 | 105 |
| d4n522a1 | posf2926 | 16 | 250 | 6 | AIR | 231 | 216 | 167 |
| d4n542a1 | posf2926 | 16 | 270 | 6 | AIR | 246 | 427 | 117 |
| d4n562a1 | posf2926 | 16 | 285 | 6 | AIR | 255 | 793 | 75 |
| d4n572a1 | posf2926 | 16 | 300 | 6 | AIR | 275 | 695 | 106 |
| d4n572a2 | posf2926 | 16 | 300 | 6 | AIR | 275 | 1237 | 125 |
| d4n572a3 | posf2926 | 16 | 300 | 6 | AIR | 272 | 1004 | 149 |
| d4n572p1 | posf2926 | 16 | 300 | 6 | AIR | 273 | 666 | 108 |
| d4n572p2 | posf2926 | 16 | 300 | 6 | 6% | 275 | 537 | 207 |
| d4n572p3 | posf2926 | 16 | 300 | 6 | 3% | 272 | 388 | 102 |
| d9n234a1 | posf2976 | 4 | 227 | 12 | AIR | 199 | 137 | 109 |
| d9n272a1 | posf2976 | 16 | 270 | 6 | AIR | 253 | 68 | 56 |
| d9n302a1 | posf2976 | 16 | 300 | 6 | AIR | 282 | 95 | 75 |
| d6n224a1 | posf2980 | 4 | 220 | 12 | AIR | 199 | 411 | 174 |
| d6n302a1 | posf2980 | 16 | 300 | 6 | AIR | 275 | 1105 | 321 |
| d7n242a1 | posf3119 | 16 | 240 | 6 | AIR | 228 | 781 | 2476 |
| d7n242p1 | posf3119 | 16 | 240 | 6 | 8% | 224 | 536 | 910 |
| d7n242p2 | posf3119 | 16 | 240 | 6 | 4% | 228 | 745 | 470 |
| d7n272a1 | posf3119 | 16 | 270 | 6 | AIR | 255 | 1420 | 1673 |
| d7n272p1 | posf3119 | 16 | 270 | 6 | 8% | 247 | 1163 | 795 |
| d7n272p2 | posf3119 | 16 | 270 | 6 | 4% | NA | 1837 | 302 |
| d7n278a1 | posf3119 | 62 | 270 | 24 | AIR | 223 | 12395 | 7233 |
| d7n278p1 | posf3119 | 62 | 270 | 24 | 8% | NA | 14885 | 1176 |
| d7n282a1 | posf3119 | 16 | 285 | 6 | AIR | 246 | 2531 | 1538 |
| d7n282p1 | posf3119 | 16 | 285 | 6 | 8% | 250 | 2651 | 318 |
| d7n302a1 | posf3119 | 16 | 300 | 6 | AIR | 282 | 3893 | 482 |
| d7n302p1 | posf3119 | 16 | 300 | 6 | 8% | 277 | 2975 | 139 |
| d7n302p2 | posf3119 | 16 | 300 | 6 | 4% | NA | 2792 | 124 |
| d5a234a1 | posf2827 | 4 | 227 | 12 | AIR | 195 | 914 | 174 |
| d5a242a1 | posf2827 | 16 | 240 | 6 | AIR | 228 | 416 | 416 |
| d5a272a1 | posf2827 | 16 | 270 | 6 | AIR | 253 | 1050 | 171 |
| d5b234a1 | posf2827 | 4 | 227 | 12 | AIR | NA | 329 | 1136 |
| d5b242a1 | posf2827 | 16 | 240 | 6 | AIR | NA | 248 | 2104 |
| d5b272a1 | posf2827 | 16 | 270 | 6 | AIR | NA | 452 | 1403 |
| d5b278a1 | posf2827 | 62 | 270 | 24 | AIR | NA | 1357 | 8827 |

JP8 + MOBIL 147B + BHT + MDA
 JP8 + MOBIL 147B + BHT + MDA
 JP8 + MOBIL 147B + BHT + MDA
 JP8 + 8Q405 + BHT + MDA
 JP8 + 8Q405 + BHT + MDA
 JP8 + 8Q405 + BHT + MDA
 JP8 + 8Q405 + BHT + MDA

Table 4. Phoenix Rig Deposition Tests

| Test Name | Fuel | Flow Rate (ml/min) | Block Temp. C | Test Duration (hrs) | Purge Gas Mixturt % Oxygen of Total Volume | Bulk Out Heated Section Temp. C | Cooled Section Total Carbon (micrograms) | Additives* |
|-----------|----------|--------------------|---------------|---------------------|--|---------------------------------|--|---|
| d5b278p1 | posf2827 | 62 | 270 | 24 | 8% | NA | 977 | JP8 + 8Q405 + BHT + MDA |
| d5b278p2 | posf2827 | 62 | 270 | 24 | 4% | NA | 625 | JP8 + 8Q405 + BHT + MDA |
| d3c234a1 | posf2827 | 4 | 227 | 12 | AIR | 195 | 1564 | 8qQ405@100mg/L BHT@25mg/L MCP-477@300mg/L |
| d3c272a1 | posf2827 | 16 | 270 | 6 | AIR | 241 | 1985 | 8qQ405@100mg/L BHT@25mg/L MCP-477@300mg/L |
| d3c302a1 | posf2827 | 16 | 300 | 6 | AIR | 266 | 3638 | 8qQ405@100mg/L BHT@25mg/L MCP-477@300mg/L |
| d5p234a1 | posf2827 | 4 | 227 | 12 | AIR | 194 | 588 | JP8 ADDITIVES |
| d5p272a1 | posf2827 | 16 | 270 | 6 | AIR | 243 | 2131 | (DCI-4A, Stadis450, & DiEGME) |
| d5p302a1 | posf2827 | 16 | 300 | 6 | AIR | 276 | 5079 | (DCI-4A, Stadis450, & DiEGME) |
| d5p302a2 | posf2827 | 16 | 300 | 6 | AIR | 273 | 5353 | (DCI-4A, Stadis450, & DiEGME) |
| d3r234a1 | posf2827 | 4 | 227 | 12 | AIR | 193 | 148 | 8Q405 @ 100 ml/min |
| d3r272a1 | posf2827 | 16 | 270 | 6 | AIR | 246 | 302 | 8Q405 @ 100 ml/min |
| d3r302a1 | posf2827 | 16 | 300 | 6 | AIR | 273 | 796 | 8Q405 @ 100 ml/min |
| d3r302a2 | posf2827 | 16 | 300 | 6 | AIR | 270 | 720 | 8Q405 @ 100 ml/min |
| d5s234a1 | posf2827 | 4 | 227 | 12 | AIR | 189 | 205 | JP8 + 8Q405 @ 100 mg/L |
| d5s272a1 | posf2827 | 16 | 270 | 6 | AIR | 240 | 564 | JP8 + 8Q405 @ 100 mg/L |
| d5s302a1 | posf2827 | 16 | 300 | 6 | AIR | 266 | 1621 | JP8 + 8Q405 @ 100 mg/L |
| d5s302a2 | posf2827 | 16 | 300 | 6 | AIR | NA | 1476 | JP8 + 8Q405 @ 100 mg/L |
| d4f234a1 | posf2926 | 4 | 227 | 12 | AIR | 199 | 197 | 8Q405 @ 100 & BHT @ 25 mg/L |
| d4f272a1 | posf2926 | 16 | 270 | 6 | AIR | 241 | 265 | 8Q405 @ 100 & BHT @ 25 mg/L |
| d4f302a1 | posf2926 | 16 | 300 | 6 | AIR | 266 | 670 | 8Q405 @ 100 & BHT @ 25 mg/L |
| d4p234a1 | posf2926 | 4 | 227 | 12 | AIR | 190 | 922 | JP8 |
| d4p272a1 | posf2926 | 16 | 270 | 6 | AIR | 243 | 572 | JP8 |
| d4p302a1 | posf2926 | 16 | 300 | 6 | AIR | 277 | 1559 | JP8 |
| d4n302a4 | posf2926 | 16 | 300 | 6 | AIR | 282 | 1240 | NONE |
| d4n302a5 | posf2926 | 16 | 300 | 6 | AIR | 277 | 1579 | NONE |
| d4r234a1 | posf2926 | 4 | 227 | 12 | AIR | 202 | 162 | 8Q405 @ 100 mg/L |
| d4r272a1 | posf2926 | 16 | 270 | 6 | AIR | 250 | 305 | 8Q405 @ 100 mg/L |
| d4r302a1 | posf2926 | 16 | 300 | 6 | AIR | 271 | 554 | 8Q405 @ 100 mg/L |
| d4s234a1 | posf2926 | 4 | 227 | 12 | AIR | 185 | 312 | JP8 + 8Q405 @ 100 mg/L |
| d4s272a1 | posf2926 | 16 | 270 | 6 | AIR | 242 | 643 | JP8 + 8Q405 @ 100 mg/L |
| d4s302a1 | posf2926 | 16 | 300 | 6 | AIR | 271 | 1184 | JP8 + 8Q405 @ 100 mg/L |
| d9n278a1 | posf2976 | 62 | 270 | 24 | AIR | 213 | 214 | NONE |
| d9n278p1 | posf2976 | 62 | 270 | 24 | 8% | 211 | 137 | NONE |
| d6b278a1 | posf2980 | 62 | 270 | 24 | AIR | 206 | 1366 | JP8+8Q405+BHT+MDA |
| d6b278p1 | posf2980 | 62 | 270 | 24 | 8% | 205 | 1177 | JP8+8Q405+BHT+MDA |

Table 4. Phoenix Rig Deposition Tests

| Test Name | Fuel | Flow Rate (ml/min) | Block Temp. C | Test Duration (hrs) | Purge Gas Mixt _{ure} | % Oxygen of Total Volume | Temp. C | Total Carbon (micrograms) | Cooled Section Total Carbon (micrograms) | Additives* |
|-----------|----------|--------------------|---------------|---------------------|-------------------------------|--------------------------|---------|---------------------------|--|---|
| d6b278p2 | posf2980 | 62 | 270 | 24 | | 4% | 207 | 941 | 608 | JP8+8Q405+BHT+MDA |
| d6b278p3 | posf2980 | 62 | 270 | 24 | | 0% | 206 | 330 | 166 | JP8+8Q405+BHT+MDA |
| d6d234a1 | posf2980 | NA | 227 | 12 | | AIR | 206 | 330 | 166 | JP8 + 8Q405 + BHT |
| d6d234n1 | posf2980 | NA | 227 | 12 | | AIR | 209 | 93 | 55 | JP8+8Q405+BHT |
| d6d272a1 | posf2980 | 16 | 270 | 6 | | AIR | 250 | 785 | 109 | JP8 + 8Q405 + BHT |
| d6d302a1 | posf2980 | 16 | 300 | 6 | | AIR | 266 | 1660 | 83 | JP8 + 8Q405 + BHT |
| d6d228a2 | posf2980 | 4 | 220 | 24 | | AIR | 193 | 309 | 706 | JP8 + 8Q405 + BHT |
| d6d230a1 | posf2980 | 4 | 230 | 0.5 | | AIR | 195 | 181 | 87 | JP8 + BHT + 8Q405 |
| d6d231a1 | posf2980 | 4 | 230 | 3 | | AIR | 203 | 257 | 147 | JP8 + BHT + 8Q405 |
| d6d231a2 | posf2980 | 4 | 230 | 1.5 | | AIR | 203 | 216 | 141 | JP8 + BHT + 8Q405 |
| d6d232a1 | posf2980 | 4 | 230 | 6 | | AIR | 200 | 286 | 134 | JP8 + BHT + 8Q405 |
| d6d232a2 | posf2980 | 4 | 230 | 6 | | AIR | 200 | 288 | 278 | JP8 + BHT + 8Q405 |
| d6d234a2 | posf2980 | 4 | 230 | 12 | | AIR | 200 | 296 | 31 | JP8 + BHT + 8Q405 |
| d6d238a1 | posf2980 | 4 | 230 | 24 | | AIR | 203 | 388 | 1135 | JP8 + BHT + 8Q405 |
| d6d302a2 | posf2980 | 16 | 300 | 6 | | AIR | 273 | 1075 | 202 | JP8 FOR 3 HRS. & JP8 + BHT + 8Q405 FOR 3 HRS. |
| d6d302a3 | posf2980 | 16 | 300 | 6 | | AIR | 275 | 1347 | 156 | JP8 FOR 3 HRS. & JP8 + BHT + 8Q405 FOR 3 HRS. |
| d6p234a1 | posf2980 | 4 | 227 | 12 | | AIR | 200 | 1148 | 147 | JP8 |
| d6d272a1 | posf2980 | 16 | 270 | 6 | | AIR | 245 | 2239 | 202 | JP8 |
| d6d302a1 | posf2980 | 16 | 300 | 6 | | AIR | 276 | 2145 | 115 | JP8 |
| d6d302a2 | posf2980 | 16 | 300 | 6 | | AIR | 269 | 2351 | 169 | JP8 |
| d6p220a1 | posf2980 | 4 | 220 | 0.5 | | AIR | 190 | 311 | 143 | JP8 |
| d6p221a1 | posf2980 | 4 | 220 | 1.5 | | AIR | 194 | 156 | 118 | JP8 |
| d6p221a2 | posf2980 | 4 | 220 | 3 | | AIR | 196 | 520 | 172 | JP8 |
| d6p222a1 | posf2980 | 4 | 220 | 6 | | AIR | 197 | 491 | 213 | JP8 |
| d6p224a1 | posf2980 | 4 | 220 | 12 | | AIR | 190 | 670 | 217 | JP8 |
| d6p224a2 | posf2980 | 4 | 220 | 12 | | AIR | 193 | 849 | 227 | JP8 |
| d6p224a3 | posf2980 | 4 | 220 | 12 | | AIR | 193 | 887 | 288 | JP8 |
| d6p228a1 | posf2980 | 4 | 220 | 24 | | AIR | 189 | 2166 | 557 | JP8 |
| d6p234a3 | posf2980 | 4 | 227 | 12 | | AIR | 197 | 835 | 177 | JP8 |
| d6p278a1 | posf2980 | 62 | 270 | 24 | | AIR | 205 | 3640 | 871 | JP8 |
| d6p278a2 | posf2980 | 62 | 270 | 24 | | AIR | 204 | 3577 | 4744 | JP8 |
| d6p278a3 | posf2980 | 62 | 270 | 24 | | AIR | 206 | 1802 | 3837 | JP8 |
| d6p278p1 | posf2980 | 62 | 270 | 24 | | 8% | 209 | 4972 | 2976 | JP8 |
| d6p278p2 | posf2980 | 62 | 270 | 24 | | 1.50% | 205 | 6925 | 1253 | JP8 |
| d6p278p3 | posf2980 | 62 | 270 | 24 | | 0% | 206 | 351 | 183 | JP8 |

Table 4. Phoenix Rig Deposition Tests

| Test Name | Fuel | Flow Rate (ml/min) | Block Temp. C | Test Duration (hrs) | Purge Gas Mixt ure | % Oxygen of Total Volume | Temp. C | Total Carbon (micrograms) | Total Carbon (micrograms) | Additives* |
|-----------|----------|--------------------|---------------|---------------------|-------------------------------|--------------------------|---------|---------------------------|---------------------------|--|
| d6p278p4 | posf2980 | 62 | 270 | 24 | | 8% | 202 | 6128 | 243 | JP8 |
| d6p278p5 | posf2980 | 62 | 270 | 24 | | 0.50% | 203 | 5608 | 1395 | JP8 |
| d6p295a1 | posf2980 | 100 | 290 | 15 | | AIR | 181 | 2647 | 2018 | JP8 |
| d6p295p1 | posf2980 | 100 | 290 | 15 | | 8% | 184 | 5389 | 871 | JP8 |
| d6p295p2 | posf2980 | 100 | 290 | 15 | | 1.50% | 181 | 4543 | 542 | JP8 |
| d7b272a1 | posf3119 | 16 | 270 | 6 | | AIR | NA | 764 | 1840 | JP8+100 (8Q405+BHT+MDA) |
| d7b278a1 | posf3119 | 16 | 270 | 24 | | AIR | 252 | 12898 | 5194 | JP8+BHT+8Q405+MDA |
| d7b302a1 | posf3119 | 16 | 300 | 6 | | AIR | 282 | 1200 | 954 | JP8+100 (8Q405+BHT+MDA) |
| d7d278a1 | posf3119 | 62 | 270 | 24 | | AIR | 219 | 1091 | 946 | JP8+BHT+8Q405 |
| d7d278a2 | posf3119 | 16 | 270 | 24 | | AIR | 255 | 16330 | 5860 | JP8+BHT+8Q405 |
| d7d278p1 | posf3119 | 62 | 270 | 24 | | AIR | 219 | 940 | 646 | JP8+BHT+8Q405 |
| d7h272a1 | posf3119 | 16 | 270 | 6 | | AIR | 256 | 2729 | 1550 | JP8+BHT |
| d7h272a2 | posf3119 | 16 | 270 | 6 | | AIR | 260 | 2560 | 2691 | JP8+BHT |
| d7h278a1 | posf3119 | 62 | 270 | 24 | | AIR | 219 | 30422 | 5044 | JP8+BHT |
| d7h278a2 | posf3119 | 16 | 270 | 24 | | AIR | 255 | 25427 | 9631 | JP8+BHT |
| d7h278p1 | posf3119 | 62 | 270 | 24 | | 8% | 223 | 31871 | 616 | JP8+BHT |
| d7h302a1 | posf3119 | 16 | 300 | 6 | | AIR | 280 | 5629 | 2072 | JP8+BHT |
| d7k272a1 | posf3119 | 16 | 270 | 6 | | AIR | 256 | 528 | 1661 | JP8+BHT+MDA |
| d7k278a1 | posf3119 | 62 | 270 | 24 | | AIR | 220 | 688 | 391 | JP8+BHT+MDA |
| d7k278a2 | posf3119 | 16 | 270 | 24 | | AIR | 260 | 9694 | 6973 | JP8+BHT+MDA |
| d7k278p1 | posf3119 | 62 | 270 | 24 | | 8% | NA | 912 | 135 | JP8+BHT+MDA |
| d7k302a1 | posf3119 | 16 | 300 | 6 | | AIR | 280 | 1006 | 365 | JP8+BHT |
| d7g282p1 | posf3119 | 16 | 285 | 6 | | 8% | 254 | 1085 | 148 | Triphenylphosphine (C6H5)3P - 282grams/gal - 209mg/L |
| d7g302a1 | posf3119 | 16 | 300 | 6 | | AIR | 282 | 4375 | 1044 | Triphenylphosphine (C6H5)3P - 282grams/gal - 209mg/L |
| d7g302a2 | posf3119 | 16 | 300 | 6 | | AIR | 280 | 3417 | 724 | Triphenylphosphine (C6H5)3P - 282grams/gal - 209g/L |
| d3n2716a | posf2827 | 32 | 270 | 48 | | AIR | NA | 20400 | 63970 | NONE |
| d3n272a4 | posf2827 | 16 | 270 | 6 | | AIR | 245 | 659 | 2299 | NONE |

This page intentionally left blank.

Table 5. Phoenix Rig Oxygen Consumption Tests
(* Test with two heater blocks)

| | | | | | | | | | | | | | | |
|---|----------------------|-------------------|--------------------|-------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| O3rval | | | | | | | | | | | | | | |
| POSF 2827 JET A + Betz 8Q405 @ 100 mg/liter | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| Test Name | Flow Rate-- (ml/min) | Purge Gas Mixture | T Bulk Out (deg C) | % Oxygen Consumed | | | | | | | | | | |
| O1nva4 | | | | | | | | | | | | | | |
| posf2747 | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| 21% Oxygen | | | | | | | | | | | | | | |
| | | | | | 25 | 163 | 172 | 182 | 187 | 193 | 197 | 202 | 205 | 210 |
| | | | | | 0.307 | 0.308 | 0.307 | 0.303 | 0.302 | 0.298 | 0.291 | 0.282 | 0.270 | 0.236 |
| | | | | | | | | | | | | | | |
| O3nva9 | | | | | | | | | | | | | | |
| posf2827 | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| Test Name | Flow Rate-- (ml/min) | Purge Gas Mixture | T Bulk Out (deg C) | % Oxygen Consumed | | | | | | | | | | |
| O3nva9 | | | | | | | | | | | | | | |
| posf2827 | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| | | | | | 193 | 203 | 212 | 220 | 230 | 237 | 247 | 265 | | |
| | | | | | 0.955 | 0.872 | 0.804 | 0.694 | 0.438 | 0.053 | 0.053 | 0.053 | | |
| O3cval | | | | | | | | | | | | | | |
| posf2827 BETZ 8Q405 @ 100 mg/liter BHT @ 25 mg/L MOBIL MCP477 @300 mg/L | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| Test Name | Flow Rate-- (ml/min) | Purge Gas Mixture | T Bulk Out (deg C) | % Oxygen Consumed | | | | | | | | | | |
| O3cval | | | | | | | | | | | | | | |
| posf2827 | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| | | | | | 185 | 198 | 204 | 215 | 225 | 235 | 243 | 270 | | |
| | | | | | 0.990 | 0.914 | 0.796 | 0.524 | 0.175 | 0.060 | 0.057 | 0.058 | | |
| O5pval | | | | | | | | | | | | | | |
| POSF 2827 JET A + JP8 ADDITIVES | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| Test Name | Flow Rate-- (ml/min) | Purge Gas Mixture | T Bulk Out (deg C) | % Oxygen Consumed | | | | | | | | | | |
| O5pval | | | | | | | | | | | | | | |
| posf2827 | | | | | | | | | | | | | | |
| 16 | | | | | | | | | | | | | | |
| NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| | | | | | 180 | 186 | 196 | 204 | 214 | 224 | 234 | 243 | 273 | |
| | | | | | 0.960 | 0.938 | 0.900 | 0.813 | 0.672 | 0.416 | 0.115 | 0.055 | 0.058 | |

Table 5. Phoenix Rig Oxygen Consumption Tests
(* Test with two heater blocks)

| Test Name | O3rval | | | | | | | | | | | | | | | |
|----------------------|---|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Fuel | POSF 2827 JET A + Betz 8Q405 @ 100 mg/liter | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 181 | 191 | 196 | 199 | 204 | 209 | 214 | 219 | 224 | 227 | 232 | 236 | 241 | 246 | 275 | |
| % Oxygen Consumed | 0.994 | 0.975 | 0.962 | 0.944 | 0.913 | 0.895 | 0.837 | 0.757 | 0.662 | 0.586 | 0.437 | 0.281 | 0.106 | 0.053 | 0.054 | |
| Test Name | O5sval | | | | | | | | | | | | | | | |
| Fuel | POSF 2827 JET A + JP8 + Betz 8Q405 @ 100 mg/liter | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 191 | 199 | 209 | 219 | 227 | 236 | 246 | 275 | | | | | | | | |
| % Oxygen Consumed | 0.917 | 0.895 | 0.865 | 0.757 | 0.572 | 0.352 | 0.054 | 0.058 | | | | | | | | |
| Test Name | O4nval | | | | | | | | | | | | | | | |
| Fuel | POSF-2926, TANK S-6 | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 14 | 173 | 182 | 191 | 200 | 205 | 210 | 214 | 218 | 222 | 227 | 232 | 237 | 246 | 256 | 273 |
| % Oxygen Consumed | 0.314 | 0.314 | 0.311 | 0.307 | 0.292 | 0.280 | 0.268 | 0.240 | 0.173 | 0.085 | 0.027 | 0.025 | 0.025 | 0.026 | 0.025 | 0.026 |
| Test Name | O4fval | | | | | | | | | | | | | | | |
| Fuel | POSF 2926 JET A + BETZ 8Q405 + BHT | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 25 | 212 | 221 | 241 | 266 | | | | | | | | | | | |
| % Oxygen Consumed | 1 | 0.743 | 0.122 | 0.05 | 0 | | | | | | | | | | | |
| Test Name | O4pval | | | | | | | | | | | | | | | |
| Fuel | POSF2926 & JP8 Additives | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 22 | 180 | 190 | 200 | 210 | 220 | 230 | | | | | | | | | |
| % Oxygen Consumed | 1 | 0.973 | 0.911 | 0.818 | 0.554 | 0.071 | 0.054 | | | | | | | | | |

Table 5. Phoenix Rig Oxygen Consumption Tests
(* Test with two heater blocks)

| | | | | | | | | | | | | | | | | | |
|----------------------|--|------------------------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Test Name | | O4rval | | | | | | | | | | | | | | | |
| Fuel | | POSF 2926 & BETZ 8Q405 @ 100mg/L | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | | 22 | 183 | 193 | 203 | 213 | 223 | 233 | | | | | | | | | |
| % Oxygen Consumed | | 1 | 0.990 | 0.978 | 0.851 | 0.671 | 0.186 | 0.057 | | | | | | | | | |
| Test Name | | O9nval | | | | | | | | | | | | | | | |
| Fuel | | POSF2976 | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | | 24 | 170 | 180 | 188 | 198 | 208 | 212 | 217 | | | | | | | | |
| % Oxygen Consumed | | 1 | 0.981 | 0.970 | 0.970 | 0.952 | 0.797 | 0.396 | 0.053 | | | | | | | | |
| Test Name | | O6dval | | | | | | | | | | | | | | | |
| Fuel | | POSF 2980 + JP8 + Betz 8Q405 + BHT | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | | AIR | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | | 23 | 179 | 185 | 189 | 193 | 198 | 202 | 205 | 211 | 215 | 222 | 227 | 230 | 234 | 239 | 244 |
| % Oxygen Consumed | | 1.000 | 0.945 | 0.934 | 0.931 | 0.925 | 0.916 | 0.905 | 0.890 | 0.864 | 0.845 | 0.806 | 0.751 | 0.629 | 0.463 | 0.244 | 0.053 |
| Test Name | | O6pval | | | | | | | | | | | | | | | |
| Fuel | | POSF 2980 + JP8 | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | | AIR | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | | 183 | 188 | 191 | 196 | 201 | 207 | 211 | 216 | 220 | 225 | 230 | | | | | |
| % Oxygen Consumed | | 0.903 | 0.887 | 0.860 | 0.837 | 0.789 | 0.714 | 0.658 | 0.568 | 0.415 | 0.228 | 0.050 | | | | | |
| Test Name | | O7nval | | | | | | | | | | | | | | | |
| Fuel | | POSF3119 | | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | | 16 | | | | | | | | | | | | | | | |
| Purge Gas Mixture | | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | | 25 | 165 | 168 | 170 | 177 | 182 | 185 | 190 | 195 | 200 | 201 | 204 | 209 | 211 | 218 | 224 |
| % Oxygen Consumed | | 1.000 | 0.998 | 0.999 | 0.998 | 0.999 | 0.991 | 0.988 | 0.984 | 0.974 | 0.945 | 0.922 | 0.908 | 0.861 | 0.752 | 0.598 | 0.400 |

Table 5. Phoenix Rig Oxygen Consumption Tests
(* Test with two heater blocks)

| | | | | | | | | | | | | | | | |
|----------------------|-------------------------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Test Name | O9nva3* | | | | | | | | | | | | | | |
| Fuel | POSF2976 | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 180 | 190 | 194 | 197 | 202 | 207 | 212 | 217 | | | | | | | |
| % Oxygen Consumed | 0.929 | 0.890 | 0.864 | 0.833 | 0.683 | 0.430 | 0.137 | 0.078 | | | | | | | |
| Test Name | O6nva1* | | | | | | | | | | | | | | |
| Fuel | POSF2980 | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 4 | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 28 | 167 | 180 | 186 | 191 | 195 | 200 | 206 | 211 | | | | | | |
| % Oxygen Consumed | 1.000 | 0.751 | 0.615 | 0.474 | 0.246 | 0.058 | 0.056 | 0.049 | 0.050 | | | | | | |
| Test Name | O6dva3* | | | | | | | | | | | | | | |
| Fuel | POSF 2980 JET A + JP8 + BHT + 8Q405 | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 4 | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 24 | 162 | 170 | 178 | 184 | 189 | 194 | 199 | 206 | 209 | 217 | | | | |
| % Oxygen Consumed | 1 | 0.966 | 0.918 | 0.854 | 0.752 | 0.609 | 0.379 | 0.057 | 0.058 | 0.058 | 0.067 | | | | |
| Test Name | O6pva3* | | | | | | | | | | | | | | |
| Fuel | POSF 2980 JET A + JP8 | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 4 | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 145 | 149 | 158 | 162 | 171 | 177 | 182 | 187 | 189 | 194 | 200 | 207 | | | |
| % Oxygen Consumed | 0.965 | 0.955 | 0.905 | 0.850 | 0.675 | 0.560 | 0.372 | 0.083 | 0.060 | 0.054 | 0.058 | 0.055 | | | |
| Test Name | O7hva1* | | | | | | | | | | | | | | |
| Fuel | POSF 3119 JET A + JP8 + BHT | | | | | | | | | | | | | | |
| Flow Rate-- (ml/min) | 16 | | | | | | | | | | | | | | |
| Purge Gas Mixture | NATURAL DIFFUSION (21% O2) | | | | | | | | | | | | | | |
| T Bulk Out (deg C) | 25 | 200 | 204 | 208 | 213 | 217 | 220 | 227 | 228 | 233 | 238 | 245 | 254 | 268 | 280 |
| % Oxygen Consumed | 1 | 0.943 | 0.918 | 0.905 | 0.857 | 0.785 | 0.636 | 0.302 | 0.054 | 0.053 | 0.054 | 0.054 | 0.054 | 0.054 | 0.053 |

This page intentionally left blank.

5. FUEL/MATERIALS COMPATIBILITY DATA

Fuel-materials compatibility tests have been conducted with the proposed JP-8+100 additive packages. The purpose of this testing is to identify fuel system materials which may experience significant adverse interactions as a result of prolonged contact with the JP-8+100 jet fuel. This work is also detailed in a separate technical report (21).

A summary of the test results of the materials subjected to thermal aging in the additive test fuels and in the control JP-8 fuel is presented in Table 6. Each material shown is presented in this table at the temperatures to which it was tested. The overall test result/evaluation of this summary table was taken from each materials individual data sheet. The "W" symbol indicates a material test result which was within the allowable requirements set forth. An "O" symbol indicates a material test result which was outside the allowable requirement. The "OT" symbol indicates that a material was tested to a temperature beyond its limits, i.e., to a temperature higher than the material was designed to (or would be expected to) tolerate. The "E" indicates that the material has been tested, but that the evaluation is incomplete. An "I" indicates that a test still is planned but has not yet been conducted. The "NT" indicates no test is planned. The use of the symbol "CN" indicates control (fuel) and is primarily associated with metallics.

The *metallic* materials evaluation compares results obtained when materials were subjected to the JP-8 test fuels (JP-8 +100 and JP-8 +100 x4) to results obtained when materials were subjected to the JP-8 control fuel. In contrast, the *non-metallics* evaluation measures results obtained when materials were subjected to the control fuel (JP-8) against the same test evaluation criteria (specifications and standards) as results obtained when materials were subjected to test fuels (containing thermal stability additives).

Materials are reported in the following test results sections as having "passed" when they are assigned a "W" (within allowable requirement) for *all* material property tests in the data collection format.

Materials are reported as having "failed" when they were rated with an "O" (outside allowable requirement) in *any* material property test in the data collection format. A material that is reported as having failed may actually have had acceptable ("W," within allowable requirement) results in one or more of the tests. A material has failed in the context of this report when it has failed to meet the allowable requirement in *any one* test.

Materials are reported as having "failed" when they were rated with an "OT" (material tested beyond temperature range) even though the material would not have been expected to tolerate the test temperatures.

The Betz additive package was judged acceptable primarily based on its comparison to JP-8 (control) fuel.

This report contains a selected few of the more than 300 data pages from the database for all the materials' individual physical property test results/evaluations for a given temperature and the thermal aging test period(s) 28/7 days.

Two formats were developed to display the consolidated thermal aging test results and evaluations of each individual material of this program. These formats contain both the material/fuel exposure results and the fuel/material exposure test results. The non-metallics format contains all the material property test results, evaluation criteria and the evaluation of those results, as well as the fuel/material exposure control fuel general observations. The metallic format contains all the material property test results and the evaluation of those results as well as the fuel/material exposure/control fuel and general observations.

The control fuel results are shown in order to illustrate the effects of thermal stress on fuel without the inclusion of a metallic or non-metallic fuel system material. The control fuel was not necessarily thermally stressed (at the same time as the test fuel/material exposure. The two control fuels used were JP-8 (POSF-2980) or, later (June 1995) in the test program, JP-8 (POSF-2926). The fuel designations are recorded in the upper right hand corner of each test material data sheet.

The test fuels were: *a)* JP-8 (POSF-2980) with thermal stability additive at a *normal* concentration (+100); and *b)* JP-8 (POSF-2980) with thermal stability additive at a *four times normal* concentration (+100 x4). During the 1997 calendar year, POSF-2926 was used exclusively as both the test fuel and the baseline fuel due to the depletion of POSF-2980 fuel.

Selected data from more than 225 materials (300 tests) are shown in Table 7: for nitrile O-rings at 160, 180, 200, 250, and 325F, and for CPM 10V metallic material at 325F. The O ring data illustrates the effect of temperature on the material.

Screening test results for the control fuel and several +100 fuel additives are included as Table 8 to illustrate the effect of two different fuels (POSF-2926 and POSF-2980) on three selected materials.

Table 6. Fuel/Material Test Result Summary Table

Page 1 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|----------------|--|-------------------|-------------|------------|-----------------|---------------------|
| I.A.1 | Adhesive, Epoxy Polyamide, EC 3569, Bk-127 Lot#25D2P | Epoxy/Polyamide | 200 | W | W | W |
| I.A.2 | Adhesive, FM 47 Vinyl Phenolic | Vinyl | 200 | OT | OT | W |
| I.A.3 | Adhesive, AF 126-2, Nitrile, Mod. Epoxy | Nitrile | 200 | W | W | W |
| I.A.4 | Adhesive, AF 143-2, BR-127, Mod. Hi Temp Epoxy | Epoxy | 200 | W | W | W |
| I.A.5 | Adhesive, EPON 828/DTA, Un. Mod.Epoxy | | 200 | W | W | W |
| I.A.6 | Adhesive, FM73 W/BR-127 Primer, Nitrile Mod. Epoxy | Nitrile epoxy | 200 | W | W | W |
| I.A.7 | Adhesive, AF-10E/EC 1290 Primer, Scotchweld | Primer Scotchweld | 200 | W | W | W |
| I.A.8 | Adhesive, AF-10 W/EC 3950, Primer Scotchweld | | | NT | NT | NT |
| I.A.9 | Adhesive, EC776 Mil-S-4383, 3M Co., Nitrile | Nitrile | 200 | O | W | W |
| I.B.1 | Bladder Tank, AM Fuel PS-598, Nitrile | | 200 | OT | W | OT |
| I.B.10 | Goodyear 80C39 | Polyurethane | | NT | NT | NT |
| I.B.11 | Bladder Tank, Engineered Fabrics 3572N, Nylon Structural Cloth | Nylon | 200 | W | W | W |
| I.B.12 | Bladder Tank, Engineered Fabrics P/N 491, Nylon Structural Cloth | Polyester | 200 | W | W | W |
| I.B.13 | Amfuel PN C121 | Nylon | 200 | W | W | W |
| I.B.14 | Amfuel Cloth PN C130 | | 200 | W | W | W |
| I.B.2 | Bladder Tank, AMFuel U5200B, Nitrile | Nitrile | 200 | OT | OT | OT |
| I.B.3 | Bladder Tank, AMFuel PU 339, Polyurethane | Polyurethane | 200 | W | W | W |
| I.B.4 | Bladder Tank, Engineered Fabrics, PN 51956, Nitrile | Nitrile | 160 | W | W | W |
| I.B.5 | Bladder Tank, Engineered Fabrics, P/N 5904C, Polyurethane | Polyurethane | 160 | O | O | O |
| I.B.6 | Goodyear 26950 | Nitrile | 200 | OT | OT | OT |
| I.B.7 | Bladder Tank, Goodyear 51956, Nitrile | | 200 | OT | OT | OT |
| I.B.8 | Bladder Tank, Goodyear 80C29, Urethane | Urethane | 200 | OT | OT | OT |
| I.B.9 | Goodyear 80C29 | Nitrile | | NT | NT | NT |
| I.C.1 | Adhesive, EC776 Mil-S-4383, 3M Co., Nitrile | | 200 | O | W | W |
| I.C.2 | MIL-C-27725, Polyurethane | Polyurethane | 200 | W | W | W |
| I.C.3 | BMS 10-20 Epoxy | Epoxy | 200 | W | W | W |
| I.C.4 | Sealant, PR-1440 B2 Pro Seal BMS 5-267, Maganese, Mil-S-8802F | Mn | 200 | W | W | W |
| I.C.5 | MMS-425, PR2911 | | 200 | W | W | W |
| I.D.1 | Sealant, PR 1422, Type I, B2, Mil-S-8802F, Dichromate | Dichromate | 200 | W | W | W |
| I.D.10 | Sealant, PR-705, Polysulfide | Polysulfide | 200 | W | W | W |
| I.D.11 | Sealant, DC9403, Fluorosilicone Mil-S-55334 | Fluorosilicone | 200 | W | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 2 of 9

| Test ID | Material | Type | Temp | JP8 | JP8 +100 | JP8 + 100 x4 |
|---------|--|---|------|-----|----------|--------------|
| I.D.12 | Sealant, G651, Cyanosilicone | Cyanosilicone | | NT | NT | NT |
| I.D.2 | Sealant, PR-1440 B2 Pro Seal BMS 5-267, Maganese, Mil-S-8802F | Mn | 200 | W | W | W |
| I.D.3 | Sealant, PR-1750 B2, Manganese Mil-S-83430A | | 200 | W | W | W |
| I.D.4 | Sealant, PR1221, B2 Mil-S-7502, Lead Dioxide | Lead dioxide | | NT | NT | NT |
| I.D.5 | Sealant, Q4-2817 W1200 Primer, Fluorosilicone | Fluorosilicone | 200 | W | W | W |
| I.D.6 | Sealant, PR2911, Polyurethane | Polyurethane | 200 | O | O | O |
| I.D.7 | Sealant, PR-1828 B2 Polythioether | Polythioether | 200 | W | W | W |
| I.D.8 | Sealant, PR-1776 B2, Polysulfide AMS 3281 | Polysulfide | 160 | W | W | O |
| | | | 200 | OT | OT | OT |
| I.D.9 | Sealant, PR1775 B2, Polysulfide AMS 3265 | | 160 | W | W | W |
| | | | 200 | OT | OT | OT |
| I.E.1 | Composite, AS4/3501-6, Epoxy graphite | Epoxy graphite | 200 | W | W | W |
| I.E.2 | Composite, IM7/5250-4(BMI), Graphite Bismaleimide | Graphite | 200 | W | W | W |
| I.E.3 | Composite, AS 7/8551-7A Epoxy graphite | Epoxy graphite | 200 | W | W | W |
| I.E.4 | Composite | Fiberglass | | NT | NT | NT |
| I.E.5 | | Epoxy Resin | | NT | NT | NT |
| I.F.1 | Borosilicate 0.4 + 07.0 Formula (Glass Fibers) | Phenolic, latex, acrylic, epoxy binders | 200 | I | NT | I |
| I.F.2 | Screen | Unknown | 200 | I | NT | I |
| I.F.3 | Foam, FOMEX YELLOW TYPE II, Polyester, MIL-B-83054 | Polyurethane (ester) | 200 | W | W | W |
| I.F.4 | Foam, FOMEX BLUE TYPE IV, Polyether, Mil-B-83054 | Polyurethane (ether) | 200 | W | W | W |
| I.F.5 | Foam, FOMEX, GRAY CLASS 1, Polyether, Mil-F-87260 | | 200 | W | W | W |
| I.F.6 | Foam, CREST, GREY CLASS II., Polyther Mil-F-87260 | | 200 | W | W | W |
| I.F.7 | Foam, Foamex, Charcoal Gray Class II, Polyurethane Mil-F-87260 | | | NT | NT | NT |
| I.F.8 | Foam, Crest, Yellow Type II Non-conductive, Polyurethane Mil-B-80354 | Polyurethane (ester) | | W | W | W |
| I.G.1 | "O" ring, Nitrile, N-756 (Parker), MIL-P-83461 | Nitrile | 160 | O | O | O |
| | | | 200 | O | O | O |
| I.G.10 | "O" ring, Fluorosilicone, ES2000/8539 (Bendix) Mil-R-25988 | Fluorosilicone | | NT | NT | NT |
| I.G.11 | Washer, Urethane, PO-652/P/N 212147Argo-TECH | Urethane | 160 | W | W | W |
| | | | 200 | OT | OT | OT |
| I.G.12 | Tank, Urethane, P/N 212351 ArgoTECH JT90 | | 200 | W | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 3 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|----------------|--|-----------------|-------------|------------|-----------------|---------------------|
| I.G.13 | Cork, P/N 30-155-5-1 Parker | Cork | 200 | W | W | W |
| I.G.14 | "O" Rin, Nitrile, Mil-P-83461 (hydraulic) | Nitrile | 200 | O | O | O |
| I.G.2 | "O" ring, Nitrile, N304-75 (Parker), Mil-P-25732 | | 160 | O | O | O |
| I.G.3 | "O" ring, Nitrile N-602-70 (Parker), Mil-P-5315 | | 200 | O* | O* | O* |
| | | | 160 | O | W | W |
| | | | 180 | OT | OT | OT |
| | | | 200 | OT | OT | OT |
| | | | 200 | OT | OT | OT |
| | | | 325 | OT | OT | OT |
| I.G.4 | "O" ring, Nitrile, N 506-65 (Parker) AMS 7271/MS 9201 | | 160 | W | W | W |
| I.G.5 | "O" ring, Fluorosilicone (Parker) L 677-70, Mil-P-25988 | Fluorosilicone | 200 | OT | OT | OT |
| | | | 200 | W* | W* | W* |
| I.G.6 | "O" ring, Fluorocarbon (Parker) V 747-75 (Viton) Mil-R-83248 | Fluoroelastomer | 200 | W* | W* | W* |
| I.G.7 | "O" ring, Fluorocarbon (Parker) V0835-75 (Viton) GLT Mil-R-83485 | | 200 | W | W | W |
| I.G.8 | "O" ring, Perfluoroelastomer, 93244G Kalrez DuPont, AMS7257A | Kalrez | 200 | W | W | W |
| I.G.9 | "O" ring, Nitrile, CLS8715#74-2 Coast Craft, ASE3 | Nitrile | 160 | O | O | O |
| I.H.1 | Self Sealing Hose | | 200 | OT | OT | OT |
| | | | | NT | NT | NT |
| I.H.2 | ACRYLIC/NITRATE/DUODYNE P/N AC603-01 Mil-H-4495 | Acrylic/nitrile | 160 | W | NT | NT |
| I.H.3 | NITRATE/DUODYNE P/N AC646-01 Mil-H-370 | Nitrile | 200 | OT | OT | OT |
| | | | 200 | OT | OT | OT |
| I.H.4 | NITRATE/DUODYNE P/N AC6611-06 Mil-H-17902 | | 200 | OT | OT | OT |
| I.H.5 | EPICHLOROHYDRIN/DUODYNE P/N EC61401 Mil-H-26521 | Epichlorohydrin | 200 | OT | W | W |
| I.I.1 | TFE (TEFLON) | Teflon | 200 | O | O | O |
| I.I.10 | Teflon/Kapton | Hybrid Teflon | 200 | I | I | I |
| I.I.11 | Shrink Wrap | | 200 | I | I | I |
| I.I.2 | Nylon 66 /DuPont Zytel 101, ASTM D 4066 - Old | Nylon | 160 | O | O | O |
| I.I.3 | Polyethylene (HDP) | Polyethylene | 200 | O | O | O |
| | | | 200 | O | O | O |
| I.I.4 | KAPTON/UPILEX | Kapton | 200 | W | W | W |
| I.I.5 | Marmon | | | NT | NT | NT |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 4 of 9

| Test ID | Material | Type | Temp | JP8 | JP8 +100 | JP8 +100 x4 |
|----------|--|---------------|------|-----|----------|-------------|
| I.I.6 | Vinyl Plastic tubing Mil-I-7444 Type I | Vinyl Plastic | 200 | E | E | E |
| I.I.7 | Kynar | Shrink Wrap | 200 | W | W | W |
| I.I.9 | Magnetic Wire Insulation type I | HML Varnish | 325 | I | I | I |
| I.J.1 | 2219 T87 Aluminum, welded UNS A92319/4191D (AMS) | Al | 200 | CN | W | W |
| I.J.10 | 321 SS, Brazed | SS | 325 | CN | W | W |
| I.J.11 | Tin & Lead, QQ-S-571, SN60(Tin 60%, Lead 40%) B-36-21A | Pb, Sn | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| I.J.12 | 6061 T-6 Mil-B-7883 Type V Grade B, Dip Braze | | 200 | CN | W | W |
| I.J.13 | Ti, Cu, Ni Braze, P&W | Ti, Cu, Ni | 325 | CN | W | W |
| I.J.14 | Aluminum, 6061-T6, Welded With 4043 Filler | Al | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| I.J.15 | 5052 H-34 Welded w/ 6061T6 w/ 5356 Filler | | 200 | I | I | I |
| I.J.16 | SN 95, Sb05 Base Material, B36-21A | Cu | 200 | I | I | I |
| I.J.2 | Match Fill 6AL-AV(Ti), Welded | Matchfill | 325 | CN | W | W |
| I.J.3 | Match Fill, 3AL-2.5V(Ti), Welded | | 325 | CN | W | W |
| I.J.4 | Match Fill, Inco 718 Nickel (Welded) | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| I.J.5 | Match Fill, Inco 625 (Ni), Welded | | 325 | CN | W | W |
| I.J.6 | Match Fill, 321, SS Ferrous (Welded) | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| I.J.7 | Match Fill, IN200/201 Nickel, Welded | | 325 | CN | W | W |
| I.J.8 | In200/In201, Welded | BNI | 325 | CN | W | W |
| I.J.9 | Waspalloy (Ni), Brazed AMS 4786 AG | AMS 4786 Ag | 325 | CN | W | W |
| I.K.1.1 | Cover, Ink Stamp, Coating QQ-A-25011, EC 776 | | 200 | W | W | W |
| I.K.1.2 | Cover, Ink Stamp, Coatings QQ-A-25011, EC 776 | | 200 | W | W | W |
| I.K.1.3 | | | 200 | W | W | W |
| I.K.10.1 | BF Boodrich Probe P/N 391002-250 | Coating | 200 | I | I | I |
| I.K.10.2 | BF Boodrich Electronics P/N 391002-250 | | 200 | I | I | I |
| I.K.11.1 | Ragan Data Systems, Probe P/N 75-108-2F | | 200 | I | I | I |
| I.K.11.2 | Ragan Data Systems, Electronics P/N 75-108-2F | | 200 | I | I | I |
| I.K.12 | Ametek Aerospace Products CH-5851-L | Polysulfide | 200 | I | I | I |
| I.K.2 | Dry Film Lubricant, Dicronite DoD-L-85645 | dicronite | 200 | I | I | I |
| I.K.3 | Dry thread lubricant | Graphite | 200 | I | I | I |
| I.K.4 | Name plate, QQA-250/1, Color A11136 | | 200 | W | W | W |
| I.K.5 | Dry Film Lubricant | Mo disulfide | 200 | I | I | I |
| I.K.6a | | Al varnish | | NT | NT | NT |

W = Within Tolerance; O = Out of Tolerance; OT = Tested beyond material's Temperature Range; I = Test Planned
 E = Evaluation incomplete (tested); NT = No test planned; CN = Control; * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 5 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|----------------|---|-------------|-------------|------------|-----------------|---------------------|
| <i>I.K.6b</i> | Resin No48-C-31, ES#11110 Midland Div | | | NT | NT | NT |
| <i>I.K.6c</i> | Reducer: LAMNERX500 Spec. No. 66-C-28, ES#11110 Midland Div | | | NT | NT | NT |
| <i>I.K.7</i> | Carbon Bearing #6001, Cr Plate | SS | 200 | W | W | W |
| <i>I.K.8.1</i> | Pump Pure Carbon co. PG18RCH | | 325 | I | I | I |
| <i>I.K.8.2</i> | Pump P658RCH Pure Carbon co. | | 325 | W | W | W |
| <i>I.K.8.3</i> | Pump Pure Carbon co. P5N2 | | 325 | W | W | W |
| <i>I.K.9</i> | Seal, Mil-L-46010B, Type I, Micro-seal Green tweed | | 200 | I | I | I |
| <i>I.L.1</i> | Threadlock MIL-5-22473 GRADE A or AV, Loctite | | 200 | W | W | W |
| <i>I.L.2</i> | Threadlock MIL-S-22473 (Red), Loctite 272 | | 200 | W | W | W |
| <i>I.L.3</i> | Threadlock MIL-S-22473 (Brown) Loctite 222 | | 200 | W | W | W |
| <i>I.M.1</i> | 5052-0 Bare Aluminum | Al | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.10</i> | A 355-T6 Cast Aluminum | | 200 | CN | W | W |
| <i>I.M.11</i> | A 356-T6 Cast Aluminum | | 200 | CN | W | W |
| <i>I.M.12</i> | 7050-T74 Bare Aluminum | | 200 | CN | W | W |
| <i>I.M.13</i> | 316 Stainless Steel (Passivated), Ferrous | SS | 200 | CN | W | W |
| <i>I.M.14</i> | 321 Stainless Steel (Passivated), Ferrous | | 200 | CN | W | W |
| <i>I.M.15</i> | 304 Stainless Steel (Passivated) Ferrous | | 200 | CN | W | W |
| <i>I.M.16</i> | 718 INCO, Nickel | Ni | 200 | CN | W | W |
| <i>I.M.17</i> | 440C Stainless Steel, AMS 5630, Fe | SS | 200 | CN | W | W |
| <i>I.M.18</i> | 347 Stainless Steel, Fe | | 200 | CN | W | W |
| <i>I.M.19</i> | Alloy 30302 AMS 5688H, Fe | | 200 | CN | W | W |
| <i>I.M.2</i> | 6061-T4 Bare Aluminum | Al | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| <i>I.M.20</i> | 17-4 Ph AMS 5604/5643 Stainless Steel, Fe | SS | 200 | CN | W | W |
| <i>I.M.21</i> | 1010 Cadmium Plate (Class 2), Ferrous | Ferrous | 325 | CN | W | W |
| <i>I.M.22</i> | 1010 Zinc Plate, Ferrous | | 325 | CN | W | W |
| <i>I.M.23</i> | 4130 Cadmium (Class 2) Plate Steel | | 200 | CN | W | W |
| <i>I.M.24</i> | 6AL-4V, Titanium | Ti | 200 | CN | W | W |
| <i>I.M.25</i> | 950 Bronze Aluminum, Cu | Cu/Al | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.26a</i> | Naval Brass (Cu/Ni - 70/30) | Cu/Ni | 200 | CN | W | W |
| <i>I.M.26b</i> | Naval Brass (Cu/Ni - 90/10) | | 200 | CN | W | W |
| <i>I.M.27</i> | Brass, Sheet 268, Substitute 260, Copper | Cu | 160 | CN | W | W |
| | | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.28</i> | Lead, AMS 4751/4750 | Pb | 200 | CN | W | W |
| | | | 325 | CN | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 6 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|----------------|--|--------------|-------------|------------|-----------------|---------------------|
| <i>I.M.29</i> | Shaw Aerospace - Barium Ferrite | Ba | 160 | CN | W | W |
| | | | 200 | OT | OT | OT |
| | | | 325 | OT | OT | OT |
| <i>I.M.3</i> | 6061-T6 Bare Aluminum | Al | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.30</i> | NEO-DYMIUM, ND | | 160 | E | E | E |
| | | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.31</i> | Copper Brass Sheet, ASTM B36-21A | Cu | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.32</i> | 1010 Bare, Fe | Ferrous | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.33</i> | ASTM B-29, Soft Lead | Pb | 200 | CN | W | W |
| <i>I.M.34</i> | Monel 400 Sheet, Ni/Cu | Cu/Ni | 325 | CN | W | W |
| <i>I.M.35</i> | 15-5PH, Stainless Steel, Fe, Cr, Ni, Cu, | Ferrous | 325 | CN | W | W |
| <i>I.M.36</i> | 5052 - H34 Aluminum | Al | 200 | CN | W | W |
| <i>I.M.37</i> | 1045 Cadmium Plate Class II, Type 2 Gold, Fe | Ferrous | 325 | CN | W | W |
| <i>I.M.38</i> | 1045 Bare Fe | | 325 | CN | W | W |
| <i>I.M.39</i> | AZ91 T-6 (Substitute AZ31 - N24), Mg | Mg | 200 | CN | W | W |
| <i>I.M.4</i> | 7075-T6 Aluminum, Chromic Acid Anodized | Al | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| <i>I.M.40</i> | 4130 Bare, Steel, Fe | Ferrous | 325 | CN | W | W |
| <i>I.M.41</i> | Sn 95, Sb 05 | solder | 200 | CN | W | W |
| <i>I.M.42</i> | 2014T6 AMS 4029 | Al | 200 | I | I | I |
| <i>I.M.43</i> | 4340, AMS6415 280KSI Tensile | Steel | 325 | I | I | I |
| <i>I.M.5</i> | 7075-T6 ALODINE/200 Aluminum | Al | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| <i>I.M.6</i> | 7075-T6 Bare Aluminum | | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| <i>I.M.7</i> | 2024-T3 Bare Aluminum | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.M.8</i> | 2219-T87 Bare Aluminum | | 200 | CN | W | W |
| | | | 325 | OT | OT | OT |
| <i>I.M.9</i> | 3003 Bare Aluminum | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>I.O.1</i> | Unicellular Buna-n HR Textron | Buna N | 225 | W | W | W |
| <i>I.O.2</i> | Unicellular Buna-n HR Textron, Foam Moulding Inc | Polyurethane | 225 | W | W | W |
| <i>I.O.3</i> | Polyurethane, HR Textron, Custom Foam, Sample 1 | | 225 | W | W | W |
| <i>I.O.4</i> | Polyurethane, HR Textron, Custom Foam, Sample 2 | | 225 | W | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 7 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|----------------|--|--------------------|-------------|------------|-----------------|---------------------|
| I.O.5 | Polyurethane, HR Textron, Custom Foam, Sample 3 | Polyurethane | 225 | W | W | W |
| I.O.6 | Polyurethane, HR Textron, Custom Foam, Sample 4 | | 225 | W | W | W |
| I.O.7 | Floats, XAR Industries Inc. | | 225 | W | W | W |
| I.O.8 | Cork, Parker 30-155-5-1 | Cork | 200 | W | W | W |
| I.P.1 | Epoxy, Epon 828 DETA | Epoxy | 200 | W | W | W |
| I.P.2.1 | Polysulfide/(film) Chem seal CS3100 Mil-S-8516 | Polysulfide | 200 | O | O | O |
| I.P.2.2 | CS3100 Chem Seal Mil-S-8516 | | 200 | E | E | E |
| I.P.3 | Fluorosilicone, AMS 3361 | Fluorosilicone | 200 | nl | NT | NT |
| I.P.4 | Urethane | Urethane | 200 | NT | NT | NT |
| II.G.1 | "O" ring, Fluorosilicone, ES2000/8539 (Bendix) Mil-R-25988 | Fluorosilicone | 275 | OT | OT | OT |
| II.G.10 | Washer, Urethane, PO-652/P/N 212147Argo-TECH | Urethane | 325 | OT | OT | OT |
| | | | 160 | W | W | W |
| | | | 200 | OT | OT | OT |
| II.G.11 | Tank, Urethane, P/N 212351 ArgoTech JT90 | | 325 | OT | OT | OT |
| | | | 200 | W | W | W |
| | | | 325 | OT | OT | OT |
| II.G.12 | "O" ring, Fluorocarbon, GTC 778, Green Tweed Mil-R-83485 | Fluorocarbon | 325 | W | W | W |
| II.G.13 | "O" ring, Fluorosilicone, GTC B-95, Green Tweed Mil-R-25988 | Fluorosilicone | 400 | W | W | W |
| | | | 200 | W | W | O |
| II.G.14 | "O" ring, Fluorosilicone, Stillman TH-1384 Mil-R-25988 | | 325 | OT | OT | OT |
| | | | 180 | W | W | W |
| II.G.15 | "O" ring, Fluorosilicone L-1186-80, Parker Mil-R-25988 | | 200 | W | W | W |
| II.G.2 | "O" ring, Fluorosilicone (Parker) L 677-70, Mil-P-25988 | | 200 | W | W | W |
| | | | 250 | OT | W | W |
| | | | 325 | OT | OT | OT |
| II.G.3 | "O" ring, Fluorocarbon (Parker) V0835-75 (Viton) GLT Mil-R-83485 | Fluoroelastomer | 200 | W | W | W |
| | | | 325 | W | W | W |
| | | | 400 | W | W | W |
| II.G.4 | "O" ring, Perfluoroelastomer, 93244G Kalrez DuPont, AMS7257A | perfluoroelastomer | 200 | W | W | W |
| | | | 325 | W | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table
Page 8 of 9

| <i>Test ID</i> | <i>Material</i> | <i>Type</i> | <i>Temp</i> | <i>JP8</i> | <i>JP8 +100</i> | <i>JP8 + 100 x4</i> |
|------------------|--|--------------------|-------------|------------|-----------------|---------------------|
| <i>II.G.5</i> | "O" ring, Fluorosilicone, ESS928 JONAL (Bendix) Mil-R-25988(MOD) | Fluorosilicone | 275 | OT | OT | OT |
| | | | 325 | OT | OT | OT |
| <i>II.G.6</i> | "O" ring, Fluorocarbonr, GTC 777, Green Tweed Mil-R-83485 | Fluoroelastomer | 325 | W | W | W |
| | | | 400 | W | W | W |
| <i>II.G.7</i> | "O" ring, Fluorosilicone, GTC 409, Green Tweed, Mil-R-25988 | Fluorosilicone | 325 | OT* | OT* | OT* |
| <i>II.G.8</i> | "O" ring, Perfluoroelastomer, GTC 505, Green Tweed, AMS7257A | Perfluoroelastomer | 325 | O | O | O |
| <i>II.G.9</i> | "O" ring, Fluorocarbon (Parker) V 747-75 (Viton) Mil-R-83248 | Fluoroelastomer | 200 | W* | W* | W* |
| | | | 325 | O | O | O |
| <i>II.M.1</i> | 6AL-4V, Titanium | Ti | 325 | CN | W | W |
| <i>II.M.10</i> | Alloy 30302 AMS 5688H, Fe | SS | 325 | CN | W | W |
| <i>II.M.11</i> | 440C Stainless Steel, AMS 5630, Fe | | 325 | CN | W | W |
| <i>II.M.12</i> | 304 Stainless Steel (Passivated) Ferrous | | 325 | CN | W | W |
| <i>II.M.13</i> | 316 Stainless Steel (Passivated), Ferrous | | 325 | CN | W | W |
| <i>II.M.14</i> | 321 Stainless Steel (Passivated), Ferrous | | 325 | CN | W | W |
| <i>II.M.16</i> | ASI 51410SS (AMS 5504-J) | | 200 | E | E | E |
| | | | 325 | CN | W | W |
| <i>II.M.17</i> | 440C Stainless Steel, AMS 5630, Fe | Steel | 325 | CN | W | W |
| <i>II.M.18</i> | Powder Metallurgy cpm 10V (Rolled Fe, V, CR, C, Mn, SiL, T,S,Mo CPM 10V) | | 325 | CN | W | W |
| <i>II.M.19</i> | A 355-T6 Cast Aluminum | Al | 325 | CN | W | W |
| <i>II.M.2</i> | 3Al-2.5V, Titanium | Ti | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| | | | 400 | CN | W | W |
| <i>II.M.20</i> | C 356-T6 Cast Aluminum | Al | 325 | CN | W | W |
| <i>II.M.21</i> | A-286 AMS 5525, 2410 Silver Plate | Ferrous | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>II.M.22</i> | 135 Modified AMS 6470J, Nitalloy, MIL-S-6709 | Nitalloy | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>II.M.23.1</i> | Leaded bronze (Tap MS 285), Saw cut, Cu (New Type) | Cu | 160 | CN | W | W |
| | | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| <i>II.M.23.2</i> | Leaded bronze (Tap MS 285), (Polished Cylinder End Drylube) | | 160 | CN | W | W |
| | | | 200 | CN | W | W |
| | | | 325 | CN | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

Table 6. Fuel/Material Test Result Summary Table

Page 9 of 9

| Test ID | Material | Type | Temp | JP8 | JP8 +100 | JP8 + 100 x4 |
|-----------|--|------------|------|-----|----------|--------------|
| II.M.23.3 | Leaded bronze (Tap MS 285), Coated Cylinder (Indium), Argo-Tech | | 325 | CN | W | W |
| II.M.23.4 | Leaded bronze (Tap MS 285), Coated Cylinder (Indium), ArgoTech "B" | | 325 | CN | W | W |
| II.M.24 | 17-4 Ph AMS 5604/5643 Stainless Steel, Fe | Ferrous | 400 | CN | W | W |
| II.M.25 | IN 200, Nickel | Ni | 325 | CN | W | W |
| | | | 200 | CN | W | W |
| II.M.26 | Augmentor spray bar, SS, Brazed Nozzles (P&W) | SS | 325 | CN | W | W |
| II.M.27 | Monel 400 Sheet, Ni/Cu | Cu/Ni | 325 | CN | W | W |
| II.M.28 | Incolloy 909, Ni, Co, Fe | Ni, Co, Fe | 325 | CN | W | W |
| II.M.29 | Titanium 6-2-4-2 sheet, AMS 4919C | Ti, Al, Sn | 325 | CN | W | W |
| II.M.3 | Hastalloy, Nickel Alloy, 5536K | Ni | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| II.M.30 | HAYNES 188 (Co, Cr, Ni) | Co, Cr, Ni | 325 | CN | W | W |
| II.M.31 | HAYNES 214 (Fe, Al, Cr, Ni) | Co, Cr, Fe | 325 | NT | NT | NT |
| II.M.32.1 | AMS 7902 Beryllium Alloy, Al, Be, Met 162 (as cast alloy 310) | | 325 | CN | W | W |
| II.M.32.2 | AMS 7902 Beryllium Alloy, Al, Be, Met 162 (Mach. Surfaces 157) | | 325 | CN | W | W |
| II.M.32.3 | AMS 7902 Beryllium Alloy, Al, Be, Met 162 (AM 162 rolled std. grind finish)) | | 325 | CN | W | W |
| II.M.33 | UNS C17200 Be Cu Spring | Cu, Be | 325 | CN | W | W |
| II.M.34 | DB Inconel 718 Fusion Bond, Ni/Cr | Cr, Ni | 325 | CN | W | W |
| | | | 400 | NT | NT | NT |
| II.M.35 | 17-4 PH H-1000, SS | SS | 325 | CN | W | W |
| II.M.36 | 8 Al-1V-21 Mo,Ti | Ti | 325 | CN | W | W |
| II.M.37 | Ion Vapor Deposit IVD on 4130 | Steel | 325 | I | I | I |
| II.M.38 | 52100 AMS644H | | 325 | I | I | I |
| II.M.39 | 8620 AMS6277E | | 325 | I | I | I |
| II.M.4 | WASPALLOY, Nickel, AMS 5544E | Ni | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| II.M.5 | INCO 625, Nickel Alloy, AMS 55990 | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| II.M.6 | 718 INCO, Nickel, AMS 5596G | | 200 | CN | W | W |
| | | | 325 | CN | W | W |
| II.M.7 | STELLITE 30, Cu, Cr | Cr, Cu | 325 | CN | W | W |
| II.M.8 | 347 Stainless Steel, Fe | SS | 325 | CN | W | W |
| II.M.9 | Greek Ascolloy, Ferrous, AMS 5616 | Ferrous | 200 | CN | W | W |
| | | | 325 | CN | W | W |

W = Within Tolerance: O = Out of Tolerance: OT = Tested beyond material's Temperature Range: I = Test Planned
 E = Evaluation incomplete (tested): NT = No test planned: CN = Control: * Denotes 7 day test data available

This page intentionally left blank.

Table 7. Selected Fuel/Material Data

Wright Patterson Air Force Base

and the

University of Dayton

**Material Test
Data Non-Metals**

Material ID I.G.3 **Material:** "O" ring, Nitrile N-602-70 (Parker), Mil-P-5315
Temperature (F): 160 **Use:** Airframe, Fuel systems gaskets, "O"-Ring
Test date: 15-Feb-96 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 92-POSF-2926 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | Evaluations JP8+100 | JP8+100 x 4 |
|--------------------------------|-----------------|---------------------|--------------------------|-------------------------|------------|----------------------------|--------------------|
| Compression Set | 9 | 12 | 6 | NA | W | W | W |
| Elongation (%) | 199 | 199 | 202 | 264 | W | W | W |
| Hardness, Shore A (pts) | 57 | 65 | 65 | 66 | W | W | W |
| Tensile (PSI) | 1009 | 1526 | 1592 | 1712 | O | W | W |
| Volume Swell (%) | 16 | 17 | 17 | NA | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|---------------------------|-----------------------|-----------------------------|------------------------------|
| Acid No. (mg KOH/gm) | NE | .004 | .004 |
| Conductivity (pS/m) @72F | 15 | 400 | 662 |
| Gums (mg/100ml) | NE | 4.4 | 41.4 |
| Hydroperoxides (mM) | NE | 0 | 0 |

Evaluation Criteria

| | | |
|-------------------------|-------------------|-----------|
| Compression Set | Maximum Value | 50% |
| Elongation (%) | Decrease | 25% |
| Hardness, Shore A (pts) | Decrease/Increase | 5pts/5pts |
| Tensile (PSI) | Decrease | 25% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C ,C1--C6 is Clear, light to dark

W = Within Tolerance; O = Out of Tolerance;

NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data Non-Metals**

**Wright Patterson Air Force Base
and the
University of Dayton**

Material ID I.G.3 **Material:** "O" ring, Nitrile N-602-70 (Parker), Mil-P-5315
Temperature (F): 180 **Use:** Airframe, Fuel systems gaskets, "O"-Ring
Test date: 14-Mar-96 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 92-POSF-2926 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | Evaluations JP8+100 | JP8+100 x 4 |
|--------------------------------|-----------------|---------------------|--------------------------|-------------------------|------------|----------------------------|--------------------|
| Compression Set | 19 | 24 | 25 | NA | W | W | W |
| Elongation (%) | 232 | 223 | 187 | 264 | W | W | O |
| Hardness, Shore A (pts) | 55 | 57 | 62 | 66 | OT | OT | W |
| Tensile (PSI) | 1163 | 1093 | 1320 | 1712 | OT | OT | W |
| Volume Swell (%) | 18 | 17 | 17 | NA | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|---------------------------|-----------------------|-----------------------------|------------------------------|
| Acid No. (mg KOH/gm) | 0.006 | 0.003 | 0.004 |
| Color | C1 | C1 | C1 |
| Conductivity (pS/m) @72F | 149 | 376 | 604 |
| Gums (mg/100ml) | 3.2 | 5.4 | 12.4 |
| Hydroperoxides (mM) | 0.37 | 0 | 0 |

Evaluation Criteria

| | | |
|-------------------------|-------------------|-----------|
| Compression Set | Maximum Value | 50% |
| Elongation (%) | Decrease | 25% |
| Hardness, Shore A (pts) | Decrease/Increase | 5pts/5pts |
| Tensile (PSI) | Decrease | 25% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C, C1--C6 is Clear, light to dark
W = Within Tolerance; O = Out of Tolerance;
NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

Wright Patterson Air Force Base

and the

University of Dayton

**Material Test
Data Non-Metals**

Material ID I.G.3 **Material:** "O" ring, Nitrile N-602-70 (Parker), Mil-P-5315
Temperature (F): 200 **Use:** Airframe, Fuel systems gaskets, "O"-Ring
Test date: 21-Nov-94 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 93-POSF-2980 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | <u>Evaluations</u> | |
|-------------------------|----------|--------------|-------------------|------------------|-----|--------------------|-------------|
| | | | | | | JP8+100 | JP8+100 x 4 |
| Compression Set | 37 | 41 | 40 | NA | W | W | W |
| Elongation (%) | 34 | 138 | 147 | 265 | OT | OT | OT |
| Hardness, Shore A (pts) | 76 | 63 | 63 | 69 | OT | OT | OT |
| Tensile (PSI) | 174 | 991 | 1211 | 1970 | OT | OT | OT |
| Volume Swell (%) | 16 | 17 | 18 | NA | W | W | W |

| | | | |
|---------------------------|-----------------------|-----------------------------|------------------------------|
| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|---------------------------|-----------------------|-----------------------------|------------------------------|

Evaluation Criteria

| | | |
|-------------------------|-------------------|-----------|
| Compression Set | Maximum Value | 50% |
| Elongation (%) | Decrease | 25% |
| Hardness, Shore A (pts) | Decrease/Increase | 5pts/5pts |
| Tensile (PSI) | Decrease | 25% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C, C1--C6 is Clear, light to dark

W = Within Tolerance; O = Out of Tolerance;

NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data Non-Metals**

**Wright Patterson Air Force Base
and the
University of Dayton**

Material ID I.G.3 **Material:** "O" ring, Nitrile N-602-70 (Parker), Mil-P-5315
Temperature (F): 325 **Use:** Airframe, Fuel systems gaskets, "O"-Ring
Test date: 16-Nov-95 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 93-POSF-2980 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | Evaluations JP8+100 | JP8+100 x 4 |
|--------------------------------|-----------------|---------------------|--------------------------|-------------------------|------------|----------------------------|--------------------|
| Compression Set | 170 | 162 | 147 | NA | OT | OT | OT |
| Elongation (%) | 35 | Broke | 23 | 265 | OT | OT | OT |
| Hardness, Shore A (pts) | 70 | 82 | 75 | 69 | W | OT | W |
| Tensile (PSI) | 132 | Broke | 111 | 1970 | OT | OT | OT |
| Volume Swell (%) | 19 | 15 | 15 | N/A | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|---------------------------|-----------------------|-----------------------------|------------------------------|
| Acid No. (mg KOH/gm) | .005 | .001 | .006 |
| Color | C2 | C2 | C2 |
| Conductivity (pS/m) @72F | 10.75 | 99 | 403 |
| Gums (mg/100ml) | 4.2 | 7.6 | 15.8 |
| Hydroperoxides (mM) | .016 | NE | .011 |

Evaluation Criteria

| | | |
|-------------------------|-------------------|-----------|
| Compression Set | Maximum Value | 50% |
| Elongation (%) | Decrease | 25% |
| Hardness, Shore A (pts) | Decrease/Increase | 5pts/5pts |
| Tensile (PSI) | Decrease | 25% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C ,C1--C6 is Clear, light to dark
W = Within Tolerance; O = Out of Tolerance;
NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data Non-Metals**

**Wright Patterson Air Force Base
and the
University of Dayton**

Material ID I.G.5 **Material:** "O" ring, Fluorosilicone (Parker) L 677-70, Mil-P-25988
Temperature (F): 200 **Use:** Airframe, Fuel systems gaskets, "O"-Ring
Test date: 09-Jun-94 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 93-POSF-2980 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | Evaluations JP8+100 | JP8+100 x 4 |
|--------------------------------|-----------------|---------------------|--------------------------|-------------------------|------------|----------------------------|--------------------|
| Compression Set | 6 | 9 | 10 | NA | W | W | W |
| Elongation (%) | 199 | 201 | 194 | 231 | W | W | W |
| Hardness, Shore A (pts) | 63 | 63 | 63 | 69 | W | W | W |
| Tensile (PSI) | 856 | 857 | 852 | 984 | W | W | W |
| Volume Swell (%) | 9 | 9 | 9 | NA | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|---------------------------|-----------------------|-----------------------------|------------------------------|
| Acid No. (mg KOH/gm) | 0.002 | 0.002 | 0.003 |
| Color | C1 | C1 | C1 |
| Conductivity (pS/m) @72F | 42 | 231 | 399 |
| Gums (mg/100ml) | 3.4 | 5.2 | 14.2 |
| Hydroperoxides (mM) | 0.09 | 0.03 | 0 |

Evaluation Criteria

| | | |
|-------------------------|---------------|--------|
| Compression Set | Maximum Value | 30% |
| Elongation (%) | Decrease | 35% |
| Hardness, Shore A (pts) | Decrease | 20pts |
| Tensile (PSI) | Decrease | 45% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C ,C1--C6 is Clear, light to dark
W = Within Tolerance; O = Out of Tolerance;
NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data Non-Metals**

**Wright Patterson Air Force Base
and the
University of Dayton**

| | | | |
|----------------------------|-------|-----------------------|---|
| Material ID | I.G.5 | Material: | "O" ring, Fluorosilicone (Parker) L 677-70, Mil-P-25988 |
| Temperature (F): | 250 | Use: | Airframe, Fuel systems gaskets, "O"-Ring |
| Test date: | | Additive/Fuel: | Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980 |
| Test Length (days): | 28 | Baseline Fuel: | 93-POSF-2980 + (JP8 Additives) |

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | Evaluations | |
|-------------------------|----------|--------------|-------------------|------------------|-----|-------------|-------------|
| | | | | | | JP8+100 | JP8+100 x 4 |
| Compression Set | 18 | | | NA | W | NE | NE |
| Elongation (%) | 130 | 225 | 192 | 195 | W | W | W |
| Hardness, Shore A (pts) | 44 | 54 | 58 | 65 | OT | W | W |
| Tensile (PSI) | 162 | 546 | 562 | 984 | OT | W | W |
| Volume Swell (%) | 4 | 9 | 8 | NA | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|--------------------|----------------|----------------------|-----------------------|
|--------------------|----------------|----------------------|-----------------------|

Evaluation Criteria

| | | |
|-------------------------|---------------|--------|
| Compression Set | Maximum Value | 30% |
| Elongation (%) | Decrease | 35% |
| Hardness, Shore A (pts) | Decrease | 20pts |
| Tensile (PSI) | Decrease | 45% |
| Volume Swell (%) | Min/Max | 0%/25% |

Color - C ,C1--C6 is Clear, light to dark
W = Within Tolerance; O = Out of Tolerance;
NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data Non-Metals**

**Wright Patterson Air Force Base
and the
University of Dayton**

Material ID II.G.2 **Material:** "O" ring, Fluorosilicone (Parker) L 677-70, Mil-P-25988
Temperature (F): 325 **Use:** "O" Ring (Airframe /Engine)
Test date: 07-Sep-94 **Additive/Fuel:** Betz Dearborn 8Q462 (Normal & x4 Concentrations)/93-POSF-2980
Test Length (days): 28 **Baseline Fuel:** 93-POSF-2980 + (JP8 Additives)

| Material Property Tests | post JP8 | post JP8+100 | post JP8 +100 x 4 | Control Material | JP8 | <u>Evaluations</u> | |
|-------------------------|----------|--------------|-------------------|------------------|-----|--------------------|-------------|
| | | | | | | JP8+100 | JP8+100 x 4 |
| Compression Set | 121 | 131 | 139 | 896 | OT | OT | OT |
| Compression Set | 60 | 60 | 57 | NA | OT | OT | OT |
| Elongation (%) | 88 | 96 | 82 | 214 | OT | OT | OT |
| Hardness, Shore A (pts) | 38 | 40 | 41 | 67 | OT | OT | OT |
| Volume Swell (%) | 11 | 10 | 10 | NA | W | W | W |

| Fuel Property Test | JP8 w/material | JP8 + 100 w/material | JP8+100 x4 w/material |
|--------------------------|----------------|----------------------|-----------------------|
| Acid No. (mg KOH/gm) | .003 | .01 | .004 |
| Color | C3 | C3 | C3 |
| Conductivity (pS/m) @72F | 343 | 1011 | 627 |
| Gums (mg/100ml) | 12 | 13.6 | 20 |
| Hydroperoxides (mM) | .025 | .001 | NE |

Evaluation Criteria

| | | |
|-------------------------|---------------|--------|
| Compression Set | Maximum Value | 30% |
| Elongation (%) | Decrease | 35% |
| Hardness, Shore A (pts) | Decrease | 20 pts |
| Tensile (PSI) | Decrease | 45% |
| Volume Swell (%) | Maximum Value | 25% |

Color - C ,C1--C6 is Clear, light to dark
W = Within Tolerance; O = Out of Tolerance;
NSR = No Specification; NE Not Evaluated; NA = Not Applicable; ND = Not Detected

Table 7. Selected Fuel/Material Data

**Material Test
Data - Metals**

Wright Patterson Air Force Base

and the

University of Dayton

| | |
|-------------------------------|---|
| Test ID: II.M.18 | Material: Powder Metallurgy cpm 10V (Rolled Fe, V, CR, C, Mn, SiI, T,S,Mo CPM 10V) |
| Temperature (F): 325 | Use: Engine Fuel Lines & Components |
| Test date: 01-Aug-95 | Additive/Fuel: Betz Dearborn 8Q462 (Normal and x4 Concentrations)/93-POSF-2980 |
| Test Length (days): 28 | Baseline Fuel: 93-POSF-2980 + (JP8 Additives) |

| Material Property Test | Observations | | | | | | Evaluations | | |
|---------------------------|--|---------------|--------------|---------------|----------------|-----------------|-------------|----------|------------|
| | JP8 pre | JP8 post | JP8+100 pre | JP8+100 post | JP8+100 x4 Pre | JP8+100 x4 Post | JP8 | JP8 +100 | JP8+ 100x4 |
| Color | *L2 | **L4 | *L2 | *L3 | *L2 | *L2 | O | W | W |
| | *Light surface rust (Uniform corrosion), ** Medium Rusting (Uniform corrosion) | | | | | | | | |
| Pitting (Microscopy) | ND | P | ND | P | ND | P | CN | W | W |
| | pitting - all samples depth< 0.0016" | | | | | | | | |
| Pitting (Visual) | ND | ND | ND | ND | ND | ND | CN | W | W |
| Average Weight (gms) | 32.9016 | 32.9248 | 32.7326 | 32.7569 | 32.9687 | 32.9852 | | | |
| Percent Gain/Loss | | 0.07 | | 0.07 | | 0.05 | | | |
| Fuel Property Test | 7 Day | 28 Day | 7 day | 28 day | 7 day | 28 day | | | |
| Color | C2 | C3 | C2 | C2 | C2 | C3 | | | |
| Cr (ppb) | ND | 6 | 10 | 8 | 15 | 12 | | | |
| Fe (ppb) | 50 | 180 | 200 | 320 | 1050 | 1600 | | | |
| V (ppb) | ND | ND | ND | 60 | 30 | 110 | | | |
| Fuel Property Test | pre | post | pre | post | pre | post | | | |
| Conductivity (pS/m) @ 72 | 145 | 26 | 312 | 30 | 537 | 324 | | | |

Fuel Color - C ,C1--C6 is Clear, light to dark; Metal Color - L, L1--L6 is Light, light to dark deposit
W = Within Tolerance O = Out of Tolerance; NSR = No Specification
NE Not Evaluated; NA = Not Applicable; ND = Not Detected CN = Control

Table 8. Fuel/Material Screening Test Results

SCREENING TEST RESULTS FOR JP-8 + 100 ADDITIVES AND MATERIALS COMPATIBILITY COMPARISON CHART

10 NOV '96
Rev. 13 NOV '96
DHK/UDRI
PAGE 1 OF 3

| MATERIAL TEST I.D. TYPE TEST DATE | PHYSICAL PROPERTIES EVALUATED AT 28 DAYS 200° F | CONTROL AT ROOM TEMP. NO AGING | JP-8 FUEL (93 POSF) AGING 28 DAYS / 200 ° F | | | | | |
|---|--|--|---|---------------|----------|----------|----------|----------|
| | | | 2980 | 2926 | 2980 | 2926 | 2980 | 2926 |
| I.A.2 ADHESIVE FM 47 VINYL PHENOLIC 9/26/96 | LAP SHEAR (PSI) | 3755 | 3771 | 4000/ 2932 | 2982 | 3575 | 3188 | 3526 |
| | COHESIVE (%) | 100 | 100 | 100/ 100 | 100 | 100 | 100 | 100 |
| | | | | | | | | |
| | | | | | | | | |
| I.A.5 ADHESIVE EPON 828 DETA UN. MOD. EPOXY 9/27/96 | LAP SHEAR (PSI) | 4294 | 3879 | 3565/ 3659 | 3884 | 3702 | 3851 | 3693 |
| | COHESIVE (%) | 100 | 100 | 100/ 100 | 100 | 100 | 100 | 100 |
| | | | | | | | | |
| | | | | | | | | |
| I.F.5 ESM FOAM FOMEX CLASS I. MIL-F-87260 10/3/96 | TENSILE (PSI) | 12/ 15 | 9/ 11 | 9 | 11 | 8 | 11 | 8 |
| | ELONGATION (%) | 146/ 118 | 92/ 87 | 89 | 92 | 90 | 85 | 96 |
| | RESISTIVITY (PS/M) | 5.52E+11/ 1.29E+11 | 2.45E+12 3.92E+11 | 2.45E+12 | 3.98E+11 | 2.21E+12 | 3.06E+11 | 2.45E+12 |

Table 8. Fuel/Material Screening Test Results (continued)

SCREENING TEST RESULTS FOR JP-8 + 100 ADDITIVES AND MATERIALS COMPATIBILITY COMPARISON CHART

10 NOV '96
Rev. 13 NOV '96
DHK/UDRI
PAGE 2 OF 3

| MATERIAL TEST I.D. TYPE TEST DATE | PHYSICAL PROPERTIES EVALUATED AT 28 DAYS 200° F | CONTROL AT ROOM TEMP. NO AGING | JP-8 FUEL (93 POSF) AGING 28 DAYS / 200 ° F | | | | | | | 28 DAYS / 160 J F | |
|---|--|--|---|---------------|---------------|----------------------|-------------------|----------------------|-------------------|-----------------------|---------------------|
| | | | 2980 | 2926 | 2980 | 2926 | 2980 | 2926 | 2980 | 2980 | 2926 |
| | | | NO ADD. | NO ADD. | 1750 MOBIL | 1750 MOBIL | 1750 MOBIL X 4 | 1750 MOBIL X 4 | 1750 MOBIL X 4 | BETZ/ X 4 | 1750/ MOBIL/ X 4 |
| I.A.2 ADHESIVE FM 47 VINYL PHENOLIC 9/26/96 | LAP SHEAR (PSI) | 3755 | 3771 | 4000/ 2932 | 3575 | 2717 | 3575 | 3016 | NO RETEST | 2869/ 2950 | |
| | COHESIVE (%) | 100 | 100 | 100/ 100 | 100 | 40 | 100 | 60 | NO RETEST | 30/ 34 | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| I.A.5 ADHESIVE EPON 828 DETA UN. MOD. EPOXY 9/27/96 | LAP SHEAR (PSI) | 4294 | 3879 | 3565/ 3659 | 3591 | 3357 | 3595 | 3464 | NO RETEST | 3003 2953 | |
| | COHESIVE (%) | 100 | 100 | 100/ 100 | 100 | 100 | 100 | 80 | NO RETEST | 44/ 36 | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| I.F.5 ESM FOAM FOMEX CLASS I. MIL-F-87260 10/3/96 | TENSILE (PSI) | 12/ 15 | 9/ 11 | 9 | 8 | 8 | 7 | 8 | NO RETEST | 8/ 9 | |
| | ELONGATION (%) | 146 118 | 92/ 87 | 89 | 83 | 72 | 87 | 74 | NO RETEST | 88/ 91 | |
| | RESISTIVITY (PS/M) | 5.52E+11/ 1.29E+11 | 2.45E+12/ 3.92E+11 | 2.45E+12 | 3.06E+12 | 6.74E+12 1.84E+13 | 3.31E+12 | 6.13E+12 3.56E+12 | NO RETEST | 1.96E+12/ 1.59E+12 | |

Table 8. Fuel/Material Screening Test Results (continued)

SCREENING TEST RESULTS FOR JP-8 + 100 ADDITIVES AND MATERIALS COMPATIBILITY COMPARISON CHART

Rev. 13 NOV '96
DHK/UDRI
PAGE 3 OF 3

| MATERIAL TEST I.D. TYPE TEST DATE | PHYSICAL PROPERTIES EVALUATED AT 28 DAYS 200° F | CONTROL AT ROOM TEMP. NO AGING | JP-8 FUEL (93 POSF) AGING 28 DAYS / 200 °F | | | | | | | |
|---|--|--|--|----------|----------|----------|----------|----------|----------|----------|
| | | | 2980 | 2926 | 2926 | 2926 | 2926 | 2926 | 2926 | 2926 |
| I.A.2 ADHESIVE FM 47 VINYL PHENOLIC 9/26/96 | LAP SHEAR (PSI) | 3755 | 3771 | 4000 | 3500 | 3411 | 3573 | 3902 | 3549 | 3807 |
| | COHESIVE (%) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 |
| | | | | | | | | | | |
| | | | | | | | | | | |
| I.A.5 ADHESIVE EPON 828 DETA UN. MOD. EPOXY 9/27/96 | LAP SHEAR (PSI) | 4294 | 3879 | 3565 | 3757 | 3193 | 3387 | 3726 | 3540 | 3642 |
| | COHESIVE (%) | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 |
| | | | | | | | | | | |
| | | | | | | | | | | |
| I.F.5 ESM FOAM FOMEX CLASS I. MIL-F-87260 10/3/96 | TENSILE (PSI) | 12/ 15 | 9/ 11 | 9 | 8 | 8 | 8 | 8 | 11* | 11* |
| | ELONGATION (%) | 146/ 118 | 92/ 87 | 89 | 95 | 85 | 82 | 77 | 121* | 130* |
| | RESISTIVITY (PS/M) | 5.52E+11/ 1.29E+11 | 2.45E+12/ 3.92E+11 | 2.45E+12 | 5.82E+12 | 9.81E+12 | 3.68E+12 | 6.13E+12 | 6.13E+11 | 9.19E+11 |

* CREST (CLASS II) (NOT FOMEX)

This page intentionally left blank.

6. EXTENDED DURATION THERMAL STABILITY TEST RESULTS

A schematic of the EDTST system is shown in Figure 1. The system consists of a 60 gallon feed tank, an electrical motor driven gear pump, two clamshell furnace heaters, and a scrap tank. The primary test articles for the EDTST are the heater, preheater and heat exchanger tubes and two filters (2 and 7 micron).




Figure 1. Extended Duration Thermal Stability Test (EDTST) schematic.

The heater deposits relate to deposits that could occur in hot components such as fuel nozzles, heat exchangers or engine nozzle actuators. The segment with the largest deposits is related to the potential deposits in the fuel injection nozzle that could cause decreased flow or complete plugging.

The preheater deposits relate to deposits that could occur in heat exchangers, or engine control system valves (bypass, main control, or nozzle flow divider). The segment with the largest deposit relates to potential plugging that could occur in an engine heat exchanger. Another important aspect of the preheater is deposit that occurs at the exit to the preheater, which is unheated. The engine fuel systems valves are close tolerance and vulnerable to any significant deposits. The tolerances of the valves are in the range of 3 microns. Therefore, any detectable deposit at the exit from the preheater is considered to be unacceptable. The heat exchanger deposits are representative of deposits that could be experienced in a ram/air cooler located in a high temperature bypass line from an engine to an aircraft fuel tank..

The 2 μ filter deposit indicates the tendency of the recirculated fuel to form or carry deposits back to the aircraft fuel tanks/components. The 7 μ filter deposits are not significant for applications where the fuel is exposed to high temperatures only in the fuel nozzles, since the fuel is immediately sprayed into the engine burner after being subjected to the heater temperatures in the engine nozzles. This filter's deposits are very significant for future application where cooling of high temperature air or other high temperature components is experienced before the fuel enters the engine fuel nozzles. For these applications, tubing and valves will be exposed to fuel deposits as indicated by these filter deposits.

Recommended acceptance criteria for the test articles for meeting JP-8+100 fuel goals are as follows: Deposits in the test articles after this test shall not exceed the following:

Preheater tube maximum segment - 10 $\mu\text{g}/\text{cm}^2$.

Heat exchanger tube maximum segment - 30 $\mu\text{g}/\text{cm}^2$.

Heater tube maximum segment - 250 $\mu\text{g}/\text{cm}$.

2 micron filter - 300 μg .

7 micron filter - 10000 μg .

A summary of the test data for the EDTST is shown in Table 9. The test data that exceed the above acceptance criteria are shown in boldface.

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|-----------|---|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|-------------------------------------|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-16 | 2926 | 300 | 500 | | 235 | NA | NA | 72 hrs |
| RUN-17 | 2926 | 300 | 550 | | 771 | NA | NA | 72 hrs |
| RUN-18 | 2926 | 350 | 500 | 28,480-7 | 529 | NA | NA | 72 hrs |
| RUN-19 | 2926 | 250 | 500 | 264-7 | 270 | NA | NA | 72 hrs |
| RUN-20 | 2926 | 350 | 450 | 2,870-7 | 43 | NA | NA | 72 hrs |
| RUN-21 | 2926 | 350 | 500 | 2,450-7 | 283 | NA | NA | 72 hrs |
| RUN-22 | 2926 | 375 | 500 | No Data | 245 | NA | NA | 72 hrs - Filter plugged in 13 hours |
| RUN-23 | 2926 | 350 | 550 | 14,660-7 | 1,466 | NA | NA | 72 hrs |
| RUN-24 | 2926 (JP-8) | 350* | 450 | 5,090-7 | 1,228 | 85 | 37 | * indicates two pass recirculation |
| RUN-25 | 2926 (JP-8) | 325* | 450 | 3,260-7 | 321 | 14 | 11 | |
| RUN-26 | 2926 (JP-8) | 350* | 450 | 331-2 19,310-7 | 239 | 45 | 13 | |
| RUN-27 | 2926 (JP-8) | 350 | 450 | No Data | 414 | NA | NA | |
| RUN-28 | 2926 | 350* | 450 | 13,690-2 7,630-7 | 173 | 25 | No Data | |
| RUN-29 | 2926 (JP-8) | 300* | 400 | 284-7 | 15 | No Data | No Data | |
| RUN-30 | 2926 (JP-8) | 350* | 450 | 10,500-7 | 51 | 24 | 13 | |
| RUN-31 | 2926 (JP-8) | 350 | 500 | 3,530-7 | 424 | 11 | NA | |
| RUN-32 | 2926 (JP-8) +Betz8Q405&BH T (B&B) | 350 | 500 | 204-7 | 14 | 6 | NA | |
| RUN-33 | 2926 (JP-8) | 350* | 450 | 180-2 4,510-7 | 67 | 17 | No Data | |
| RUN-34 | 2926 (JP8) +B&B | 350 | 550 | 183-7 | 367 | NA | NA | |
| RUN-35 | 2926 (JP8) | 350 | 500 | 7,290-7 | 914 | 10 | NA | ½ gph |
| RUN-37 | 2926 +Mobil 477&BHT/MDA | 350 | 500 | 1,780-7 | 201 | 38 | NA | |
| RUN-38 | 2980 | 350 | 500 | 88,700-7 | 645 | 10 | NA | |
| RUN-39 | 2980 +B&B | 350 | 500 | 481-7 | 49 | 4 | NA | |
| RUN-40 | 2980 (JP8) +B&B | 350 | 500 | 386-7 | 47 | 4 | NA | |
| RUN-41 | JPTS | 425 | 550 | 2,150-7 | 605 | 117 | NA | |
| RUN-42 | JPTS | 350 | 500 | 233-7 | 14 | 10 | NA | |
| RUN-43 | 2980 (JP8) +B&B | 425 | 550 | 27,420-7 | 44 | 173 | NA | |
| RUN-44 | 2827 | 350 | 500 | 429,720-7 | 15,726 | 20 | NA | |
| RUN-45 | 2827 (JP8) +B&B | 350 | 500 | 76,960-7 | 262 | 7 | NA | |
| RUN-46 | 2827 | 350 | 450 | 58,530-7 | 273 | 15 | NA | |
| RUN-47 | 2827 (JP8) | 300* | 400 | 2,240-7 | 80 | 15 | 5 | F22 baseline |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|-----------|--|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|--------------------------|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-48 | 2926 | 350 | 500 | 44,170-7 | 1,896 | 25 | NA | |
| RUN-49 | 2827 (JP8) +B&B | 350* | 500 | 227-2 264-7 | 347 | 10 | 6 | |
| RUN-50 | JPTS | 350 | 550 | 3,880-7 | 16 | 10 | NA | |
| RUN-51 | JPTS | 425 | 550 | 1,260-7 | 267 | 127 | NA | |
| RUN-52 | 2980 (JP8) +B&B | 350 | 550 | 255-7 | 888 | 7 | NA | |
| RUN-53 | JPTS | 350* | 550 | 198-2 2,300-7 | 13 | 7 | No Data | |
| RUN-54 | 2827 | 350 | 500 | 500,440-7 | 2,443 | 12 | NA | Silicosteel |
| RUN-55 | 2980 (JP8) | 350* | 500 | 111,150-7 | 9,354 | 104 | 28 | |
| RUN-56 | 2980 (JP8) +Mobil 147B +BHT/MDA (M&B&M) | 350 | 500 | 433-7 | 87 | 10 | NA | |
| RUN-57 | 2980 (JP8) M&B&M | 350 | 550 | 522-7 | 1,140 | 40 | NA | |
| RUN-58 | 2827 | 350 | 500 | 90,190-7 | 1,636 | 10 | NA | 1/8" OD -.020" wall tube |
| RUN-59 | 2980 (JP8) +M&B&M | 350* | 500 | 266-2 374-7 | 38 | 13 | No Data | |
| RUN-61 | 2980 ARSFSS Run-21 | 300 | 450 | 27,580-7 | 148 | 6 | NA | |
| RUN-62 | 2980 (JP8) +Betz 8Q462 | 350* | 500 | 193-2 559-7 | 53 | 13 | No Data | |
| RUN-63 | 2980 | 300 | 450 | 263-7 | 14 | 6 | NA | |
| RUN-64 | 2980 (Used fuel Run-63) | 300 | 450 | 335-7 | 37 | 5 | NA | |
| RUN-65 | 2827 | 350 | 500 | 223,920-7 | 561 | NA | NA | |
| RUN-67 | 2980 | 300 | 450 | 450-7 | 31 | NA | NA | 1/2" OD ph tube |
| RUN-68 | 2980 (JP8) +Betz462 | 300 | 450 | N.D. | 16 | NA | NA | 2 gph |
| RUN-69 | 2827 (JP8) | 350 | 550 | 468,660-7 | 4,296 | 7 | NA | |
| RUN-71 | 2980 (JP8) +Betz 462 | 400* | 500 | 280-2 22,720-7 | 103 | 43 | No Data | |
| RUN-72 | 2827 (JP8) | 350 | 500 | 126,790-7 | 600 | 9 | NA | |
| RUN-73 | 2980 (JP8) +Betz 462 | 375* | 500 | 358-2 6,160-7 | 95 | 14 | | |
| RUN-74 | 2827 (JP8) +M&B&M | 400* | 500 | 218-2 2,350-7 | 470 | 307 | 149 | |
| RUN-75 | 3084 (JP8) | 350 | 500 | 20,150-7 | 4,381 | 14 | NA | |
| RUN-76 | 3084 (JP8) | 350* | 500 | 391-2 39,200-7 | 8,860 | 53 | No Data | |
| RUN-77 | 3084 (JP8) +Betz 462 | 350* | 500 | 170-2 930-7 | 102 | 8 | 8 | |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|-----------|----------------------------------|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|------------------------|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-78 | 2827 (JP8) +M&B&M | 350* | 500 | 199-2 276-7 | 171 | 17 | 6 | |
| RUN-80 | 3084 (JP8) | 350a | 500 | 95-2 2,330-7 | 1,305 | 32 | 6 | a-active recirculation |
| RUN-81 | 3084 (JP8) +1/2M&B&M +JP8d | 350a | 500 | 147-2 228-7 | 74 | 8 | 6 | |
| RUN-82 | 3119 (JP8) | 350a | 500 | | 4,260 | 30 | 6 | |
| RUN-83 | 3119 (JP8) | 350* | 500 | 86-2 6,390-7 | 5,139 | 44 | 8 | |
| RUN-84 | 3119 (JP8) | 350a | 490 | 92-2 2,060-7 | 2,974 | 24 | 6 | |
| RUN-85 | 3119 (JP8) +B&B&M | 350a | 500 | 90-2 330-7 | 61 | 4 | 5 | |
| RUN-86 | 3084 (JP8) +M1521 +B&M | 350a | 500 | 184-2 288-7 | 402 | 16 | 287 | |
| RUN-87 | 3084 (JP8) + SDA +B&M | 350a | 500 | 500-2 288-7 | 61 | 6 | 3 | |
| RUN-88 | 3084 (JP8) | 350a | 450 | 115-2 434-7 | 49 | 6 | 8 | |
| RUN-89 | 3119 (JP8d) | 350 | 500 | 5,130-7 | 1,717 | 15 | | |
| RUN-90 | 3084 (JP8) | 350a | 500 | 279-2 5,260-7 | 1,278 | 15 | 10 | |
| RUN-91 | 3119 (JP8) + MDA | 350a | 500 | 67-2 1,030-7 | 217 | 6 | 3 | |
| RUN-92 | 3119 (JP8) +M&B&M | 400a | 500 | 487-2 50,370-7 | 148 | 34 | 72 | |
| RUN-94 | 3119 (JP8) + M&B&M | 350a | 500 | 245-2 377-7 | 136 | 8 | 6 | |
| RUN-95 | 3119 (JP8) + B&B&M | 400a | 500 | 1,770-2 49,740-7 | 188 | 30 | 56 | |
| RUN-96 | 3084 (JP8) + B&B&M | 350a | 500 | 212-2 1,300-7 | 103 | 6 | 6 | |
| RUN-97 | 3084 (JP8) + MDA | 350a | 500 | 146-2 2,640-7 | 80 | 5 | 34 | |
| RUN-98 | 3084 (JP8) + BHT | 350a | 500 | 157-2 18,550-7 | 848 | 8 | 21 | |
| RUN-99 | 3084 (JP8) + MDA/BHT | 350a | 500 | 151-2 | 137 | 6 | 28 | |
| RUN-100 | 3084 (JP8) +B&B | 350a | 500 | 158-2 1,640-7 | 60 | 5 | 4 | |
| RUN-101 | 3119 (JP8) + BHT | 350a | 500 | No Data | 1,130 | 11 | 23 | |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|--|----------------------------|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|---|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-102 | 3119 (JP8) + MDA/BHT | 350a | 500 | 159-2 5,230-7 | 164 | 7 | 23 | |
| RUN-103 | 3119 (JP8) + Betz/BHT | 350a | 500 | 205-2 1,320-7 | 75 | 8 | 13 | |
| RUN-104 | 3084 (JP8) | 350a | 500 | 395-2 42,470-7 | 1,700 | 12 | 18 | |
| RUN-105 | 3084 (JP8) + B&B&M | 350a | 500 | No Data | 33 | 6 | 10 | |
| RUN-106 | 3084 (JP8) + MDA/BHT | 350a | 500 | 368-2 2,920-7 | 35 | 6 | 5 | |
| RUN-107 | 3119 (JP8) + MDA/BHT | 400a | 500 | 1,150-2 59,310-7 | 1,363 | 68 | 96 | |
| RUN-108 | 3166 (JP8) | 350h | 500 | 12,740-2 17,500-7 | 8,829 | 28 | 3 | |
| RUN-109 | 3119 (JP8) +SDA/BHT/MDA | 400h | 500 | 2,990-2 653-7 | 307 | 64 | 134 | |
| RUN-110 | 3084 (JP8) + Mobil/BHT | 350a | 500 | 192-2 263-7 | 156 | 7 | 11 | |
| RUN-111 | 3084 (JP8) + SDA/BHT | 350a | 500 | 220-2 2,190-7 | 113 | 10 | 5 | |
| RUN-113 Rn test $\frac{1}{2}$ gph $\frac{1}{2}$ " ph | 3119 (JP8) | 350 | 500 | | 3,409 | NA | NA | All Reynolds Number (Rn) tests were 50hrs |
| RUN-114 Rn test $\frac{3}{4}$ gph $\frac{1}{2}$ " ph | 3119 (JP8) | 350 | 500 | 13,070-7 | 2,618 | 23 | NA | Preheater also used in Run-113 |
| RUN-115 Rn test $\frac{1}{2}$ gph $\frac{3}{8}$ " ph | 3119 (JP8) | 350 | 500 | | 3,112 | NA | NA | |
| RUN-116 Rn test 1.0 gph $\frac{3}{8}$ " ph | 3119 (JP8) | 350 | 500 | | 880 | NA | NA | Same tube as Run-115 |
| RUN-117 Rn test $\frac{1}{2}$ gph $\frac{1}{4}$ " ph | 3119 (JP8) | 350 | 500 | | 5,304 | NA | NA | |
| RUN-118 Rn test $1\frac{1}{2}$ gph $\frac{1}{2}$ " ph | 3119 (JP8) | 350 | 500 | 13,890-7 | 1,036 | NA | NA | |
| RUN-121 | 3166 (JP8) | 400a | 500 | 72-2 9,068-7 | 8,386 | 181 | 63 | Test stopped after 24 Hrs |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|--------------------------------------|-------------------------------------|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|---|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-122 Rn test ½ gph ¼" ph | 3119 (JP8) + B&B&M | 350 | 500 | 386-7 | 117 | NA | NA | |
| RUN-123 Rn test ½ gph ¼" ph | 3119 (JP8) | 350 | 500 | 3,130-7 | 2,381 | NA | NA | |
| RUN-124 Rn test ½ gph ½" ph | 3119 (JP8) | 350 | 500 | 9,410-7 | 1,345 | NA | NA | |
| RUN-125 | 3119 (JP8) + B&B&M | 425a | 530 | 4,620-2 3,110-7 | 108 | 43 | No Data | 6 hr QCT Demo |
| RUN-126 | 3166 (JP8) 125% B&B&M | 400a | 500 | 23-2 23-7 | 269 | 28 | 20 | |
| RUN-127 | 3166 (JP8) + B&B&M | 400a | 500 | 240-2 1,310-7 | 221 | 30 | 11 | |
| RUN-128 Rn test ½ gph ¼" ph | 3119 (JP8) | 350 | 500 | 13,610-7 | 1,157 | NA | NA | |
| RUN-129 | 3119 (JP8) | 350 | 500 | No Data. | 4,150 | No Data | NA | Baseline test copper doped fuel 1 gph, 50 hrs, ½" ph, no recirculation. |
| RUN-130 | 3166 (JP8) + B&M | 400a | 500 | 226-2 51,740-7 | 250 | 15 | 7 | No BHT |
| RUN-131 | 3166 (JP8) +200% B&B&M | 400a | 500 | 256-2 175-7 | 147 | 11 | 12 | |
| RUN-132 | 3119 (JP8) Cu doped | 300a | 450 | 305-2 4,690-7 | 1,247 | No Data | No Data | |
| RUN-133 Rn test ½ gph ½" ph | 3119 (JP8) | 350 | 500 | 8,650-7 | 1,180 | NA | NA | |
| RUN-135 | 3166 (JP8) + B&PDA 5%)&M | 400a | 500 | 5,370-2 198,140-7 | 301 | 36 | 265 | |
| RUN-136 | 3119 (JP8) +250ppb cu | 350a | 500 | 21,450-2 126,980-7 | 8,587 | 43 | 173 (also – 132) | 50 Hr test |
| RUN-137 | 3119 (JP8) + B&B&M +250ppb cu | 350a | 500 | 46,150-2 78,400-7 | 484 | No Data | No Data | 50 Hr test |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|-----------|--------------------------------------|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|---|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-138 | 3119 (JP8) + M&B&M +250ppb cu | 350a | 500 | 38,640-2 49,300-7 | 79 | 12 | 12 | 50 Hr test |
| RUN-140 | JP-TS | 400a | 500 | 2,230-2 31,000-7 | 3,065 | 40 | 116 | |
| RUN-141 | 3166 (JP8) +150%Betz + BHT/MDA | 400a | 500 | 2,930-2 155,190-7 | 245 | 22 | 78 | |
| RUN-142 | 3166 (JP8) + SDA/B/M | 400a | 500 | No Data | 12,461 | 410 | No Data | Test stopped after 40 hrs due to 100 °F heater temp rise. |
| RUN-143 | 3166 (JP8) + B/B/M | 400a | 500 | 1,470-2 141,550-7 | 172 | 23 | 80 | Same fuel used in ARSFSS Run-42 |
| RUN-144 | 3166 (JP8) + B/B/M | 350a | 500 | 214-2 1,030-7 | 42 | 3 | 8 | |
| RUN-145 | 3166 (JP8) + Ethyl 3263 | 350a | 500 | 265-2 743-7 | 280 | 14 | 3 | |
| RUN-146 | 3166 (JP8) +2xB/B/M | 400a | 500 | 284-2 103,190-7 | 149 | 19 | 52 | |
| RUN-147 | 3166 (JP8) +1.5xB/B/M | 385a | 500 | 264-2 415-7 | 153 | 10 | 7 | |
| RUN-148 | 3119 (JP8) +B/B/M +929ppb Cu | 350a | 500 | 1,900-2 68,950-7 | 342 | No Data | No Data | Fuel stored at 140 °F for 30 days with all additives. |
| RUN-149 | 3166 (JP8) + B/B/M +839ppb Cu | 350a | 500 | 2,190-2 48,070-7 | 771 | 35 | 313 | |
| RUN-150 | 3166 (JP8) +B/B/M +607ppb Cu | 350a | 500 | 3,110-2 29,640-7 | 441 | No Data | No Data | |
| RUN-151 | 3166 (JP8) + B/B/M +518ppb Cu | 350a | 500 | 2,260-2 60,670-7 | 385 | 41 | 260 | |
| RUN-153 | 3166 (JP8) + Ethyl 3300 | 350a | 500 | 24-2 32-7 | 150 | 11 | 5 | |
| RUN-154 | 3305 (JP8) | 350a | 500 | 213-2 80,880-7 | 414 | 5 | 14 | |
| RUN-155 | 3305 (JP8) + B/B/M +518ppb Cu | 350a | 500 | 2,750-2 73,520-7 | 2,448 | 44 | 190 | |
| RUN-157 | 3166 (JP8) + B/B/M | 350a | 500 | 209-2 663-7 | 93 | 4 | 6 | |
| RUN-158 | 3166 (JP8) +Ethyl +BHT/MDA | 350a | 500 | 3,390-2 7,950-7 | 1,590 | 4 | 4 | |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|-----------|--|---------------|----------------------|-----------------------|----------------------------------|-------------------------------------|--------------------------------------|---|
| | | | | | Heater $\mu\text{g}/\text{cm}^2$ | Preheater $\mu\text{g}/\text{cm}^2$ | Heat Exch. $\mu\text{g}/\text{cm}^2$ | |
| RUN-159 | JP7 | 425a | 550 | 45-2 458-7 | 18 | 4 | 15 | |
| RUN-160 | 3084 (JP8) + Betz462 | 400a | 500 | 2,020-2 90,000-7 | 185 | 26 | 136 | |
| RUN-161 | 3166 (JP8) + Ethyl 3345 | 350a | 500 | 8,700-2 19,540-7 | 228 | 19 | 6 | |
| RUN-162 | 3166 (JP8) + Ethyl 3346 | 350a | 500 | 181-2 251-7 | 105 | 10 | 4 | LECO problems suspected (test to be repeated) |
| RUN-163 | 3305 (JP8) (Suspect Betz) +140ppb Cu | 300a | 400 | 170-2 14,030-7 | 22 | 3 | 17 | 50Hr test |
| RUN-164 | 3166 (JP8) + Betz 462 | 350a | 500 | 287-2 470-7 | 72 | 3 | 10 | |
| RUN-165 | 3166 (JP8) + Ethyl 3346 | 350a | 500 | 310-2 364-7 | 116 | 7 | 8 | Repeat of Run-162 |
| RUN-166 | 3305 (JP8) + Betz 462 +410ppb Cu | 350a | 500 | 305-2 11,490-7 | 60 | 3 | 16 | |
| RUN-167 | 3219 (JP8) | 350a | 500 | 163-2 40,530-7 | 9,924 | 7 | 5 | |
| RUN-168 | 3219 (JP8) + Betz 462 | 350a | 500 | 163-2 453-7 | 64 | 3 | 5 | |
| RUN-169 | 3219 (JP8) + Mobil/B/M | 350a | 500 | 164-2 165-7 | 282 | 3 | 5 | |
| RUN-170 | 3219 (JP8) + SDA/B/M | 350a | 500 | 171-2 279-7 | 35 | 7 | 5 | |
| RUN-171 | 3219 (JP8) + Octel1755 | 350a | 500 | 217-2 336-7 | 41 | 3 | 7 | |
| RUN-172 | 3219 (JP8) + Ethyl 3346 | 350a | 500 | 187-2 167-7 | 125 | 6 | 7 | |
| RUN-173 | 3219 (JP8) + Betz 462 | 400a | 500 | 179-2 565-7 | 255 | 3 | 4 | |
| RUN-174 | 3219 (JP8) + SDA /BHT/MDA | 400a | 500 | 158-2 352-7 | 38 | 13 | 12 | |
| RUN-175 | 3219 (JP8) + Ethyl 3357 | 400a | 500 | 210-2 384-7 | 205 | 48 | 10 | |
| RUN-176 | 3219 (JP8) + Ethyl 3407 | 350a | 500 | BTD BTD | 59 | 7 | 5 | |
| RUN-182 | 3219 (JP8) + Ethyl 5323 | 350a | 500 | 220-2 120-7 | 35 | 3 | 5 | |
| RUN-183 | 3219 (JP8) + Ethyl 5323 | 400a | 500 | 200-2 924-7 | 78 | 33 | 7 | |

Table 9. Summary of EDTST Runs

| Test Runs | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Filters μg | Maximum Deposits | | | Comments |
|--------------|------|---------------------|-------------------------------|---------------|------------------------------|---------------------------------|-------------------------------------|----------|
| | | | | | Heater μg/cm ² | Preheater μg/cm ² | Heat Exch. μg/cm ² | |

Notes:

1. Duration of tests was 96 hours unless otherwise indicated.
2. The 2 and 7 micron filters are identified by (-2) and (-7), respectively.
3. A test series to evaluate Reynolds Number (Rn) sensitivity was initiated, but was not completed due to higher priority tests.
4. Bold indicates unacceptable deposits.

7. ADVANCED REDUCED SCALE FUEL SYSTEM SIMULATOR RESULTS

The ARSFSS is capable of simulating thermal and flow profiles of aircraft fuel systems. It also has valves that are representative of actual aircraft. The simulator consists of three major systems. These systems are the fuel conditioning system, the airframe fuel system simulator and the engine fuel system simulator. A schematic of this Simulator is shown in Figure 2. The simulator is configured for simulating an F-22 aircraft with an F119 engine. The flow established for the simulator is approximately 1/72 scale of the F119 engine. The burn flow for the simulator is 1/3 of the flow for a single F119 fuel nozzle. The total flow that is required for each test is approximately 1,500 gallons.




Figure 2. Advanced Reduced Scale Fuel System Simulator (ARSFSS) schematic.

The primary test articles contained in the simulator are (1) the fuel cooled oil cooler (FCOC), (2) the flow divider valve, (3) the burner feed arm (BFA), and (4) servovalves #1 and 2. The FCOC (Figure 2) represents the engine lube system cooler. It consists of an induction heater and a steel manifold with three 3/8" - .035 inch wall tubes and associated thermocouples. The tubes are connected and provide for three passes through the heater. The tube that is used for the final pass through the heater is removed

after each test. It is, then, cut into 2 inch segments and subjected to carbon analysis. The flow divider valve is an actual F119 valve that has been modified by changing the slot width for the reduced flow. The materials, clearances and function are representative of the F119 flow divider valve. The performance of this valve is determined by hysteresis and visual inspection. The burner feed arm is RF induction heated. It consists of a steel clamshell with a 1/8 inch - .020 inch wall stainless steel tube installed in the middle of the clamshell. Thermocouples on the outside of the tube are located along the entire length to measure the temperature profile of the tube. At the end of the tests, this tube is cut up into 1 inch sections and subjected to carbon burnoff. The servovalves are electrohydraulic valves used in the engine control system. The materials and clearances are representative of the actual engine valves. The performance of these valves is determined by hysteresis and visual inspection.

A summary of the tests conducted by the ARFSS is shown in Table 10. All tests consisted of 75 missions (150 hours approximately) of a generic F-22 aircraft duty cycle.

Table 10. Summary of ARSFSS Runs.

| RUN-# | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Maximum Deposits | | | Comments |
|--|--|---------------|----------------------|-------------------------------|--------------------------------|-----------------------|--|
| | | | | BFA $\mu\text{g}/\text{cm}^2$ | FCOC $\mu\text{g}/\text{cm}^2$ | Visual Valve Deposits | |
| RUN#19 | 2980 | 300 | 450 | 878 | | | |
| RUN#20 | 2980 | 300 | 450 | 657 | | slight | |
| RUN#21 | 2980 | 300 | 450 | 982 | | slight | No Recirculation |
| RUN#22 | 2980 (JP-8) +Betz 8Q405 +BHT | 300 | 450 | 27 | | none | |
| RUN#23 | 2980 (JP-8) | 300 | 450 | 263 | | slight | |
| RUN#24 | 2980 | 300 | 450 | 1,287 | | significant | |
| RUN#25 | 2980 (JP-8) | 300 | 450 | 296 | | slight | |
| VICKERS PUMP INSTALLED | | | | | | | |
| RUN#26 | 2980 (JP-8) | 300 | 450 | 10 | | slight | |
| RUN#27 | 2980 | 300 | 450 | 91 | | slight | |
| ALL of the following tests are with recirculation unless noted otherwise. | | | | | | | |
| RUN#28 | 2980 (JP-8) | 325 | 450 | 49 | | slight | |
| RUN#29 | 3119 (JP-8) | 350 | 500 | 4,556 | | significant | |
| RUN#30 | 3119 (JP-8) +Betz 8Q405 +BHT | 350 | 500 | 41 | | slight | |
| RUN#31 | 3119 (JP-8) +Mobil 147B +BHT +MDA | 350 | 500 | 81 | | slight | |
| RUN#32 | 3119 +Betz 8Q405 +BHT & +JP-8 ALTERNATELY | 350 | 500 | | | slight | |
| RUN#33 | 3119 (JP-8) +Betz 8Q405 +BHT + MDA & +Mobil 147B +BHT +MDA CO-Mingled | 350 | 500 | 46 | | slight | |
| RUN#34 | 3119 (JP-8) | 350 | 500 | 1,166 | | | Rn Test-50 Hrs 10.7 pph (2500 Rn) No Recirculation |
| RUN#35 | 3119 (JP-8) | 350 | 500 | 44 | | | Rn Test-50 Hrs 21.4 pph (5000 Rn) No Recirculation |
| RUN#37 | 3119 (JP-8) +BHT +MDA | 350 | 500 | 58 | | slight | |

Table 10. Summary of ARSFSS Runs.

| RUN-# | Fuel | Bulk Temp (F) | Wetted Wall Temp (F) | Maximum Deposits | | | Comments |
|--------|---|---------------|----------------------|-------------------------------|--------------------------------|------------------------------|---------------|
| | | | | BFA $\mu\text{g}/\text{cm}^2$ | FCOC $\mu\text{g}/\text{cm}^2$ | Visual Valve Deposits | |
| RUN#38 | 3119 (JP-8) +SDA +BHT +MDA | 350 | 500 | 73 | | none | |
| RUN#39 | 3166 (JP-8) +Betz 8Q462 | 400 | 500 | 106 | 81 | significant | |
| RUN#40 | 3166 (JP-8) +Betz 8Q462 | 375 | 500 | 115 | 12 | none | |
| RUN#41 | 3166 (JP-8) +200% Betz 8Q405 +BHT +MDA | 400 | 500 | 73 | 26 | significant | |
| RUN#43 | 3166 (JP-8) +Betz 8Q462 | 385 | 500 | 75 | 19 | significant | |
| RUN#44 | 3166 (JP-8) +150% Betz 8Q405 +BHT +MDA | 400 | 500 | 82 | 24 | significant | 315 °F Bypass |
| RUN#47 | 3166 (JP-8) | 350 | 500 | 5,441 | 60 | significant | |
| RUN#48 | 3166 (JP-8) +Betz8Q462 | 400 | 500 | 15 | 53 | slight to significant | |

Notes:

1. All runs were with recirculation except as noted.
2. The visual valve deposits were on servo#2 and the flow divider valves.
3. A test series to evaluate Reynolds Number (Rn) sensitivity were conducted similar to the EDTST.
4. Bold indicates unacceptable deposits.

8. CONCLUSIONS

This report consists of data set summaries of tests performed in support of the development of advanced jet fuels, including JP-8+100, JP-900, and endothermic fuels. For the development of JP-8+100 fuel, we have tested hundreds of additives in both small and large scale test devices. We formulated combinations of the best additives (detergent/dispersant, hindered phenol antioxidant, and metal deactivator) and demonstrated their efficacy in reducing deposition in realistic aircraft conditions in large-scale simulator rigs. We optimized the concentrations of these additives for maximum effectiveness and minimum cost. We performed extensive studies of the compatibility of these fuel additives with current and future aircraft fuel system materials. We determined that the current best additives show no negative effects on both metallic and non-metallic fuel system materials.

We also performed extensive studies on the fundamental processes of fuel oxidation, deposition, and pyrolysis. We developed chemical kinetic mechanisms which can simulate the oxidation and deposition processes. We performed experimental and modeling studies on fuel cooling which shows that deposition which occurs in fuel cooling heat exchangers can be a significant problem in fuel system design. We demonstrated an inverse relationship between oxidation and deposition over a range of fuels, and showed that our chemical kinetic mechanism can be used to explain this seemingly anomalous result. We developed statistical techniques to assist the evaluation of jet fuel additives, thermal stability measurements, and aircraft field performance. We developed a wide variety of fuels analysis techniques for measurement of the following: dissolved oxygen, detergent/dispersant capacity, antioxidants and phenolics, hydroperoxides, trace jet fuel compounds, metal deactivators, products of endothermic reforming, dissolved and free water in fuel, BHT, Betz dispersant, and elemental metals. We explored alternative techniques for reducing jet fuel deposition including: removal of dissolved oxygen, silylating agents, oxygen scavenging additives, and solid-phase extraction.

We also made progress in support of development of future fuels such as JP-900 and endothermic fuels. We explored the effect of supercritical fluid properties on high temperature fuels. We have begun to study the pyrolysis of fuel in catalytic and non-catalytic reaction systems.

This page intentionally left blank.

REFERENCES

- (1) Klavetter, E. A., Martin, S. J., and Wessendorf, K. O., 1993, "Monitoring Jet Fuel Thermal Stability Using a Quartz Crystal Microbalance," *Energ. Fuels*, Vol. 7, pp. 582-588.
- (2) Zabarnick, S., 1994, "Studies of Jet Fuel Thermal Stability and Oxidation Using a Quartz Crystal Microbalance and Pressure Measurements," *Ind. Eng. Chem. Res.*, Vol. 33, pp. 1348-1354.
- (3) Zabarnick, S., and Whitacre, S. D., 1998, "Aspects of Jet Fuel Oxidation," *J. Eng. Gas Turbines Power*, Vol. 120, pp. 519-525.
- (4) Zabarnick, S., and Grinstead, R. R., 1994, "Studies of Jet Fuel Additives using the Quartz Crystal Microbalance and Pressure Monitoring at 140 C," *Ind. Eng. Chem. Res.*, Vol. 33, pp. 2771-2777.
- (5) Zabarnick, S., 1994, "Evaluation of Jet Fuels and Jet Fuel Additives Using the Quartz Crystal Microbalance and Pressure Measurements," University of Dayton Research Institute, UDR-TR-94-63.
- (6) Zabarnick, S., Zelesnik, P., and Whitacre, S. D., 1995, "Evaluation of Jet Fuels and Jet Fuel Additives Using the Quartz Crystal Microbalance and Pressure Measurements. Part II.," University of Dayton Research Institute, UDR-TR-95-98.
- (7) Zabarnick, S., Whitacre, S. D., and Mick, M. S., 1997, "Evaluation of Jet Fuels and Jet Fuel Additives Using the Quartz Crystal Microbalance and Pressure Measurements. Part III.," University of Dayton Research Institute, UDR-TR-97-108.
- (8) Zelesnik, P., 1995, "Studies of Jet Fuel Thermal Stability, Oxidation and Additives Using the Quartz Crystal Microbalance and Oxygen Monitoring," M.S. Thesis, University of Dayton.
- (9) Grinstead, R., 1994, "Evaluation of JP-8+100 Additives by the Isothermal Corrosion Oxidation Test and the Microcarbon Residue Test," University of Dayton Research Institute, UDR-TR-94-63.
- (10) Heneghan, S. P., Martel, C. R., Williams, T. F., and Ballal, D. R., 1993, "Studies of Jet Fuel Thermal Stability in a Flowing System," *J. Eng. Gas Turbines Power*, Vol. 115, pp. 480-490.
- (11) Katta, V. R., Jones, E. G., and Roquemore, W. M., 1997, "Modeling of Deposition Process in Liquid Fuels," ASME, 97-3040.

- (12) Chin, L. P., Katta, V. R., and Heneghan, S. P., 1994, "Computer Modeling of Deposits Formed in Jet Fuels," *Prepr.-Am. Chem. Soc., Div Pet. Chem.*, Vol. 39, pp. 19-25.
- (13) Heneghan, S. P., Martel, C. R., Williams, T. F., and Ballal, D. R., 1995, "Effects of Oxygen and Fuel Additives on the Thermal Stability of Jet Fuels," *J. Eng. Gas Turbines Power*, Vol. 117, pp. 120-124.
- (14) Ervin, J. S., Williams, T. F., and Katta, V. R., 1996, "Global Kinetic Modeling of Aviation Fuel Fouling in Cooled Regions in a Flowing System," *Ind. Eng. Chem. Res.*, Vol. 35, pp. 4028-4032.
- (15) Zabarnick, S., 1998, "Chemical Kinetic Modeling of Antioxidant Chemistry for Jet Fuel Applications," *Energ. Fuels*, Vol. 12, pp. 547-553.
- (16) Ervin, J. S., and Zabarnick, S., 1998, "Computational Fluid Dynamics Simulations of Jet Fuel Oxidation Incorporating Pseudo-Detailed Chemical Kinetics," *Energ. Fuels*, Vol. 12, pp. 344-352.
- (17) Heneghan, S. P., Zabarnick, S., Ballal, D. R., and Harrison, W. E., 1996, "JP-8+100: Development of a Thermally Stable Jet Fuel," *J. Energy Res. Tech.*, Vol. 118, pp. 170-179.
- (18) Williams, T. F., Martel, C. R., and Blust, J., 1994, "Studies of Thermal Stability of Jet Fuels, Vol. I: Experimental Work," University of Dayton Research Institute, UDR-TR-94-10.
- (19) Williams, T. F., Martel, C. R., and Blust, J., 1994, "Studies of Thermal Stability of Jet Fuels, Vol. II: Data Sets," University of Dayton Research Institute, UDR-TR-94-11.
- (20) Rubey, W. A., Striebich, R. C., Tissandier, M. D., Tirey, D. A., and Anderson, S. D., 1995, "Gas Chromatographic Measurement of Trace Oxygen and Other Dissolved Gases in Thermally Stressed Jet Fuel," *J. Chrom. Sci.*, Vol. 33, pp. 433-437.
- (21) Kalt, D. H., 1997, "Fuel and Fuel System Materials Compatibility Test Program for a JP-8+100 Fuel Additive," University of Dayton Research Institute, UDR-TR-97-01.